

Problem 7.35

Some metals, like lead for example, have recrystallization temperatures as low as 30% of the absolute melting temperatures. For lead, this means a recrystallization temperature in the room temperature range. The new grains are continuously forming and nullifying the effects of cold work. Such materials are said not to strain harden.