

When we start Picosoft, all of the markers are OFF by default. If we want to start with some particular marker set to ON, we need some sort of initialization code. Suppose we are using 5 markers and we want to start with marker M01 ON. We will use the following code:

