

Follow steps provided below to enable BlueTooth

1. Boot laptop into BIOS
2. In BIOS -> Security -> I/O Ports Access -> BlueTooth -> Enabled
3. Press F10 and Select Yes
4. In Windows, ensure you have the following installed. Here are links to them (one is Power Manager 3.62 or so, one is Power Management Driver 1.62 or so (you may have a higher one, if so keep yours) and Hotkey Features 3.52 or so):
  - [83ku14ww.exe](#)
  - [8mvu32ww.exe](#)
  - [8ru410ww.exe](#)

Once the above 3 has been installed

5. Reboot the laptop
6. Ensure the BlueTooth / WLAN switched is on (you'll see Bluetooth symbol on the hinge part of your laptop)
7. Once the laptop has been booted into Windows
8. Press Fn + F5 and select On Bluetooth (if already on, that's great)
9. Once its On, Windows will show a notification that there is a new hardware found. (or maybe not, if not no problem).
10. Reboot then done. (may not need to reboot here, not sure)