ISE In-Depth Tutorial

UG695 (v13.4) January 18, 2012





Xilinx is disclosing this user guide, manual, release note, and/or specification (the "Documentation") to you solely for use in the development of designs to operate with Xilinx hardware devices. You may not reproduce, distribute, republish, download, display, post, or transmit the Documentation in any form or by any means including, but not limited to, electronic, mechanical, photocopying, recording, or otherwise, without the prior written consent of Xilinx. Xilinx expressly disclaims any liability arising out of your use of the Documentation. Xilinx reserves the right, at its sole discretion, to change the Documentation without notice at any time. Xilinx assumes no obligation to correct any errors contained in the Documentation, or to advise you of any corrections or updates. Xilinx expressly disclaims any liability in connection with technical support or assistance that may be provided to you in connection with the Information.

THE DOCUMENTATION IS DISCLOSED TO YOU "AS-IS" WITH NO WARRANTY OF ANY KIND. XILINX MAKES NO OTHER WARRANTIES, WHETHER EXPRESS, IMPLIED, OR STATUTORY, REGARDING THE DOCUMENTATION, INCLUDING ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT OF THIRD-PARTY RIGHTS. IN NO EVENT WILL XILINX BE LIABLE FOR ANY CONSEQUENTIAL, INDIRECT, EXEMPLARY, SPECIAL, OR INCIDENTAL DAMAGES, INCLUDING ANY LOSS OF DATA OR LOST PROFITS, ARISING FROM YOUR USE OF THE DOCUMENTATION.

© Copyright 2002-2012 Xilinx Inc. All Rights Reserved. XILINX, the Xilinx logo, the Brand Window and other designated brands included herein are trademarks of Xilinx, Inc. All other trademarks are the property of their respective owners. The PowerPC name and logo are registered trademarks of IBM Corp., and used under license. All other trademarks are the property of their respective owners.

Revision History

The following table shows the revision history for this document.

Date	Version	Revision		
03/01/11	13.1	Changed tutorial directory to: c:\xilinx_tutorial		
		Updated CORE Generator tool graphics.		
		Updated third party synthesis tool versions.		
10/19/11	13.3	Revalidated for the 13.3 release. Editorial updates only; no technical content updates.		
01/18/12	13.4	Revalidated for the 13.4 release. Editorial updates only; no technical content updates.		

Table of Contents

Revision History 2
Chapter 1: Introduction
About the In-Depth Tutorial
Tutorial Contents 5
Tutorial Flows
Chapter 2: Overview of the ISE Design Suite
Software Overview
Using Project Revision Management Features
Chapter 3: HDL-Based Design
Overview of HDL-Based Design
Getting Started
Design Description
Design Entry
Synthesizing the Design 33
Chapter 4: Schematic-Based Design
Overview of Schematic-Based Design
Getting Started
Design Description
Design Entry 46
Chapter 5: Behavioral Simulation
Overview of Behavioral Simulation Flow 75
ModelSim Setup
ISim Setup
Getting Started
Adding an HDL Test Bench
Behavioral Simulation Using ModelSim79
Behavioral Simulation Using ISim
Chapter 6: Design Implementation
Overview of Design Implementation
Getting Started
Specifying Options

Translating the Design	
Using the Constraints Editor	95
Assigning I/O Locations Using the PlanAhead Tool	101
Mapping the Design	104
Using Timing Analysis to Evaluate Block Delays After Mapping	106
Placing and Routing the Design	108
Using FPGA Editor to Verify the Place and Route	109
Evaluating Post-Layout Timing	111
Creating Configuration Data	113
Command Line Implementation	116

Chapter 7: Timing Simulation

Overview of Timing Simulation Flow	117
Getting Started	117
Timing Simulation Using ModelSim	118
Timing Simulation Using Xilinx ISim	126

Chapter 8: Configuration Using iMPACT

Overview of iMPACT 13	31
Device Support	31
Download Cable Support 13	31
Configuration Mode Support 13	31
Getting Started 13	32
Using Boundary-Scan Configuration Mode 13	33
Troubleshooting Boundary-Scan Configuration 14	40
Creating an SVF File 14	41

Appendix A: Additional Resources

Xilinx Resources	147
ISE Design Suite Documentation	147



Chapter 1

Introduction

About the In-Depth Tutorial

This tutorial gives a description of the features and additions to the Xilinx® ISE® Design Suite. The primary focus of this tutorial is to show the relationship among the design entry tools, Xilinx and third-party tools, and the design implementation tools.

This guide is a learning tool for designers who are unfamiliar with the features of the ISE Design Suite or those wanting to refresh their skills and knowledge.

You may choose to follow one of the three tutorial flows available in this document. For information about the tutorial flows, see Tutorial Flows.

Tutorial Contents

This guide covers the following topics:

- Chapter 2, Overview of the ISE Design Suite, introduces you to the primary user interface for the ISE Design Suite, Project Navigator, and the synthesis tools available for your design.
- Chapter 3, HDL-Based Design, guides you through a typical HDL-based design procedure using a design of a runner's stopwatch. This chapter also shows how to use ISE Design Suite accessories, such as the CORE Generator[™] tool and ISE Text Editor.
- Chapter 4, Schematic-Based Design, explains many different facets of a schematic-based ISE Design Suite design flow using a design of a runner's stopwatch. This chapter also shows how to use ISE Design Suite accessories, such as the CORE Generator tool and ISE Text Editor.
- Chapter 5, Behavioral Simulation, explains how to simulate a design before design implementation to verify that the logic that you have created is correct.
- Chapter 6, Design Implementation, describes how to Translate, Map, Place, Route, and generate a bitstream file for designs.
- Chapter 7, Timing Simulation, explains how to perform a timing simulation using the block and routing delay information from the routed design to give an accurate assessment of the behavior of the circuit under worst-case conditions.
- Chapter 8, Configuration Using iMPACT, explains how to program a device with a newly created design using the IMPACT configuration tool.

Tutorial Flows

This document contains three tutorial flows. In this section, the three tutorial flows are outlined and briefly described to help you determine which sequence of chapters applies to your needs. The tutorial flows include the following:

- HDL design flow
- Schematic design flow
- Implementation-only flow

HDL Design Flow

The HDL design flow is as follows:

- 1. Chapter 3, HDL-Based Design
- Chapter 5, Behavioral Simulation
 Note: Although behavioral simulation is optional, it is strongly recommended in this tutorial flow.
- 3. Chapter 6, Design Implementation
- 4. Chapter 7, Timing Simulation
 - *Note:* Although timing simulation is optional, it is strongly recommended in this tutorial flow.
- 5. Chapter 8, Configuration Using iMPACT

Schematic Design Flow

The schematic design flow is as follows:

- 1. Chapter 4, Schematic-Based Design
- Chapter 5, Behavioral Simulation
 Note: Although behavioral simulation is optional, it is strongly recommended in this tutorial flow.
- 3. Chapter 6, Design Implementation
- 4. Chapter 7, Timing Simulation

Note: Although timing simulation is optional, it is strongly recommended in this tutorial flow.

5. Chapter 8, Configuration Using iMPACT

Implementation-Only Flow

The implementation-only flow is as follows:

- 1. Chapter 6, Design Implementation
- 2. Chapter 7, Timing Simulation

Note: Although timing simulation is optional, it is strongly recommended in this tutorial flow.

3. Chapter 8, Configuration Using iMPACT



Chapter 2

Overview of the ISE Design Suite

Software Overview

The ISE® Design Suite controls all aspects of the design flow. Through the Project Navigator interface, you can access all of the design entry and design implementation tools. You can also access the files and documents associated with your project.

Project Navigator Interface

By default, the Project Navigator interface is divided into four panel sub-windows, as seen in Figure 2-1. On the top left are the Start, Design, Files, and Libraries panels, which include display and access to the source files in the project as well as access to running processes for the currently selected source. The Start panel provides quick access to opening projects as well as frequently access reference material, documentation and tutorials. At the bottom of the Project Navigator are the Console, Errors, and Warnings panels, which display status messages, errors, and warnings. To the right is a multi-document interface (MDI) window referred to as the Workspace. The Workspace enables you to view design reports, text files, schematics, and simulation waveforms. Each window can be resized, undocked from Project Navigator, moved to a new location within the main Project Navigator window, tiled, layered, or closed. You can use the **View > Panels** menu commands to open or close panels. You can use the **Layout > Load Default Layout** to restore the default window layout. These windows are discussed in more detail in the following sections.

191	IPP Deviced Manipulation Collection Autoric Devices and all other 1	n	Commence (Incodescente d)]										
240	File Edit View Drotect Source Drocect Tools Window Lavout Heir	Desig	n Summary (implemented)]										
1		2	A 58 5 5 P 8 P 8 P	1									
Des	ign ↔□중>	< 0.	Design Overview		sto	pwatch Project Stat	us (01/27/2	011 - 13:	46:16)				1^
1	View: 💿 🏟 Implementation 🔿 🔜 Simulation	-	IOB Properties	Project File:	wtut vhd.xise	Pars	er Errors:			No Errors			
. E	Hierarchy	G	Module Level Utilization	Module Name:	stopwatch	Imp	ementation	State:		Placed and	Routed		1
8	wtut_vhd	0	Timing Constraints	Target Device:	xc3s700a-4fg484		•Errors:			No Errors			1
	KC3S/00a-4rg484 KC3S/00a-4rg484 KC3S/00a-4rg484 KC3S/00a-4rg484	\$5	Clock Report	Product Version:	ISE 13.1		•Warnings			5 Warning	s (5 new)		
00	t_preset - timer_preset (timer_preset.xco)	1116	C Static Timing	Design Goal:	Balanced		•Routing R	Results:		All Signals	Completely Rout	ced	
•	Inst_dcm1 - dcm1 (dcm1.xaw)	38	Errors and Warnings Parser Messages	Design Strategy:	Xiinx Default (unloc	ked)	•Timina Co	onstraints		All Constra	aints Met		1
62	Icd_control_inst - Icd_control - Icd_control_arch (Icd_control.vhd)		- 📓 Synthesis Messages	Environment:	System Settings		•Final Timi	ina Score		0 (Timina	Report)		
	mode_debounce - debounce - Behavioral (debounce.vhd)	100	Translation Messages										-
-	strtstop_debounce - debounce - Behavioral (debounce.vhd)		Map messages Place and Route Messages										-
	timer_inst - time_cnt - time_cnt_arch (time_cnt.vhd)		- 🛐 Timing Messages			Device Utilization 9	Summary		100000000000000000000000000000000000000			•	4
	🔤 timer_state - statmach - behavior (statmach.vhd)		Bitgen Messages	Logic Utilization		Used	Available		Utilization		Note(s)		
			Detailed Reports	Number of Slice Flip Flops		22	9	11,776		1%			-
			- B Synthesis Report	Number of 4 input LUTs		37	1	11,776		3%			-
			Iranslation Report Map Report	Number of occupied Slices		28	5	5,888		4%			-
			- 📓 Place and Route Report	Number of Slices containing or	nly related logic	28	5	286		100%			-
			Post-PAR Static Timing Report	Number of Slices containing un	nrelated logic)	286		0%			-
			Bitgen Report	Total Number of 4 input LUTs		44	3	11,776		3%			-
1			Secondary Reports	Number used as logic		37	1			1			
	C2 No Processes Kunning			Number used as a route-thru	5	7:	2						
11	Processes: stopwatch - stopwatch_arch			Number of bonded IOBs		1	5	372		4%			
21	E Summary/Reports			Number of BUFGMUXs			3	24		12%			
90	🖶 😼 User Constraints			Number of DCMs			1	8		12%			
	Synthesize - XST			Average Fanout of Non-Clock Ne	ets	3.4	3						
	± € Ø Translate		Enable Message Filtering										
	🖶 👯 🖉 Map		Optional Design Summary Contents			Performance Su	mmary					E	0
	Generate Programming File		- Show Failing Constraints	Final Timing Score:	0 (Setup: 0,	Hold: 0)	P	inout Dat	ta:	Pino	ut Report		1
	🗉 🐞 Configure Target Device		Show Warnings	Routing Results:	All Signals C	ompletely Routed	C	lock Data	a:	Cloc	k Report		1
	- 🚰 Analyze Design Using ChipScope		Show errors	Timing Constraints:	All Constrain	its Met							1
													1
						Dotailed Ben	outo					1.1	a II.
				Report Name	Etabur	Concepted	ores E.		Warnings		Infor		4
				Suptherir Deport	Current	Thu lan 27 12:41:42	2011 0	iiois	E Warnings	(E paul)	A Tohor (A	Denni)	
				Translation Deport	Current	Thu Jan 27 13:44:21	2011 0	8	0	o nowy	10	IOWI	
				Man Report	Current	Thu Jan 27 13:45:40	2011 0	6	0		5 Infos (5	new)	-
250	Start 🗠 Design 🜓 Files 📭 Libraries	TE	dk_div_262k.vhd	stopwatch.vhd	×	Design Summ	ary (Implement	(ted)			12.0100.10	1201	
Con									_				
CUI	sue												~ ~
	Analysis completed Thu Jan 27 13:46:16 2011												-
	Generating Report												
	outstating report												
	Number of warnings: O												
ICTAL CIME: 2 SECS													
	Process "Generate Post-Place & Route Static Timing" completed successfully												
													v
<												1	>
=	📱 Console 🙋 Errors 🔝 Warnings 🙀 Find in Files Results												

The following figure shows the Project Navigator interface.

Figure 2-1: Project Navigator

Design Panel

The Design panel provides access to the View, Hierarchy, and Processes panes.

View Pane

The View pane radio buttons enable you to view the source modules associated with the Implementation or Simulation Design View in the Hierarchy pane. If you select Simulation, you must select a simulation phase from the drop-down list.

Hierarchy Pane

The Hierarchy pane displays the project name, the target device, user documents, and design source files associated with the selected Design View. The View pane at the top of the Design panel allows you to view only those source files associated with the selected Design View, such as Implementation or Simulation.

Each file in the Hierarchy pane has an associated icon. The icon indicates the file type (HDL file, schematic, core, or text file, for example). For a complete list of possible source

types and their associated icons, see the "Source File Types" topic in the ISE Help. From Project Navigator, select **Help > Help Topics** to view the ISE Help.

If a file contains lower levels of hierarchy, the icon has a plus symbol (+) to the left of the name. You can expand the hierarchy by clicking the plus symbol (+). You can open a file for editing by double-clicking on the filename.

Processes Pane

The Processes pane is context sensitive, and it changes based upon the source type selected in the Sources pane and the top-level source in your project. From the Processes pane, you can run the functions necessary to define, run, and analyze your design. The Processes pane provides access to the following functions:

• Design Summary/Reports

Provides access to design reports, messages, and summary of results data. Message filtering can also be performed.

• Design Utilities

Provides access to symbol generation, instantiation templates, viewing command line history, and simulation library compilation.

• User Constraints

Provides access to editing location and timing constraints.

• Synthesis

Provides access to Check Syntax, Synthesis, View RTL or Technology Schematic, and synthesis reports. Available processes vary depending on the synthesis tools you use.

• Implement Design

Provides access to implementation tools and post-implementation analysis tools.

• Generate Programming File

Provides access to bitstream generation.

• Configure Target Device

Provides access to configuration tools for creating programming files and programming the device.

The Processes pane incorporates dependency management technology. The tools keep track of which processes have been run and which processes need to be run. Graphical status indicators display the state of the flow at any given time. When you select a process in the flow, the software automatically runs the processes necessary to get to the desired step. For example, when you run the Implement Design process, Project Navigator also runs the Synthesis process because implementation is dependent on up-to-date synthesis results.

To view a running log of command line arguments used on the current project, expand Design Utilities and select **View Command Line Log File**. See Command Line Implementation in Chapter 6 for further details.

Files Panel

The Files panel provides a flat, sortable list of all the source files in the project. Files can be sorted by any of the columns in the view. Properties for each file can be viewed and modified by right-clicking on the file and selecting **Source Properties**.

Libraries Panel

The Libraries panel enables you to manage HDL libraries and their associated HDL source files. You can create, view, and edit libraries and their associated sources.

Console Panel

The Console provides all standard output from processes run from Project Navigator. It displays errors, warnings, and information messages. Errors are signified by a red X next to the message; while warnings have a yellow exclamation mark (!).

Errors Panel

The Errors panel displays only error messages. Other console messages are filtered out.

Warnings Panel

The Warnings panel displays only warning messages. Other console messages are filtered out.

Error Navigation to Source

You can navigate from a synthesis error or warning message in the Console, Errors, or Warnings panel to the location of the error in a source HDL file. To do so, select the error or warning message, right-click the mouse, and select **Go to Source** from the right-click menu.The HDL source file opens, and the cursor moves to the line with the error.

Error Navigation to Answer Record

You can navigate from an error or warning message in the Console, Errors, or Warnings panel to relevant Answer Records on the <u>Product Support and Documentation</u> page of the Xilinx® website. To navigate to the Answer Record, select the error or warning message, right-click the mouse, and select **Search for Answer Record** from the right-click menu. The default Web browser opens and displays all Answer Records applicable to this message.

Workspace

The Workspace is where design editors, viewers, and analysis tools open. These include ISE Text Editor, Schematic Editor, Constraint Editor, Design Summary/Report Viewer, RTL and Technology Viewers, and Timing Analyzer.

Other tools such as the PlanAheadTM tool for I/O planning and floorplanning, ISim, third-party text editors, XPower Analyzer, and iMPACT open in separate windows outside the main Project Navigator environment when invoked.

Design Summary/Report Viewer

The Design Summary provides a summary of key design data as well as access to all of the messages and detailed reports from the synthesis and implementation tools. The summary lists high-level information about your project, including overview information, a device utilization summary, performance data gathered from the Place and Route (PAR) report, constraints information, and summary information from all reports with links to the individual reports. A link to the System Settings report provides information on

environment variables and tool settings used during the design implementation. Messaging features such as message filtering, tagging, and incremental messaging are also available from this view.

Using Project Revision Management Features

Project Navigator enables you to manage your project as follows.

Understanding the ISE Project File

The ISE project file (.xise extension) is an XML file that contains all source-relevant data for the project as follows:

- ISE Design Suite version information
- List of source files contained in the project
- Source settings, including design and process properties

The ISE project file does not contain the following:

- Process status information
- Command history
- Constraints data

Note: A .gise file also exists, which contains generated data, such as process status. You should not need to directly interact with this file.

The ISE project file includes the following characteristics, which are compatible with source control environments:

- Contains all of the necessary source settings and input data for the project.
- Can be opened in Project Navigator in a read-only state.
- Only updated or modified if a source-level change is made to the project.
- Can be kept in a directory separate from the generated output directory (working directory).

Note: A source-level change is a change to a property or the addition or removal of a source file. Changes to the contents of a source file or changes to the state of an implementation run are *not* considered source-level changes and do not result in an update to the project file.

Making a Copy of a Project

You can create a copy of a project using **File > Copy Project** to experiment with different source options and implementations. Depending on your needs, the design source files for the copied project and their location can vary as follows:

- Design source files can be left in their existing location, and the copied project points to these files.
- Design source files, including generated files, can be copied and placed in a specified directory.
- Design source files, excluding generated files, can be copied and placed in a specified directory.

Using the Project Browser

The Project Browser, accessible by selecting **File > Project Browser**, provides a convenient way to compare, view, and open projects as follows:

- Compare key characteristics between multiple projects.
- View Design Summary and Reports for a selected project before opening the full project.
- Compare detailed information for two selected projects.
- Open a selected project in the current Project Navigator session.
- Open a selected project in a new Project Navigator session.

Using Project Archives

You can also archive the entire project into a single compressed file. This allows for easier transfer over email and storage of numerous projects in a limited space.

Creating an Archive

To create an archive, do the following:

- 1. Select **Project > Archive**.
- 2. In the Project Archive dialog box, enter the archive name and location.

3. Click Save.

Note: The archive contains all of the files in the project directory along with project settings. Remote sources are included in the archive under a folder named remote_sources. For more information, see the ISE Help.

Restoring an Archive

You cannot restore an archived file directly into Project Navigator. The compressed file can be extracted with any ZIP utility, and you can then open the extracted file in Project Navigator.



Chapter 3

HDL-Based Design

Overview of HDL-Based Design

This chapter guides you through a typical HDL-based design procedure using a design of a runner's stopwatch. The design example used in this tutorial demonstrates many device features, software features, and design flow practices you can apply to your own design. This design targets a Spartan[™]-3A device; however, all of the principles and flows taught are applicable to any Xilinx[®] device family, unless otherwise noted.

The design is composed of HDL elements and two cores. You can synthesize the design using Xilinx Synthesis Technology (XST), Synplify/Synplify Pro, or Precision software.

This chapter is the first chapter in the HDL Design Flow. After the design is successfully defined, you will perform behavioral simulation (Chapter 5, Behavioral Simulation), run implementation with the Xilinx implementation tools (Chapter 6, Design Implementation), perform timing simulation (Chapter 7, Timing Simulation), and configure and download to the Spartan-3A device (XC3S700A) demo board (Chapter 8, Configuration Using iMPACT).

Getting Started

The following sections describe the basic requirements for running the tutorial.

Required Software

To perform this tutorial, you must have Xilinx ISE® Design Suite installed.

This tutorial assumes that the software is installed in the default location c:\xilinx\release_number\ISE_DS\ISE. If you installed the software in a different location, substitute your installation path in the procedures that follow.

Note: For detailed software installation instructions, refer to the *ISE Design Suite: Installation and Licensing Guide (UG798)* available from the Xilinx website.

Optional Software Requirements

The following third-party synthesis tools are incorporated into this tutorial and may be used in place of Xilinx Synthesis Technology (XST):

- Synopsys Synplify/Synplify Pro D-2010.06 (or above)
- Mentor Precision Synthesis 2010a (or above)

The following third-party simulation tool is optional for this tutorial and may be used in place of ISim:

• ModelSim SE/PE/DE 6.6d (or above)

VHDL or Verilog

This tutorial supports both VHDL and Verilog designs and applies to both designs simultaneously, noting differences where applicable. You will need to decide which HDL language you would like to work through for the tutorial and download the appropriate files for that language. XST can synthesize a mixed-language design. However, this tutorial does not cover the mixed language feature.

Installing the Tutorial Project Files

The tutorial project files are provided with the ISE Design Suite <u>Tutorials</u> available from the Xilinx website. Download either the VHDL or the Verilog design flow project files.

After you have downloaded the tutorial project files from the web, unzip the tutorial projects into the c:\xilinx_tutorial directory, replacing any existing files in that directory.

When you unzip the tutorial project files into c:\xilinx_tutorial, the directory wtut_vhd (for a VHDL design flow) or wtut_ver (for a Verilog design flow) is created within c:\xilinx_tutorial, and the tutorial files are copied into the newly-created directory.

The following table lists the locations of tutorial source files.

Table 3-1:	Tutorial	Directories

Directory	Description
wtut_vhd	Incomplete VHDL Source Files
wtut_ver	Incomplete Verilog Source Files
wtut_vhd\wtut_vhd_completed	Completed VHDL Source Files
wtut_ver\wtut_ver_completed	Completed Verilog Source Files

Note: The completed directories contain the finished HDL source files. Do not overwrite any files in the completed directories.

This tutorial assumes that the files are unzipped under c:\xilinx_tutorial, but you can unzip the source files into any directory with read/write permissions. If you unzip the files into a different location, substitute your project path in the procedures that follow.

Starting the ISE Design Suite

To start the ISE Design Suite, double-click the Project Navigator icon on your desktop, or select Start > All Programs > Xilinx ISE Design Suite > ISE Design Tools > Project Navigator.



Figure 3-1: Project Navigator Desktop Icon

Creating a New Project

To create a new project using the New Project Wizard, do the following:

- 1. From Project Navigator, select **File > New Project**.
 - The New Project Wizard appears.

🔤 New Project Wiza	rd E	×				
Create New Project Specify project loc	cation and type.					
Enter a name, locatio	ons, and comment for the project					
Name:	wtut_vhd					
Location:	C:\xilinx_tutorial\wtut_vhd					
Working Directory:	C:\xilinx_tutorial\wtut_vhd					
Description:						
Select the type of top-level source for the project						
HDL						
More Info	Next > Cancel)				

Figure 3-2: New Project Wizard—Create New Project Page

- 2. In the Location field, browse to c:\xilinx_tutorial or to the directory in which you installed the project.
- 3. In the Name field, enter **wtut_vhd** or **wtut_ver**.
- 4. Verify that HDL is selected as the Top-Level Source Type, and click Next.

elect the device and design flow for the	project		
Property Name	Value		
Evaluation Development Board	None Specified	1	
Product Category	All	1	
Family	Spartan3A and Spartan3AN	1	
Device	XC35700A	1	
Package	FG484	1	
Speed	-4		
Top-Level Source Type	HDL	1	
Synthesis Tool	XST (VHDL/Verilog)	•	
Simulator	ISim (VHDL/Verilog)	1	
Preferred Language	VHDL	-	
Property Specification in Project File	Store all values	1	
Manual Compile Order			
VHDL Source Analysis Standard	VHDL-93	1	
Enable Message Filtering			

The New Project Wizard—Device Properties page appears.

Figure 3-3: New Project Wizard—Device Properties Page

- 5. Select the following values in the New Project Wizard—Device Properties page:
 - Product Category: All
 - Family: Spartan3A and Spartan3AN
 - Device: XC3S700A
 - Package: **FG484**
 - Speed: **-4**
 - Synthesis Tool: XST (VHDL/Verilog)
 - Simulator: ISim (VHDL/Verilog)
 - Preferred Language: **VHDL** or **Verilog** depending on preference. This will determine the default language for all processes that generate HDL files.

Other properties can be left at their default values.

6. Click **Next**, then **Finish** to complete the project creation.

Stopping the Tutorial

You may stop the tutorial at any time and save your work by selecting **File > Save All**.

Design Description

The design used in this tutorial is a hierarchical, HDL-based design, which means that the top-level design file is an HDL file that references several other lower-level macros. The lower-level macros are either HDL modules or IP modules.

The design begins as an unfinished design. Throughout the tutorial, you will complete the design by generating some of the modules from scratch and by completing others from existing files. When the design is complete, you will simulate it to verify the design functionality.

In the runner's stopwatch design, there are five external inputs and four external output buses. The system clock is an externally generated signal. The following list summarizes the input and output signals of the design.

Inputs

The following are input signals for the tutorial stopwatch design:

strtstop

Starts and stops the stopwatch. This is an active low signal which acts like the start/ stop button on a runner's stopwatch.

reset

Puts the stopwatch in clocking mode and resets the time to 0:00:00.

• clk

Externally generated system clock.

• mode

Toggles between clocking and timer modes. This input is only functional while the clock or timer is not counting.

lap_load

This is a dual function signal. In clocking mode, it displays the current clock value in the 'Lap' display area. In timer mode, it loads the pre-assigned values from the ROM to the timer display when the timer is not counting.

Outputs

The following are outputs signals for the design:

lcd_e, lcd_rs, lcd_rw

These outputs are the control signals for the LCD display of the Spartan-3A demo board used to display the stopwatch times.

• sf_d[7:0]

Provides the data values for the LCD display.

Functional Blocks

The completed design consists of the following functional blocks:

• clk_div_262k

Macro that divides a clock frequency by 262,144. Converts 26.2144 MHz clock into 100 Hz 50% duty cycle clock.

dcm1

Clocking Wizard macro with internal feedback, frequency controlled output, and duty-cycle correction. The CLKFX_OUT output converts the 50 MHz clock of the Spartan-3A demo board to 26.2144 MHz.

• debounce

Schematic module implementing a simplistic debounce circuit for the strtstop, mode, and lap_load input signals.

• lcd_control

Module controlling the initialization of and output to the LCD display.

• statmach

State machine HDL module that controls the state of the stopwatch.

timer_preset

CORE GeneratorTM tool 64x20 ROM. This macro contains 64 preset times from 0:00:00 to 9:59:99 that can be loaded into the timer.

• time_cnt

Up/down counter module that counts between 0:00:00 to 9:59:99 decimal. This macro has five 4-bit outputs, which represent the digits of the stopwatch time.

Design Entry

For this hierarchical design, you will examine HDL files, correct syntax errors, create an HDL macro, and add a CORE Generator tool core and a clocking module. You will create and use each type of design macro. All procedures used in the tutorial can be used later for your own designs.

Adding Source Files

HDL files must be added to the project before they can be synthesized. You will add five source files to the project as follows:

- 1. Select **Project > Add Source**.
- 2. Select the following files (.vhd files for VHDL design entry or .v files for Verilog design entry) from the project directory, and click **Open**.
 - clk_div_262k
 - lcd_control
 - statmach
 - stopwatch
 - time_cnt
- 3. In the Adding Source Files dialog box, verify that the files are associated with **All**, that the associated library is **work**, and click **OK**.

The Hierarchy pane in the Design panel displays all of the source files currently added to the project, with the associated entity or module names. Each source design unit is represented in the Hierarchy pane using the following syntax: *instance name - entity name - architecture name - (file name)*.

Instantiated components with no entity or module declaration are displayed with a question mark.



Figure 3-4: Hierarchy Panel Showing Completed Design

Correcting HDL Errors

The syntactical correctness of the files is checked as the files are added to the project, and also when they are saved. Messages are posted in the Console and in the Parser Messages section of the Design Summary and indicate the success or failure as each of the files is parsed.

The time_cnt module contains a syntax error that must be corrected. An "ERROR" message in the Console indicates the failure and provides a summary and the line number of the syntax problem.

To display the error in the source file, do the following:

1. In the Console or Errors panel, click the file name in the error message.

The source code appears in the Workspace with a yellow arrow icon next to the line with the error.

- 2. Correct any errors in the HDL source file. The comments above the error explain this simple fix.
- 3. Select **File > Save** to save the file.

The parsing message in the Console should now indicate that the file was checked successfully and is now free of errors.

Creating an HDL-Based Module

Next you will create a module from HDL code. With the ISE Design Suite, you can easily create modules from HDL code using the ISE Text Editor. The HDL code is then connected to your top-level HDL design through instantiation and is compiled with the rest of the design.

You will author a new HDL module. This macro will be used to debounce the strtstop, mode and lap_load inputs.

Using the New Source Wizard and ISE Text Editor

In this section, you create a file using the New Source wizard, specifying the name and ports of the component. The resulting HDL file is then modified in the ISE Text Editor.

To create the source file, do the following:

1. Select **Project > New Source**.

The New Source Wizard opens in which you specify the type of source you want to create.

- 2. In the Select Source Type page, select **VHDL Module** or **Verilog Module**.
- 3. In the File Name field, enter **debounce**.

🔤 New Source Wizard 🛛 🛛 🔀					
Select Source Type Select source type, file name and its location.					
 IP (CORE Generator & Architecture Wizard) Schematic System Generator Project User Document Verilog Module Verilog Test Fixture VHDL Module VHDL Library P VHDL Package WHDL Test Bench Embedded Processor 	File name: debounce Location: C:\cases\13\wtut_vhd 				
More Info	Next > Cancel				

Figure 3-5: New Source Wizard—Select Source Type Page

- 4. Click Next.
- 5. In the Define Module page, enter two input ports named sig_in and clk and an output port named sig_out for the debounce component as follows:
 - a. In the first three Port Name fields, enter **sig_in**, **clk** and **sig_out**.
 - b. Set the Direction field to input for sig_in and clk and to output for sig_out.

c. Leave the Bus designation boxes unchecked.

New Source V	/izard						×		
Define Module Specify ports	for module.								
Entity name	debounce Behavioral								
Architecture name									
	Port Name	Directio	n	Bus	MSB	LSB	^		
sig_in		in	~						
clk		in	*						
sig_out		out	*						
		in	*						
		in	*						
		in	*						
		in	*						
		in	*						
		in	*						
		in	*						
		in	*				~		
More Info		[< Ba	ack	Next >	Canc	el		

Figure 3-6: New Source Wizard—Define Module Page

- 6. Click **Next** to view a description of the module.
- Click **Finish** to open the empty HDL file in the ISE Text Editor. Following is an example VHDL file.

7	Module Name: debounce - Behavioral
8	Project Name:
9	Target Devices:
10	Tool versions:
11	Description:
12	
13	Dependencies:
14	
15	Revision:
16	Revision 0.01 - File Created
17	Additional Comments:
18	
19	
20	library IEEE;
21	use IEEE.STD_LOGIC_1164.ALL;
22	use IEEE.STD_LOGIC_ARITH.ALL;
23	use IEEE.STD_LOGIC_UNSIGNED.ALL;
24	
25	Uncomment the following library declaration if instantiating
26	any Xilinx primitives in this code.
27	library UNISIM;
28	use UNISIM.VComponents.all;
29	
30	entity debounce is
31	<pre>Port (sig_in : in STD_LOGIC;</pre>
32	clk : in STD_LOGIC;
33	<pre>sig_out : out STD_LOGIC);</pre>
34	end debounce;
35	
36	architecture Behavioral of debounce is
37	
38	begin
39	
40	
41	end Behavioral;
42	

Figure 3-7: VHDL File in ISE Text Editor

www.xilinx.com

Following is an example Verilog file.

```
timescale 1ns / 1ps
2
   3
   // Company:
   // Engineer:
4
5
  // Create Date:
                  14:12:53 03/15/2007
6
7
   // Design Name:
8
   // Module Name:
                  debounce
   // Project Name:
9
10
   // Target Devices:
  // Tool versions:
11
   // Description:
12
13
   17
   // Dependencies:
14
15
   // Revision:
16
   // Revision 0.01 - File Created
17
   // Additional Comments:
18
19
   20
   module debounce(sig_in, clk, sig_out);
21
22
     input sig in;
23
       input clk;
24
      output sig_out;
25
26
27
   endmodule
28
```

Figure 3-8: Verilog File in ISE Text Editor

In the ISE Text Editor, the ports are already declared in the HDL file, and some of the basic file structure is already in place. Keywords are displayed in blue, comments in green, and values are black. The file is color-coded to enhance readability and help you recognize typographical errors.

Using the Language Templates

The ISE Language Templates include HDL constructs and synthesis templates, which represent commonly used logic components, such as counters, D flip-flops, multiplexers, and primitives. You will use the Debounce Circuit template for this exercise.

Note: You can add your own templates to the Language Templates for components or constructs that you use often.

To invoke the Language Templates and select the template for this tutorial, do the following:

1. From Project Navigator, select Edit > Language Templates.

Each HDL language in the Language Templates is divided into five sections: Common Constructs, Device Macro Instantiation, Device Primitive Instantiation, Simulation Constructs, Synthesis Constructs and User Templates. To expand the view of any of these sections, click the plus symbol (+) next to the section. Click any of the listed templates to view the template contents in the right pane.

 Under either the VHDL or Verilog hierarchy, expand Synthesis Constructs, expand Coding Examples, expand Misc, and select the template called Debounce Circuit or One Shot, Debounce Circuit. Use the appropriate template for the language you are using.



Upon selection, the HDL code for a debounce circuit is displayed in the right pane.

Figure 3-9: Language Templates

Adding a Language Template to a File

You will now use the "Use in File" method for adding templates to your HDL file. Refer to "Working with Language Templates" in the ISE Help for additional options, including drag and drop options.

To add the template to your HDL file, do the following:

- 1. With the debounce.v or debounce.vhd source file active, position the cursor under the architecture begin statement in the VHDL file, or under the module and pin declarations in the Verilog file.
- 2. Return to the Language Templates window, right-click on the **Debounce Circuit** template in the template index, and select **Use In File**.



Figure 3-10: Selecting Language Template to Use in File

3. Close the Language Templates window.

- 4. Open the debounce.v or debounce.vhd source file to verify that the Language Template was properly inserted.
- 5. *Verilog only*: Complete the Verilog module by doing the following:
 - a. Remove the reset logic (not used in this design) by deleting the three lines beginning with if and ending with else.
 - b. Change <reg_name> to **q** in all six locations.
 - c. Change <clock> to **clk**; <input> to **sig_in**; and <output> to **sig_out**.

Note: You can select **Edit** > **Find & Replace** to facilitate this. The Find fields appear at the bottom of the Text Editor.

- 6. *VHDL only*: Complete the VHDL module by doing the following:
 - a. Move the line beginning with the word signal so that it is between the architecture and begin keywords.
 - b. Remove the reset logic (not used in this design) by deleting the five lines beginning with if (<reset>... and ending with else, and delete one of the end if; lines.
 - c. Change <clock> to clk; D_IN to sig_in; and Q_OUT to sig_out.

Note: You can select **Edit > Find & Replace** to facilitate this. The Find fields appear at the bottom of the Text Editor.

- 7. Save the file by selecting **File > Save**.
- 8. Select one of the debounce instances in the Hierarchy pane.
- 9. In the Processes pane, double-click **Check Syntax**. Verify that the syntax check passes successfully. Correct any errors as necessary.
- 10. Close the ISE Text Editor.

Creating a CORE Generator Tool Module

The CORE Generator tool is a graphical interactive design tool that enables you to create high-level modules such as memory elements, math functions and communications, and I/O interface cores. You can customize and pre-optimize the modules to take advantage of the inherent architectural features of the Xilinx FPGA architectures, such as Fast Carry Logic, SRL16s, and distributed and block RAM.

In this section, you will create a CORE Generator tool module called timer_preset. The module will be used to store a set of 64 values to load into the timer.

Creating the timer_preset CORE Generator Tool Module

To create a CORE Generator tool module, do the following:

- 1. In Project Navigator, select **Project > New Source**.
- 2. Select IP (CORE Generator & Architecture Wizard).
- 3. In the File Name field, enter timer_preset.
- 4. Click Next.
- 5. Expand the IP tree selector to locate **Memories & Storage Elements > RAMs & ROMs**.

6. Select **Distributed Memory Generator**, click **Next**, and click **Finish** to open the Distributed Memory Generator customization GUI. This customization GUI enables you to customize the memory to the design specifications.

View by Funct	ion View by Name	A Hensier	Outra		المتعادية			
Name		Version	Status	License \	vendor Li	ibrary		
🗄 💋 Autom	otive & Industrial							
🗈 💋 BaseIP								
🔹 💋 Basic E	lements							
E 💋 Commu	unication & Networking							
E 💋 Debug	& Verification							
🕒 💋 Digital	Signal Processing							
🗄 💋 FPGA F	eatures and Design							
H / Math F	unctions							
🖃 💋 Memori	ies & Storage Elements							
🕀 💋 FIF	[†] Os							
🗄 💋 Me	mory Interface Generators							
🖃 💋 RA	Ms & ROMs							
- 3	Block Memory Generator	4.2	Production	>	ülinx ip			
- 3	Block Memory Generator	4.3	Production	>	álinx ip			
	Block Memory Generator	5.1	Production	>	álinx ip			
100 C	Block Memory Generator	6.1	Production	>	álinx ip	1		
- 4		tor 61	Production	>	silinx ip	l.		
	Distributed Memory Genera							
🕀 📂 Standa	Distributed Memory Genera rd Bus Interfaces							
E 💋 Standa	Distributed Memory Genera rd Bus Interfaces k Image Processing							
E D Standa	Distributed Memory Genera ard Bus Interfaces & Image Processing							
E D Standa	Distributed Memory Genery and Bus Interfaces & Image Processing						Char	

Figure 3-11: New Source Wizard—Select IP Page

- 7. Fill in the Distributed Memory Generator customization GUI with the following settings:
 - Component Name: timer_preset (defines the name of the module)
 - Depth: **64** (defines the number of values to be stored)
 - Data Width: **20** (defines the width of the output bus)
 - Memory Type: **ROM**

8. Click **Next**.

ymbol 5 ×	logi C^oRE	istributed Memory Generator	I
[0.0]]oqt ↔ (0.0] (0.0]]oqt p ↔ (0.0] (0.0]]oqt p ↔ (0.0] (0.0]]oqt p ↔ (0.0] (0.0]]oqt p ↔ (0.0]	Component Name timer_p Options Depth 64 R Data Width 20 R Memory Type	reset ange: 1665536 ange: 11024	
$(ce \rightarrow)$ $(ce \rightarrow)$ (ce	ORM Dual Port RAM Simple Dual Port RAM	 Single Port RAM SRL16-based Memory 	

Figure 3-12: CORE Generator Tool—Distributed Memory Generator Customization GUI Page 1

9. Leave Input and Output options as **Non Registered**, and click **Next**.

P Symbol 6	× LogiCXRF Distri	outed Memory Generator	6.
[6:0]]qqz ← [6:6]6 [8:0]]qqz ← [6:0]qqb [0:0]]qqb ← [6:0]qqb [0:0]][0:0][0:0][0:0][0:0][0:0][0:0][0:	Input Options Non Registered Input Clock Enable Dual Port Address Non Registered Output Options Non Registered Common Output CLK Common Output CE Pipelining Options Pipeline Stages:	Registered Qualify WE with I_CE Registered Registered Registered Isingle Port Output CE Dual Port Output CE	
	Datasheet <	ack Page 2 of 3 Next > Generate Cancel	Help

Figure 3-13: CORE Generator Tool—Distributed Memory Generator Customization GUI Page 2

- 10. To specify the Coefficients File, click the **Browse** button, and select definition1_times.coe located in the project directory.
- 11. Check that *only* the following pins are used (used pins are highlighted on the symbol on the left side of the customization GUI):
 - a[5:0]
 - spo[19:0]
- 12. Click Generate.

/iew Documents		
Symbol 8 ×	Logic RE Distribu	uted Memory
[0.0]) ↔ ↔ ↔ (0.3] (0.0]) ↔ ↔ ↔ ↔ (0.0]) (0.0]) ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔ ↔	Load COE File If desired the initial memory content ca Memory Initialisation File (MIF). Coefficients File : [vdefinition1_times.cc COE Options Default Data : 0 Reset Options Reset Options Reset OSPO	n be set by using a COE file. This will be passed to the core a be Browse Show Radix : 16 Reset QDPO
φ m. m. <tdm.< td=""> m. m. m.<!--</td--><td>Synchronous Reset QSPO CE Overrides Sync Controls</td><td>Sync Controls Overrides CE</td></tdm.<>	Synchronous Reset QSPO CE Overrides Sync Controls	Sync Controls Overrides CE

Figure 3-14: CORE Generator Tool—Distributed Memory Generator Customization GUI Page 3

The module is created and automatically added to the project library.

A number of files are added to the ipcore_dir sub-directory of the project directory. Following is a list of some of these files:

timer_preset.vho or timer_preset.veo

These are the instantiation templates used to incorporate the CORE Generator tool module into your source HDL.

timer_preset.vhd or timer_preset.v

These are HDL wrapper files for the core and are used only for simulation.

• timer_preset.ngc

This file is the netlist that is used during the Translate phase of implementation.

• timer_preset.xco

This file stores the configuration information for the timer_preset module and is used as the project source in the ISE project.

• timer_preset.mif

This file provides the initialization values of the ROM for simulation.

Instantiating the CORE Generator Tool Module in the HDL Code

Next, instantiate the CORE Generator tool module in the HDL code using either a VHDL flow or a Verilog flow. After instantiation, the core module appears beneath the stopwatch module in the hierarchy.

VHDL Flow

To instantiate the CORE Generator tool module using a VHDL flow, do the following:

- 1. In Project Navigator, double-click stopwatch.vhd to open the file in ISE Text Editor.
- 2. Place the cursor after the following line:
 - -- Insert CORE Generator ROM component declaration here
- Select Edit > Insert File, then select ipcore_dir/timer_preset.vho, and click Open.

The VHDL template file for the CORE Generator tool instantiation is inserted.

```
----- Begin Cut here for COMPONENT Declaration ----- COMP_TAG
121
122
    component timer_preset
123
       port (
        a: IN std logic_VECTOR(5 downto 0);
124
       spo: OUT std_logic_VECTOR(19 downto 0));
125
126
    end component;
127
128
     -- Synplicity black box declaration
129
    attribute syn_black_box : boolean;
130
    attribute syn_black_box of timer_preset: component is true;
131
    -- COMP_TAG_END ----- End COMPONENT Declaration -----
132
```

Figure 3-15: VHDL Component Declaration for CORE Generator Tool Module

4. Highlight the inserted code from:

```
-- Begin Cut here for INSTANTIATION Template ----
```

to

```
--INST_TAG_END ----- END INSTANTIATION Template -----
```

- 5. Select Edit > Cut.
- 6. Place the cursor after the following line:

--Insert CORE Generator ROM Instantiation here

- 7. Select **Edit > Paste** to place the core instantiation.
- 8. Change the instance name from your_instance_name to t_preset.
- 9. Edit this instantiated code to connect the signals in the stopwatch design to the ports of the CORE Generator tool module as shown below.

```
169 ----- Insert CORE Generator ROM instantiation here
170 ----- Begin Cut here for INSTANTIATION Template ----- INST_TAG
171 t_preset : timer_preset
172 port map (
173 a => address,
174 spo => preset_time);
175 -- INST_TAG_END ------ End INSTANTIATION Template ------
```

Figure 3-16: VHDL Component Instantiation of CORE Generator Tool Module

- 10. The inserted code of timer_preset.vho contains several lines of commented text for instruction and legal documentation. Delete these commented lines if desired.
- 11. Save the design using **File > Save**, and close the ISE Text Editor.

Verilog Flow

To instantiate the CORE Generator tool module using a Verilog flow, do the following:

- 1. In Project Navigator, double-click stopwatch.v to open the file in the ISE Text Editor.
- 2. Place the cursor after the following line:

//Place the Coregen module instantiation for timer_preset here

- 3. Select Edit > Insert File, and select ipcore_dir/timer_preset.veo.
- 4. The inserted code of timer_preset.veo contains several lines of commented text for instruction and legal documentation. Delete these commented lines if desired.
- 5. Change the instance name from your_instance_name to t_preset.
- 6. Edit this code to connect the signals in the stopwatch design to the ports of the CORE Generator tool module as shown below.

```
36 // Place the Coregen module instantiation for timer_preset here
37 //------ Begin Cut here for INSTANTIATION Template ---// INST_TAG
38 timer_preset t_preset (
39 .a(address), // Bus [5 : 0]
40 .spo(preset_time)); // Bus [19 : 0]
41
42 // INST TAG END ----- End INSTANTIATION Template ------
```

Figure 3-17: Verilog Component Instantiation of the CORE Generator Tool Module

7. Save the design using **File > Save** and close the ISE Text Editor.

Creating a DCM Module

The Clocking Wizard, a part of the Xilinx Architecture Wizard, enables you to graphically select Digital Clock Manager (DCM) features that you want to use. In this section you will create a basic DCM module with CLK0 feedback and duty-cycle correction.

Using the Clocking Wizard

To create the dcm1 module, do the following:

- 1. In Project Navigator, select **Project > New Source**.
- In the New Source Wizard, select IP (CoreGen & Architecture Wizard) source and enter dcm1 for the file name.
- 3. Click Next.

4. In the Select IP dialog box, select **FPGA Features and Design > Clocking > Spartan-3E, Spartan-3A > Single DCM_SP**.

View by Function View by Name					
Name	Version	Status	License	Vendor	^
Digital Signal Processing PF0A Features and Design Occking Clocking Clockin	3.1	N/A		Xilinx	
Clock Switching A Source - SA Constant	13.1 13.1 13.1 13.1 13.1	Production Production Production Production Production		Xilinx Xilinx Xilinx Xilinx Xilinx	
				3	~
Search IP Catalog:				Clear	
All IP versions		Only IP compa	tible with c	hosen p	art

Figure 3-18: Selecting Single DCM_SP IP Type

- 5. Click **Next**, and click **Finish.** The Clocking Wizard is launched.
- 6. In the Architecture Wizard Setup page, select **OK**.
- 7. In the General Setup page, verify that **RST**, **CLK0** and **LOCKED** ports are selected.
- 8. Select CLKFX port.
- 9. Enter **50** and select **MHz** for the Input Clock Frequency.
- 10. Verify the following settings:
 - Phase Shift: NONE
 - CLKIN Source: External, Single
 - Feedback Source: Internal
 - Feedback Value: **1X**
 - Use Duty Cycle Correction: Selected
- 11. Click the **Advanced** button.
- 12. Select Wait for DCM lock before DONE Signal goes high.
- 13. Click **OK**.
- 14. Click **Next**, and then click **Next** again.
- 15. Select **Use output frequency** and enter **26.2144** in the box and select **MHz**.

$$(26.2144Mhz)/2^{18} = 100Hz$$

16. Click **Next**, and then click **Finish**.

The dcml.xaw file is added to the list of project source files in the Hierarchy pane of the Design panel.

Instantiating the dcm1 Macro—VHDL Design

Next, you will instantiate the dcm1 macro for your VHDL or Verilog design. To instantiate the dcm1 macro for the VHDL design, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select dcm1.xaw.
- 2. In the Processes pane, right-click **View HDL Instantiation Template**, and select **Process Properties**.
- 3. Choose **VHDL** for the HDL Instantiation Template Target Language value, and click **OK**.
- 4. In the Processes pane, double-click View HDL Instantiation Template.
- 5. Highlight the component declaration template in the newly opened HDL Instantiation Template (dcm1.vhi) shown below.

4	Notes:
5	1) This instantiation template has been auto
6	std logic and std logic vector for the ports
7	2) To use this template to instantiate this
8	
9	COMPONENT dcm1
10	PORT (
11	CLKIN_IN : IN std_logic;
12	RST_IN : IN std_logic;
13	CLKFX OUT : OUT std logic;
14	CLKIN_IBUFG_OUT : OUT std_logic;
15	CLKO_OUT : OUT std_logic;
16	LOCKED_OUT : OUT std_logic
17);
18	END COMPONENT;

Figure 3-19: VHDL DCM Component Declaration

- 6. Select **Edit > Copy**.
- 7. Place the cursor in the following section of the stopwatch.vhd file:

-- Insert dcm1 component declaration here.

- 8. Select **Edit > Paste** to paste the component declaration.
- 9. Highlight the instantiation template in the newly opened HDL Instantiation Template shown below.

19	
20	Inst dcm1: dcm1 PORT MAP(
21	CLKIN IN => ,
22	RST IN => ,
23	CLKFX_OUT => ,
24	CLKIN IBUFG OUT => ,
25	CLKO_OUT => ,
26	LOCKED_OUT =>
27);
28	

Figure 3-20: VHDL DCM Component Instantiation

- 10. Select **Edit > Copy**.
- 11. Place the cursor below the following line in the stopwatch.vhd file:

-- Insert dcm1 instantiation here.

12. Select **Edit > Paste** to paste the instantiation template.

13. Make the necessary changes as shown in the following figure.

141	Insert dcm1 instantiation here
142	Inst_dcm1: dcm1 PORT MAP(
143	CLKIN_IN => clk,
144	RST_IN => reset,
145	CLKFX_OUT => clk_26214k,
146	CLKIN_IBUFG_OUT => open,
147	CLKO_OUT => open,
148	LOCKED_OUT => locked
149);

Figure 3-21: VHDL Instantiation for dcm1

14. Select **File > Save** to save the stopwatch.vhd file.

The dcm1 module should now appear beneath the stopwatch module in the design hierarchy.

Instantiating the dcm1 Macro—Verilog

To instantiate the dcm1 macro for your Verilog design, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select dcm1.xaw.
- 2. In the Processes pane, double-click View HDL Instantiation Template.
- 3. From the newly opened HDL Instantiation Template (dcm1.tfi), copy the instantiation template shown below.



Figure 3-22: dcm1 Macro and Instantiation Templates

4. Paste the instantiation template into the following section in the stopwatch.v file:

//Insert dcm1 instantiation here.

5. Make the necessary changes as shown in the following figure.



Figure 3-23: Verilog Instantiation for dcm1

6. Select **File > Save** to save the stopwatch.v file.

The dcm1 module should now appear beneath the stopwatch module in the design hierarchy.

Synthesizing the Design

So far you have been using Xilinx Synthesis Technology (XST) for syntax checking. Next, you will synthesize the design using either XST, Synplify/Synplify Pro, or Precision software. The synthesis tool uses the design's HDL code and generates a supported netlist type (EDIF or NGC) for the Xilinx implementation tools. The synthesis tool performs the following general steps (although all synthesis tools further break down these general steps) to create the netlist:

• Analyze/Check Syntax

Checks the syntax of the source code.

• Compile

Translates and optimizes the HDL code into a set of components that the synthesis tool can recognize.

• Map

Translates the components from the compile stage into the target technology's primitive components.

The synthesis tool can be changed at any time during the design flow. To change the synthesis tool, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select the targeted part.
- 2. Right-click and select **Design Properties**.
- 3. In the Design Properties dialog box, click the Synthesis Tool value and use the pull-down arrow to select the desired synthesis tool from the list.

Property Name	Value	
Top-Level Source Type	HDL	~
Evaluation Development Board	None Specified	~
Product Category	All	~
Family	Spartan3A and Spartan3AN	~
Device	XC35700A	~
Package	FG484	~
Speed	-4	~
Synthesis Tool	XST (VHDL/Verilog)	~
Simulator	ISim (VHDL/Verilog)	~
Preferred Language	VHDL	~
Property Specification in Project File	Store all values	~
Manual Compile Order		
VHDL Source Analysis Standard	VHDL-93	~
Enable Message Filtering		
	OK Cancel Help	-

Figure 3-24: Specifying Synthesis Tool

Note: If you do not see your synthesis tool among the options in the list, you may not have the software installed or may not have it configured in the ISE Design Suite. The synthesis tools are configured in the Preferences dialog box. Select **Edit > Preferences**, expand **ISE General**, and click **Integrated Tools**.

Changing the design flow results in the deletion of implementation data. You have not yet created any implementation data in this tutorial. For projects that contain implementation

data, Xilinx recommends that you make a copy of the project using **File > Copy Project** if you would like to make a backup of the project before continuing.

Synthesizing the Design Using XST

Now that you have created and analyzed the design, the next step is to synthesize the design. During synthesis, the HDL files are translated into gates and optimized for the target architecture.

Processes available for synthesis using XST are as follows:

• View RTL Schematic

Generates a schematic view of your RTL netlist.

• View Technology Schematic

Generates a schematic view of your technology netlist.

• Check Syntax

Verifies that the HDL code is entered properly.

• Generate Post-Synthesis Simulation Model

Creates HDL simulation models based on the synthesis netlist.

Entering Synthesis Options

Synthesis options enable you to modify the behavior of the synthesis tool to make optimizations according to the needs of the design. One commonly used option is to control synthesis to make optimizations based on area or speed. Other options include controlling the maximum fanout of a flip-flop output or setting the desired frequency of the design.

To enter synthesis options, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select stopwatch.vhd (or stopwatch.v).
- 2. In the Processes pane, right-click the **Synthesize** process, and select **Process Properties**.
- 3. Under the Synthesis Options tab, set the Netlist Hierarchy property to a value of **Rebuilt**.

Note: To use this property, you must set the Property display level to Advanced.

4. Click **OK**.

Synthesizing the Design

Now you are ready to synthesize your design. To take the HDL code and generate a compatible netlist, do the following:

- 1. In the Hierarchy pane, select stopwatch.vhd (or stopwatch.v).
- 2. In the Processes pane, double-click the **Synthesize** process.

Using the RTL/Technology Viewer

XST can generate a schematic representation of the HDL code that you have entered. A schematic view of the code helps you analyze your design by displaying a graphical connection between the various components that XST has inferred. Following are the two forms of schematic representation:

• RTL View

Pre-optimization of the HDL code.

• Technology View

Post-synthesis view of the HDL design mapped to the target technology.

To view a schematic representation of your HDL code, do the following:

- 1. In the Processes pane, expand **Synthesize**, and double-click **View RTL Schematic** or **View Technology Schematic**.
- 2. If the Set RTL/Tech Viewer Startup Mode dialog appears, select **Start with the Explorer Wizard**.
- 3. In the Create Schematic start page, select the **clk_divider** and **lap_load_debounce** components from the Available Elements list, and then click the **Add** button to move the selected items to the Selected Elements list.
- 4. Click Create Schematic.

reate RTL Schematic	natic from the "Avail	able Elements" list and move them to the "Si	elected Elements"
) Press the "Create Schematic" butto	n to generate a sche	amatic view using the items in the "Selected	Elements" list
Available Elements	A	Selected Elements	4
😑 🚣 stopwatch		Add -> 🔒 👗 clk_divider	
🗉 📁 Primitives		🛃 lap_load_debounce	
🕀 📁 Signals	<-	Remove	
🗉 📁 📁 Top Level Ports			
💼 🚣 clk_divider	<<-	Remove All	
🗈 💑 Inst_dcm1			
🗈 📥 lap_load_debounce			
🗈 📥 lcd_cntrl_inst			
🗈 🚣 mode_debounce			
🗈 🚣 strtstop_debounce			
🗈 🚣 timer_inst	-		
🗈 📥 timer_state	1		
	2		
	-		
	-		
	1		
	*		
*	Filter		Create Schoma
	Filter		Create Scheina

Figure 3-25: Create RTL Schematic Start Page

www.xilinx.com

The schematic viewer allows you to select the portions of the design to display as schematics. When the schematic is displayed, double-click on the symbol to push into the schematic and view the various design elements and connectivity. Right-click the schematic to view the various operations that can be performed in the schematic viewer.



Figure 3-26: RTL Schematic

You have completed XST synthesis. An NGC file now exists for the stopwatch design.

To continue with the HDL flow, do either of the following:

- Go to Chapter 5, Behavioral Simulation, to perform a pre-synthesis simulation of this design.
- Proceed to Chapter 6, Design Implementation, to place and route the design.

Note: For more information about XST constraints, options, reports, or running XST from the command line, see the *XST User Guides*.

Synthesizing the Design Using Synplify/Synplify Pro Software

Now that you have entered and analyzed the design, the next step is to synthesize the design. In this step, the HDL files are translated into gates and optimized to the target architecture. To access the Synplify software RTL viewer and constraints editor you must run the Synplify software outside of the ISE Design Suite.

Processes available for synthesis using the Synplify and Synplify Pro software are as follows:

• View Synthesis Report

Lists the synthesis optimizations that were performed on the design and gives a brief timing and mapping report.

• View RTL Schematic

Accessible from the Launch Tools hierarchy, this process displays the Synplify or Synplify Pro software with a schematic view of your HDL code.

• View Technology Schematic

Accessible from the Launch Tools hierarchy, this process displays the Synplify or Synplify Pro software with a schematic view of your HDL code mapped to the primitives associated with the target technology.
Entering Synthesis Options and Synthesizing the Design

To synthesize the design, set the global synthesis options as follows:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select stopwatch.vhd (or stopwatch.v).
- 2. In the Processes pane, right-click **Synthesize**, and select **Process Properties**.
- 3. In the Synthesis Options dialog box, select the **Write Vendor Constraint File** box.
- 4. Click **OK** to accept these values.
- 5. Double-click the **Synthesize** process to run synthesis.

Note: This step can also be done by selecting topwatch.vhd (or topwatch.v), clicking Synthesize in the Processes pane, and selecting Process > Run.

Examining Synthesis Results

To view overall synthesis results, double-click **View Synthesis Report** under the **Synthesize** process. The report consists of the following sections:

- Compiler Report
- Mapper Report
- Timing Report
- Resource Utilization

Compiler Report

The compiler report lists each HDL file that was compiled, names which file is the top level, and displays the syntax checking result for each file that was compiled. The report also lists FSM extractions, inferred memory, warnings on latches, unused ports, and removal of redundant logic.

Note: Black boxes (modules not read into a design environment) are always noted as unbound in the Synplify reports. As long as the underlying netlist (.ngo, .ngc or .edn) for a black box exists in the project directory, the implementation tools merge the netlist into the design during the Translate phase.

Mapper Report

The mapper report lists the constraint files used, the target technology, and attributes set in the design. The report lists the mapping results of flattened instances, extracted counters, optimized flip-flops, clock and buffered nets that were created, and how FSMs were coded.

Timing Report

The timing report section provides detailed information on the constraints that you entered and on delays on parts of the design that had no constraints. The delay values are based on wireload models and are considered preliminary. Consult the post-Place and

Route timing reports discussed in Chapter 6, Design Implementation, for the most accurate delay information.

Performance Summary

Worst slack in design: -1.581

Starting Clock	Requested Frequency	Estimated Frequency	Requested Period	Estimated Period	Slack
stopwatch clk_divider.clk_100_inferred_clock	305.3 MHz	259.5 MHz	3.276	3.854	-0.578
stopwatch dcm1_inst.CLKFX_BUF_derived_clock	111.6 MHz	94.9 MHz	8.959	10.540	-1.581

Figure 3-27: Synplify Estimated Timing Data

Resource Utilization

This section of the report lists all of the resources that the Synplify software uses for the given target technology.

You have now completed Synplify synthesis. At this point, a netlist EDN file exists for the stopwatch design.

To continue with the HDL flow, do either of the following:

- Go to Chapter 5, Behavioral Simulation, to perform a pre-synthesis simulation of this design.
- Proceed to Chapter 6, Design Implementation, to place and route the design.

Synthesizing the Design Using Precision Synthesis

Now that you have entered and analyzed the design, the next step is to synthesize the design. In this step, the HDL files are translated into gates and optimized to the target architecture.

Processes available for synthesis using the Precision software are as follows:

Check Syntax

Checks the syntax of the HDL code.

• View RTL Schematic

Accessible from the Launch Tools hierarchy, this process displays the Precision software with a schematic view of your HDL code.

• View Technology Schematic

Accessible from the Launch Tools hierarchy, this process displays the Precision software with a schematic view of your HDL code mapped to the primitives associated with the target technology.

• View Critical Path Schematic

Accessible from the Launch Tools hierarchy, this process displays the Precision software with a schematic view of the critical path of your HDL code mapped to the primitives associated with the target technology.

Entering Synthesis Options and Synthesizing the Design

Synthesis options enable you to modify the behavior of the synthesis tool to optimize according to the needs of the design. For the tutorial, the default property settings will be used.

To synthesize the design, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select stopwatch.vhd (or stopwatch.v).
- 2. In the Processes pane, double-click the **Synthesize** process.

Using the RTL/Technology Viewer

Precision Synthesis can generate a schematic representation of the HDL code that you have entered. A schematic view of the code helps you analyze your design by seeing a graphical connection between the various components that Precision has inferred. To launch the design in the RTL viewer, double-click the **View RTL Schematic** process. The following figure displays the design in an RTL view.



Figure 3-28: Stopwatch Design in Precision Synthesis RTL Viewer

You have now completed the design synthesis. At this point, an EDN netlist file exists for the stopwatch design.

To continue with the HDL flow, do either of the following:

- Go to Chapter 5, Behavioral Simulation, to perform a pre-synthesis simulation of this design.
- Proceed to Chapter 6, Design Implementation, to place and route the design.



Chapter 4

Schematic-Based Design

Overview of Schematic-Based Design

This chapter guides you through a typical FPGA schematic-based design procedure using the design of a runner's stopwatch. The design example used in this tutorial demonstrates many device features, software features, and design flow practices that you can apply to your own designs. The stopwatch design targets a SpartanTM-3A device; however, all of the principles and flows taught are applicable to any Xilinx® device family, unless otherwise noted.

This chapter is the first in the Schematic Design Flow. In the first part of the tutorial, you will use the ISE® design entry tools to complete the design. The design is composed of schematic elements, CORE Generator[™] tool components, and HDL macros. After the design is successfully entered in the Schematic Editor, you will perform behavioral simulation (Chapter 5, Behavioral Simulation), run implementation with the Xilinx implementation tools (Chapter 6, Design Implementation), perform timing simulation (Chapter 7, Timing Simulation), and configure and download to the Spartan-3A (XC3S700A) demo board (see Chapter 8, Configuration Using iMPACT).

Getting Started

The following sections describe the basic requirements for running the tutorial.

Required Software

To perform this tutorial, you must have Xilinx ISE Design Suite installed. For this design, you must install the Spartan-3A device libraries and device files.

This tutorial assumes that the software is installed in the default location, at c:\xilinx\release_number\ISE_DS\ISE. If you installed the software in a different location, substitute your installation path in the procedures that follow.

Note: For detailed software installation instructions, refer to the *ISE Design Suite: Installation and Licensing Guide (UG798)* available from the Xilinx website.

Installing the Tutorial Project Files

The tutorial project files are provided with the ISE Design Suite <u>Tutorials</u> available from the Xilinx website. Download the schematic design files (wtut_sc.zip). The download contains the following directories:

• wtut_sc

Contains source files for the schematic tutorial. The schematic tutorial project will be created in this directory.

wtut_sc\wtut_sc_completed

Contains the completed design files for the schematic tutorial design, including schematic, HDL, and state machine files.

Note: Do not overwrite files under this directory.

The schematic tutorial files are copied into the directories when you unzip the files. This tutorial assumes that the files are unzipped under c:\xilinx_tutorial, but you can unzip the source files into any directory with read/write permissions. If you unzip the files into a different location, substitute your project path in the procedures that follow.

Starting the ISE Design Suite

To launch the ISE Design Suite, double-click the Project Navigator icon on your desktop, or select Start > All Programs > Xilinx ISE Design Suite > ISE Design Tools > Project Navigator.



Figure 4-1: Project Navigator Desktop Icon

Creating a New Project

To create a new project using the New Project Wizard, do the following:

- 1. From Project Navigator, select **File > New Project**.
- 2. In the Location field, browse to c:\xilinx_tutorial or to the directory in which you installed the project.
- 3. In the Name field, enter **wtut_sc**.
- 4. Select Schematic as the Top-Level Source Type, and then click Next.
- 5. Select the following values in the New Project Wizard—Device Properties page:
 - Product Category: All
 - Family: Spartan3A and Spartan3AN
 - Device: XC3S700A

- Package: **FG484**
- Speed: -4
- Synthesis Tool: XST (VHDL/Verilog)
- Simulator: ISim (VHDL/Verilog)
- Preferred Language: **VHDL** or **Verilog** depending on preference. This will determine the default language for all processes that generate HDL files.

Other properties can be left at their default values.

6. Click **Next**, then **Finish** to complete the project creation.

Stopping the Tutorial

If you need to stop the tutorial at any time, save your work by selecting **File > Save All**.

Design Description

The design used in this tutorial is a hierarchical, schematic-based design, which means that the top-level design file is a schematic sheet that refers to several other lower-level macros. The lower-level macros are a variety of different types of modules, including schematic-based modules, a CORE Generator tool module, an Architecture Wizard module, and HDL modules.

The runner's stopwatch design begins as an unfinished design. Throughout the tutorial, you will complete the design by creating some of the modules and by completing others from existing files. Through the course of this chapter, you will create these modules,

instantiate them, and then connect them. The following figure shows a schematic of the completed stopwatch design.



Figure 4-2: Completed Stopwatch Schematic

After the design is complete, you will simulate the design to verify its functionality. For more information about simulating your design, see Chapter 5, Behavioral Simulation.

There are five external inputs and four external outputs in the completed design. The following sections summarize the inputs and outputs, and their respective functions.

Inputs

The following are input signals for the tutorial stopwatch design:

strtstop

Starts and stops the stopwatch. This is an active low signal which acts like the start/ stop button on a runner's stopwatch.

• reset

Puts the stopwatch in clocking mode and resets the time to 0:00:00.

• clk

Externally generated system clock.

• mode

Toggles between clocking and timer modes. This input is only functional while the clock or timer is not counting.

lap_load

•

This is a dual function signal. In clocking mode it displays the current clock value in the 'Lap' display area. In timer mode it will load the pre-assigned values from the ROM to the timer display when the timer is not counting.

Outputs

The following are outputs signals for the design:

lcd_e, lcd_rs, lcd_rw

These outputs are the control signals for the LCD display of the Spartan-3A demo board used to display the stopwatch times.

• sf_d[7:0]

Provides the data values for the LCD display.

Functional Blocks

The completed design consists of the following functional blocks. Most of these blocks do not appear on the schematic sheet in the project until after you create and add them to the schematic during this tutorial.

The completed design consists of the following functional blocks:

• clk_div_262k

Macro which divides a clock frequency by 262,144. Converts 26.2144 MHz clock into 100 Hz 50% duty cycle clock.

• dcm1

Clocking Wizard macro with internal feedback, frequency controlled output, and duty-cycle correction. The CLKFX_OUT output converts the 50 MHz clock of the Spartan-3A demo board to 26.2144 MHz.

• debounce

Module implementing a simplistic debounce circuit for the strtstop, mode, and lap_load input signals.

• lcd_control

Module controlling the initialization of and output to the LCD display.

• statmach

State machine module which controls the state of the stopwatch.

• timer_preset

CORE Generator tool 64X20 ROM. This macro contains 64 preset times from 0:00:00 to 9:59:99 which can be loaded into the timer.

• time_cnt

Up/down counter module which counts between 0:00:00 to 9:59:99 decimal. This macro has five 4-bit outputs, which represent the digits of the stopwatch time.

Design Entry

In this hierarchical design, you will create various types of macros, including schematic-based macros, HDL-based macros, and CORE Generator tool macros. You will learn the process for creating each of these types of macros, and you will connect the macros together to create the completed stopwatch design. All procedures used in the tutorial can be used later for your own designs.

Adding Source Files

Source files must be added to the project before the design can be edited, synthesized and implemented. You will add six source files to the project as follows:

- 1. Select **Project > Add Source**.
- 2. Select the following files from the project directory and click **Open**.
 - cd4rled.sch
 - ch4rled.sch
 - clk_div_262k.vhd
 - lcd_control.vhd
 - stopwatch.sch
 - statmach.vhd
- 3. In the Adding Source Files dialog box, verify that the files are associated with **All**, that the associated library is **work**, and click **OK**.

The Hierarchy pane in the Design panel displays all of the source files currently added to the project, with the associated entity or module names.

Opening the Schematic File in the Xilinx Schematic Editor

The stopwatch schematic available in the wtut_sc project is incomplete. In this tutorial, you will update the schematic in the Schematic Editor. After you create the project in Project Navigator and add the source files, you can open the stopwatch.sch file for editing. To open the schematic file, double-click stopwatch.sch in the Hierarchy pane of the Design panel.

The stopwatch schematic diagram opens in the Project Navigator Workspace. You will see the unfinished design with elements in the lower right corner, as shown in the following figure.

clk_div_262k





Figure 4-3: Incomplete Stopwatch Schematic

Manipulating the Window View

The View menu commands enable you to manipulate how the schematic is displayed. Select **View > Zoom > In** until you can comfortably view the schematic.

The schematic window can be undocked from the Project Navigator framework by selecting **Window > Float** while the schematic is selected in the Workspace.

After being undocked, the schematic window can be redocked by selecting **Window > Dock**.

Creating a Schematic-Based Macro

A schematic-based macro consists of a symbol and an underlying schematic. You can create either the underlying schematic or the symbol first. The corresponding symbol or schematic file can then be generated automatically.

In the following steps, you will create a schematic-based macro by using the New Source Wizard in Project Navigator. An empty schematic file is then created, and you can define the appropriate logic. The created macro is then automatically added to the project library.

The macro you will create is called time_cnt. This macro is a binary counter with five, 4-bit outputs, representing the digits of the stopwatch.

To create a schematic-based macro, do the following:

1. In Project Navigator, select **Project > New Source**.

The New Source Wizard opens, which displays a list of all of the available source types.

🔤 New Source Wizard	
Select Source Type Select source type, file name and its location.	
BMM File ChipScope Definition and Connection File Implementation Constraints File IP (CORE Generator & Architecture Wizard) MEM File Schematic System Generator Project User Document Verilog Module Verilog Test Fixture VHDL Module VHDL Nodule VHDL Package VHDL Test Bench Embedded Processor	File name: time_cnt Location: C:\xilinx_tutorial\wtut_sc
More Info	Next > Cancel

Figure 4-4: **New Source Dialog Box**

- 2. Select **Schematic** as the source type.
- 3. In the File name field, enter time_cnt.
- 4. Click Next, and click Finish.

A new schematic called time_cnt.sch is created, added to the project, and opened for editing.

- 5. Change the size of the schematic sheet by doing the following:
 - a. Right-click on the schematic page and select Object Properties.
 - b. Click on the down arrow next to the sheet size value and select **D** = 34 x 22.
 - c. Click **OK**.

Note: Changing the sheet size cannot be undone with the Edit > Undo option.

Defining the time_cnt Schematic

You have now created an empty schematic for time_cnt. The next step is to add the components that make up the time_cnt macro. You can then reference this macro symbol by placing it on a schematic sheet.

Adding I/O Markers

I/O markers are used to determine the ports on a macro or the top-level schematic. The name of each pin on the symbol must have a corresponding connector in the underlying schematic. Add I/O markers to the time_cnt schematic to determine the macro ports.

To add the I/O markers, do the following:

- 1. Select Tools > Create I/O Markers.
- In the Inputs field of the Create I/O Markers dialog box, enter q(19:0), load, up, ce, clk, clr.
- 3. In the Outputs box, enter

```
hundredths(3:0),tenths(3:0),sec_lsb(3:0),sec_msb(3:0),minutes(3
:0).
```

🚾 Create 170 Markers	×
Inputs	_
hundredths(3:0),tenths(3:0),sec_lsb(3:0),sec_msb(3:0),minutes(3:0)	
Bidirection	
OK Cancel Help	

Figure 4-5: Create I/O Markers Dialog Box

4. Click **OK**.

The eleven I/O markers are added to the schematic sheet.

Note: The Create I/O Marker function is available only for an empty schematic sheet. However, I/O markers can be added to nets at any time by selecting **Add** > **I/O Marker** and selecting the desired net.

Adding Schematic Components

Components from the device and project libraries for the given project are available from the Symbol Browser, and the component symbol can be placed on the schematic. The available components listed in the Symbol Browser are arranged alphabetically within each library.

To add schematic components, do the following:

1. Select **Add > Symbol**, or click the Add Symbol toolbar button.



Figure 4-6: Add Symbol Toolbar Button

The Symbol Browser appears in the Options panel to the left of the schematic. The Symbol Browser displays the libraries and their corresponding components.

ymbols	⇔□₽
Categories	
	~
<c: 11.1="" ise="" iseexamples="" wtut_sc="" xilinx=""></c:>	
Arithmetic	
Buffer	
Carry_Logic	_
Comparator	
Counter	
DDR Flip_Flop	
Decoder	
Flip_Flop	
General	
IO	
IO_FlipFlop	
IO_Latch	~
Tumbola	
Symbols	
cd4rled	
ch4rled	
clk_div_262k	
· lcd_control	
·	

Figure 4-7: Symbol Browser

Note: The Options panel changes depending on the action you are performing in the schematic.

- 2. The first component you will place is a cd4rled, a 4-bit, loadable, bi-directional, BCD counter with clock enable and synchronous clear. Select the cd4rled component, using either of the following methods:
 - Highlight the project directory category from the Symbol Browser dialog box and select the component **cd4rled** from the symbols list.
 - Select **All Symbols** and enter **cd4rled** in the Symbol Name Filter at the bottom of the Symbol Browser.
- 3. Move the mouse back into the schematic window.

You will notice that the cursor has changed to represent the cd4rled symbol.

4. Move the symbol outline near the top and center of the sheet and click the left mouse button to place the object.

Note: You can rotate new components being added to a schematic by selecting Ctrl+R. You can rotate existing components by selecting the component, and then selecting Ctrl+R.

5. Place three more cd4rled symbols on the schematic by moving the cursor with attached symbol outline to the desired location and clicking the left mouse button. See the following figure.



Figure 4-8: Partially Completed time_cnt Schematic

- 6. Follow the procedure outlined in steps 1 through 5 above to place the following components on the schematic sheet:
 - AND2b1
 - ch4rled
 - AND5

Refer to Figure 4-8 for placement locations.

7. To exit the Symbols mode, press the **Esc** key on the keyboard.

For a detailed description of the functionality of Xilinx library components, right-click the component and select **Symbol > Symbol Info**. Symbol information is also available in the *Libraries Guides*.

Correcting Mistakes

If you make a mistake when placing a component, you can easily move or delete the component as follows:

- To move the component, click the component and drag the mouse around the window.
- To delete a placed component, use either of the following methods:
 - Click the component, and press the **Delete** key on your keyboard.
 - Right-click the component, and select **Delete**.

Drawing Wires

You can draw wires (also called nets) to connect the components placed in the schematic. Perform the following steps to draw a net between the AND2b1 and top cd4rled components on the time_cnt schematic:

1. Select **Add > Wire**, or click the Add Wire toolbar button.

Figure 4-9: Add Wire Toolbar Button

- 2. Click the output pin of the AND2b1 and then click the destination pin CE on the cd4rled component. The Schematic Editor draws a net between the two pins.
- 3. Draw a net to connect the output of the AND5 component to the inverted input of the AND2b1 component. Connect the other input of the AND2b1 to the **ce** input I/O marker.
- 4. Connect the **load**, **up**, **clk**, and **clr** input I/O markers respectively to the **L**, **UP**, **C**, and **R** pins of each of the five counter blocks and connect the **CEO** pin of the first four counters to the **CE** pin of the next counter as shown in Figure 4-8.

To specify the shape of the net, do the following:

- 1. Move the mouse in the direction you want to draw the net.
- 2. Click the mouse to create a 90-degree bend in the wire.

Note: To draw a net between an already existing net and a pin, click once on the component pin and once on the existing net. A junction point is drawn on the existing net.

Adding Buses

In the Schematic Editor, a bus is simply a wire that has been given a multi-bit name. To add a bus, use the methodology for adding wires and then add a multi-bit name. After a bus has been created, you have the option of "tapping" this bus off to use each signal individually.

The next step is to create buses for each of the five outputs of the time_cnt schematic. The results can be found in the completed schematic.

To add the buses hundredths(3:0), tenths(3:0), sec_lsb(3:0), sec_msb(3:0) and minutes(3:0) to the schematic, perform the following steps:

- 1. Select all of the output I/O markers by drawing a box around them and then drag the group so that minutes(3:0) is below the Q3 output of the bottom counter block.
- 2. Select **Add > Wire**, or click the Add Wire toolbar button.
- 3. Click in the open space just above and to the right of the top cd4rled, and then click again on the pin of the hundredths(3:0) I/O marker. The thick line should automatically be drawn to represent a bus with the name matching that of the I/O marker.



Figure 4-10: Adding a Bus

- 4. Repeat Steps 2 and 3 for the four remaining buses.
- 5. After adding the five buses, press **Esc** or right-click at the end of the bus to exit the Add Wire mode.

Adding Bus Taps

Next, add nets to attach the appropriate pins from the cd4rled and ch4rled counters to the buses. Use bus taps to tap off a single bit of a bus and connect it to another component.

Note: Zooming in on the schematic enables greater precision when drawing the nets.

To tap off a single bit of each bus, do the following:

1. Select **Add > Bus Tap**, or click the Add Bus Tap toolbar button.



The cursor changes, indicating that you are now in Draw Bus Tap mode.

2. In the Add Bus Tap Options that appear in the Options panel, choose the --< **Right** orientation for the bus tap.

3. Click on the hundreths(3:0) bus with the left mouse button.

The Selected Bus Name and the Net Name values in the Options panel are now populated.

Note: The indexes of the Net Name may be incremented or decremented by clicking the arrow buttons next to the Net Name box.

4. With hundredths(3) as the Net Name value, move the cursor so the tip of the attached tap touches the Q3 pin of the top cd4rled component.

Note: Four selection squares appear around the pin when the cursor is in the correct position.

5. Click once when the cursor is in the correct position.

A tap is connected to the hundredths(3:0) bus, and a wire named hundreths(3) is drawn between the tap and the Q3 pin.

Click successively on pins Q2, Q1, and Q0 to create taps for the remaining bits of the hundredths(3:0) bus.

6. Repeat Steps 3 to 5 to tap off four bits from each of the remaining four buses.

Note: It is the name of the wire that makes the electrical connection between the bus and the wire (for example, sec_msb(2) connects to the third bit of sec(3:0)). The bus tap figure is for visual purposes only. The following section shows additional electrical connections by name association.

- 7. Press **Esc** to exit the Add Bus Tap mode.
- 8. Compare your time_cnt schematic with Figure 4-13 to ensure that all connections are made properly.

Adding Net Names

First, add a hanging wire to each of the five inputs of the AND5 component and to the TC pin of each of the counter blocks.

Next, add net names to the wires. To add the net names, do the following:

1. Select **Add > Net Name**, or click the Add Net Name toolbar button.



Figure 4-12: Add Net Name Toolbar Button

- 2. In the Add Net Name Options that appear in the Options panel, do the following:
 - a. In the Name field, enter tc_out0.
 - b. Select Increase the Name.

The net name tc_out0 is now attached to the cursor.

3. Click the net attached to the first input of the AND5 component.

The name is attached to the net. The net name appears above the net if the name is placed on any point of the net other than an end point.

4. Click on the remaining input nets of the AND5 to add tc_out1, tc_out2, tc_out3 and tc_out4.

The Schematic Editor increments the net name as each name is placed on a net.

Note: Alternatively, name the first net tc_out4 and select **Decrease the name** in the Add Net Names Options, and nets are named from the bottom up.

5. Repeat step 2 and then click successively on the nets connected to the TC output to add tc_out0, tc_out1, tc_out2, tc_out3, and tc_out4 to these nets.

Note: Each of the wires with identical names are now electrically connected. In this case, the nets do not need to be physically connected on the schematic to make the logical connection.

Finally, connect the input pins of the counters through net name association as follows:

- 1. Select **Add** > **Wire** or click the Add Wire toolbar button, and add a hanging net to the four data pins of each of the five counters.
- 2. Select Add > Net Name, or click the Add Net Name toolbar button.
- 3. In the Add Net Name Options that appear in the Options panel, enter **q(0)** in the Name field.
- 4. Select Increase the name.

The net name **q(0)** is now attached to the cursor.

5. Click successively on each of the nets connected to data inputs, starting from the top so that the net named q(0) is attached to the D0 pin of the top counter and the net named q(19) is attached to the D3 pin of the bottom counter. See the following figure.





Note: If the nets appear disconnected, select View > Refresh to refresh the screen

www.xilinx.com

Checking the Schematic

The time_cnt schematic is now complete. Verify that the schematic does not contain logical errors by running a design rule check (DRC). To do this, select **Tools > Check Schematic**. The Console should report that no errors or warnings are detected. If an error or warning is displayed, fix the reported problem before proceeding.

Saving the Schematic

Save the schematic as follows:

1. Select **File > Save**, or click the Save toolbar button.

Figure 4-14: Save Toolbar Button

2. Close the time_cnt schematic.

Creating and Placing the time_cnt Symbol

The next step is to create a "symbol" that represents the time_cnt macro. The symbol is an instantiation of the macro. After you create a symbol for time_cnt, you will add the symbol to a top-level schematic of the stopwatch design. In the top-level schematic, the symbol of the time_cnt macro will be connected to other components in a later section in this chapter.

Creating the time_cnt Symbol

You can create a symbol using either a Project Navigator process or a Tools menu command.

To create a symbol that represents the time_cnt schematic using a Project Navigator process, do the following:

- 1. In the Hierarchy pane of the Design panel, select time_cnt.sch.
- 2. In the Processes pane, expand **Design Utilities**, and double-click **Create Schematic Symbol**.

To create a symbol that represents the time_cnt schematic using a Tools menu command, do the following:

- 1. With the time_cnt schematic sheet open, select **Tools > Symbol Wizard**.
- 2. In the Symbol Wizard, select **Using Schematic**, and select **time_cnt**.
- 3. Click **Next**, then **Next**, then **Next**, and then **Finish** to use the wizard defaults.
- 4. View and then close the time_cnt symbol.

Placing the time_cnt Symbol

Next, place the symbol that represents the macro on the top-level schematic (stopwatch.sch) as follows:

- 1. In the Hierarchy pane of the Design panel, double-click stopwatch.sch to open the schematic.
- 2. Select **Add > Symbol**, or click the Add Symbol toolbar button.



Figure 4-15: Add Symbol Toolbar Button

- In the Symbol Browser, select the local symbols library (c:\xilinx_tutorial\wtut_sc), and then select the newly created time_cnt symbol.
- 4. Place the time_cnt symbol in the schematic so that the output pins line up with the five buses driving inputs to the lcd_control component. This should be close to grid position [1612,1728]. Grid position is shown at the bottom right corner of the Project Navigator window, and is updated as the cursor is moved around the schematic.

Note: Do not worry about connecting nets to the input pins of the time_cnt symbol. You will do this after adding other components to the stopwatch schematic.

5. Save the changes and close stopwatch.sch.

Creating a CORE Generator Tool Module

The CORE Generator tool is a graphical interactive design tool that enables you to create high-level modules such as memory elements, math functions, communications, and I/O interface cores. You can customize and pre-optimize the modules to take advantage of the inherent architectural features of the Xilinx FPGA architectures, such as Fast Carry Logic, SRL16s, and distributed and block RAM.

In this section, you will create a CORE Generator tool module called timer_preset. The module is used to store a set of 64 values to load into the timer.

Creating the timer_preset CORE Generator Tool Module

To create a CORE Generator tool module, do the following:

- 1. In Project Navigator, select **Project > New Source**.
- 2. Select IP (Coregen & Architecture Wizard).
- 3. In the File name field, enter timer_preset.
- 4. Click Next.
- 5. Double-click Memories & Storage Elements > RAMs & ROMs.

6. Select **Distributed Memory Generator**, then click **Next**, and click **Finish** to open the Distributed Memory Generator customization GUI. This customization GUI enables you to customize the memory to the design specifications.

View by Function	View by Name						
Name		 Version 	Status	License	Vendor	Library	
Basic Element Debug & Viet Digital Signal PF0A Featu Memories & PF0A Featu Memories & PF0A Featu Memory PF0A Featu Memory Bio Pf0A Featu Bio Standard Bu Video & Ima	It's ion & Networking fication processing es and Design not Sorage Elements Interface Generators ROMs Kemory Generator Kemory Generator Kemory Generator Kemory Generator Kemory Generator Romany Gen	4.2 4.3 5.1 6.1 tor 6.1	Production Production Production Production		Xiinx Xiinx Xiinx Xiinx Xiinx	նթ 10 10 10 10 10 10	
							(c)

Figure 4-16: New Source Wizard—Select IP Page

- 7. Fill in the Distributed Memory Generator customization GUI with the following settings:
 - Component Name: **timer_preset** (defines the name of the module)
 - Depth: **64** (defines the number of values to be stored)
 - Data Width: **20** (defines the width of the output bus)
 - Memory Type: **ROM**
- 8. Click Next.

		logiCXRE	Distributed Memory Generator
a[5:0] → d[19:0] → dpra[5:0] →	→spo[19:0] →qspo[19:0] →qpo[19:0]	Component Name Options Depth 64 Data Width 20	timer_preset Range: 1665536 Range: 11024
← lot picture ← so_i ← so_i ← so ← so		ROM Dual Port RAM Simple Dual Po	Single Port RAM SIL 16-based Memory art RAM

9. Leave Input and Output options as **Non Registered**, and click **Next**.

Figure 4-17: CORE Generator Tool—Distributed Memory Generator Customization GUI

- 10. To specify the Coefficients File, click the **Browse** button to browse to the project directory, and select definition1_times.coe.
- 11. Check that *only* the following pins are used (used pins are highlighted on the symbol on the left side of the customization GUI):
 - a[5:0]
 - spo[19:0]
- 12. Click Generate.

The module is created and automatically added to the project library.

A number of files are added to the ipcore_dir sub-directory of the project directory. Following is a list of some of these files:

timer_preset.sym

This file is a schematic symbol file.

timer_preset.vhd or timer_preset.v

These are HDL wrapper files for the core and are used only for simulation.

• timer_preset.ngc

This file is the netlist that is used during the Translate phase of implementation.

• timer_preset.xco

This file stores the configuration information for the timer_preset module and is used as a project source.

• timer_preset.mif

This file provides the initialization values of the ROM for simulation.

Creating a DCM Module

The Clocking Wizard, a Xilinx Architecture Wizard, enables you to graphically select Digital Clock Manager (DCM) features that you want to use. In this section, you will create a basic DCM module with CLK0 feedback and duty-cycle correction.

Using the Clocking Wizard

Create the dcm1 module as follows:

- 1. In Project Navigator, select **Project > New Source**.
- In the New Source Wizard, select the IP (Coregen & Architecture Wizard) source type, and enter dcm1 for the file name.
- 3. Click Next.
- 4. In the Select IP dialog box, select **FPGA Features and Design > Clocking > Spartan-3E, Spartan-3A > Single DCM_SP**.

Name Digital Signal Processing FPGA Features and Design	A Version	n Status	License	Vendor
Digital Signal Processing FPGA Features and Design	1			YCHOOL
FPGA Features and Design				
📄 🧖 Clocking				
Clocking Wizard	3.1	N/A		Yiliny
Electing wizere	0.1	100 H		OBILIA
Spartan-3E Spartan-3A				
Board Deskew with an Internal Deskew (D	CM SP) 13.1	Production		Xilinx
Cascading in Series with Two DCM SP	13.1	Production		Xilinx
🗌 🔆 Clock Forwarding / Board Deskew (DCM_S	P) 13.1	Production		Xilinx
Clock Switching with Two DCM_SPs	13.1	Production		Xilinx
Single DCM_SP	13.1	Production		Xilinx
🗊 💋 Virtex-4				
🕒 📂 💋 Virtex-5				
🖶 💋 IO Interfaces				
<				>

Figure 4-18: Selecting Single DCM Core Type

- 5. Click **Next**, then click **Finish**. The Clocking Wizard opens.
- 6. In the Architecture Wizard Setup page, select **OK**.
- 7. In the General Setup page, verify that **RST**, **CLK0** and **LOCKED** ports are selected.
- 8. Select CLKFX port.

- 9. Type **50** and select **MHz** for the Input Clock Frequency.
- 10. Verify the following settings:
 - Phase Shift: NONE
 - CLKIN Source: External, Single
 - Feedback Source: Internal
 - Feedback Value: **1X**
 - Use Duty Cycle Correction: Selected

🏶 Xilinx Clocking Wizard - General Setup	
CLKIN CLKFB CLKFB DC PSEN PSEN PSINCDEC PSCLK	CLK90
C Input Clock Frequency P	hase Shift ype: NONE y value: 0 0
CLKIN Source	Feedback Source
 External Internal 	External Internal None
 Single 	③ Single
O Differential	 Differential
- Divide By Value	- Feedback Value
2 4	⊙ 1× ○ 2×
L V Use Duty Cycle Correction	
More Info Advanced	< Back Next > Cancel

Figure 4-19: Xilinx Clocking Wizard—General Setup

- 11. Click the **Advanced** button.
- 12. Select the Wait for DCM Lock before DONE Signal goes high option.
- 13. Click **OK**.
- 14. Click Next, and then Next again.
- 15. Select Use output frequency and enter 26.2144 in the box and select MHz.

$$(26.2144Mhz)/2^{18} = 100Hz$$

16. Click **Next**, and then click **Finish**.

The dcm1.xaw file is created and added to the list of project source files in the Hierarchy pane of the Design panel.

Creating the dcm1 Symbol

Next, create a symbol representing the dcm1 macro. This symbol will be added to the top-level schematic (stopwatch.sch) later in the tutorial.

- 1. In Hierarchy pane of the Project Navigator Design panel, select dcm1.xaw.
- 2. In the Processes pane, double-click Create Schematic Symbol.

Creating an HDL-Based Module

With the ISE Design Suite, you can easily create modules from HDL code. The HDL code is connected to your top-level schematic design through instantiation and compiled with the rest of the design. You will author a new HDL module. This macro will be used to debounce the strtstop, mode, and lap_load inputs.

Using the New Source Wizard and ISE Text Editor

In this section, you create a file using the New Source wizard, specifying the name and ports of the component. The resulting HDL file is then modified in the ISE Text Editor.

To create the source file, do the following:

- 1. Select **Project > New Source**.
- 2. Select VHDL Module or Verilog Module.
- 3. In the File Name field, enter **debounce**.
- 4. Click Next.
- 5. Enter two input ports named sig_in and clk and an output port named sig_out for the debounce component as follows:
 - a. In the first three Port Name fields, enter **sig_in**, **clk and sig_out**.
 - b. Set the Direction field to input for sig_in and clk and to output for sig_out.
 - c. Leave the Bus designation boxes unchecked.

🔤 New Source V	/izard						×
Define Module Specify ports	s for module.						
Entity name	debounce						
Architecture name	Behavioral						
	Port Name	Direction		Bus	MSB	LSB	^
sig_in		in	~				
clk		in	*				
sig_out		out	*				
		in	~				
		in	*				
		in	*				
		in	~				
		in	*				
		in	*				
		in	*				
		in	*				~
More Info			< Ba	ack	Next >	Cano	el

Figure 4-20: New Source Wizard

- 6. Click **Next** to view a description of the module.
- 7. Click Finish to open the empty HDL file in the ISE Text Editor.

The VHDL file is shown in the following figure.

```
-- Module Name:
                           debounce - Behavioral
     -- Project Name:
8
9
     -- Target Devices:
     -- Tool versions:
10
     -- Description:
11
12
13
     -- Dependencies:
14
15
     -- Revision:
16
     -- Revision 0.01 - File Created
     -- Additional Comments:
17
18
19
     library IEEE;
20
    use IEEE STD_LOGIC_1164.ALL;
use IEEE.STD_LOGIC_ARITH.ALL;
use IEEE.STD_LOGIC_UNSIGNED.ALL;
21
22
23
24
25
        -- Uncomment the following library declaration if instantiating
26
     ---- any Xilinx primitives in this code.
27
     --library UNISIM;
28
     --use UNISIM.VComponents.all;
29
30
     entity debounce is
        Port ( sig_in : in STD_LOGIC;
clk : in STD_LOGIC;
31
32
                 sig_out : out STD_LOGIC);
33
34
35
    end debounce;
36
     architecture Behavioral of debounce is
37
38
    begin
39
40
41
     end Behavioral;
42
```

Figure 4-21: VHDL File in ISE Text Editor

The Verilog HDL file is shown in the following figure.



Figure 4-22: Verilog File in ISE Text Editor

www.xilinx.com

In the ISE Text Editor, the ports are already declared in the HDL file, and some of the basic file structure is already in place. Keywords are displayed in blue, comments in green, and values are black. The file is color-coded to enhance readability and help you recognize typographical errors.

Using the Language Templates

The ISE Language Templates include HDL constructs and synthesis templates which represent commonly used logic components, such as counters, D flip-flops, multiplexers, and primitives. You will use the Debounce Circuit template for this exercise.

Note: You can add your own templates to the Language Templates for components or constructs that you use often.

To invoke the Language Templates and select the template for this tutorial, do the following:

1. From Project Navigator, select Edit > Language Templates.

Each HDL language in the Language Templates is divided into the following sections: Common Constructs, Device Macro Instantiation, Device Primitive Instantiation, Simulation Constructs, Synthesis Constructs, and User Templates. To expand the view of any of these sections, click the plus symbol (+) next to the section. Click any of the listed templates to view the template contents in the right pane.

 Under either the VHDL or Verilog hierarchy, expand Synthesis Constructs, expand Coding Examples, expand Misc, and select the template called Debounce Circuit. Use the appropriate template for the language you are using.

When the template is selected in the hierarchy, the contents display in the right pane.



Figure 4-23: Language Templates

Adding a Language Template to a File

You will now use "Use in File" method for adding templates to your HDL file. Refer to "Working with Language Templates" in the ISE Help for additional usability options, including drag and drop options.

To add the template to your HDL file, do the following:

- 1. With the debounce.vor debounce.vhd source file active, position the cursor under the architecture begin statement in the VHDL file, or under the module and pin declarations in the Verilog file.
- 2. Return to the Language Templates window, right-click on the **Debounce Circuit** template in the template index, and select **Use In File**.



Figure 4-24: Selecting Language Template to Use in File

- 3. Close the Language Templates window.
- 4. Open the debounce.v or debounce.vhd source file to verify that the Language Template was properly inserted.
- 5. *Verilog only*: Complete the Verilog module by doing the following:
 - a. Remove the reset logic (not used in this design) by deleting the three lines beginning with if and ending with else.
 - b. Change <reg_name> to **q** in all six locations.
 - c. Change <clock> to clk; <input> to sig_in; and <output> to sig_out.

Note: You can select **Edit** > **Find & Replace** to facilitate this. The Find fields appear at the bottom of the Text Editor.

- 6. *VHDL only*: Complete the VHDL module by doing the following:
 - a. Move the line beginning with the word signal so that it is between the architecture and begin keywords.
 - b. Remove the reset logic (not used in this design) by deleting the five lines beginning with if (<reset>... and ending with else, and delete one of the end if; lines.
 - c. Change <clock> to clk; D_IN to sig_in; and Q_OUT to sig_out.

Note: You can select **Edit** > **Find & Replace** to facilitate this. The Find fields appear at the bottom of the Text Editor.

- 7. Save the file by selecting **File > Save**.
- 8. Select one of the debounce instances in the Hierarchy pane.
- 9. In the Processes pane, double-click **Check Syntax**. Verify that the syntax check passes successfully. Correct any errors as necessary.
- 10. Close the ISE Text Editor.

Creating Schematic Symbols for HDL Modules

Next, create the schematic symbols for both the debounce and statmach HDL files as follows:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select debounce.vhd or debounce.v.
- 2. In the Processes panel, expand **Design Utilities**, and double-click **Create Schematic Symbol**.
- 3. Repeat this procedure for the statmach.vhd file.

You are now ready to place the symbols on the stopwatch schematic.

Placing the statmach, timer_preset, dcm1, and debounce Symbols

You can now place the statmach, timer_preset, dcm1, and debounce symbols on the stopwatch schematic (stopwatch.sch).

To place the symbols, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, double-click stopwatch.sch to open the schematic file in the Workspace.
- 2. Select **Add > Symbol**, or click the Add Symbol toolbar button.



Figure 4-25: Add Symbol Toolbar Button

The Symbol Browser appears in the Options panel to the left of the schematic. The Symbol Browser displays the libraries and their corresponding components.

- 3. View the list of available library components in the Symbol Browser.
- 4. Locate the project-specific macros by selecting the project directory name in the Categories window.

Note: The timer_preset symbol is located in the <code>ipcore_dir</code> directory.

5. Select the appropriate symbol, and add it to the stopwatch schematic in the approximate location, as shown in Figure 4-26.

Note: Do not worry about drawing the wires to connect the symbols. You will connect components in the schematic later in the tutorial.

6. Save the schematic.



The following figure shows the stopwatch schematic with placed symbols.

Figure 4-26: Placing Design Macros

Changing Instance Names

When a symbol is placed on a schematic sheet, it is given a unique instance name beginning with the prefix XLXI_. To help make the hierarchy more readable in the Project Navigator Hierarchy pane, change the names of the added symbol instances as follows:

- 1. Right-click on the dcm1 symbol instance, and select Object Properties.
- 2. In the Object Properties dialog box, change the value of the InstName field to dcm_inst, and click OK.
- 3. Repeat steps 1 and 2 to change the following symbol instance names:
 - Name the statmach instance **timer_state**.
 - Name the top debounce instance **lap_load_debounce**.
 - Name the middle debounce instance **mode_debounce**.
 - Name the bottom debounce instance **strtstop_debounce**.
 - Name the timer_preset instance t_preset.
 - Name the time_cnt instance timer_cnt.

Using Hierarchy Push/Pop

First, perform a hierarchy "push down," which enables you to focus in on a lower-level of the schematic hierarchy to view the underlying file. Push down into the time_cnt macro, which is a schematic-based macro created earlier in this tutorial, and examine its components.

To push down into time_cnt from the top-level stopwatch schematic, do the following:

1. Click the time_cnt symbol in the schematic, and select the Hierarchy Push toolbar button. You can also right-click the macro, and select **Symbol > Push into Symbol**.



Figure 4-27: Hierarchy Push Toolbar Button

In the time_cnt schematic, you see five counter blocks. Push into any of the counter blocks by selecting the block and clicking on the Hierarchy Push toolbar button. This process may be repeated until the schematic page contains only Xilinx primitive components. If you push into a symbol that has an underlying HDL or IP core file, the appropriate text editor or customization GUI opens, which enables you to edit the file.

2. After examining the macro, return to the top-level schematic by selecting **View > Pop to Calling Schematic**, or select the Hierarchy Pop toolbar button when nothing in the schematic is selected. You can also right-click in an open space of the schematic, and select **Pop to Calling Schematic**.



Figure 4-28: Hierarchy Pop Toolbar Button

Specifying Device Inputs/Outputs

You use I/O markers to specify device I/O on a schematic sheet. All of the Schematic Editor schematics are netlisted to VHDL or Verilog and then synthesized by the synthesis tool of choice. When the synthesis tool synthesizes the top-level schematic HDL, the I/O markers are replaced with the appropriate pads and buffers.

Adding Input Pins

Add five input pins to the stopwatch schematic: reset, clk, lap_load, mode and strtstop.

To add these components, draw a hanging wire to the two inputs of dcm1 and to the sig_in pin of each debounce symbol.

Note: Refer to Drawing Wires for detailed instructions.

Adding I/O Markers and Net Names

It is important to label nets and buses for the following reasons:

• Aids in debugging and simulation, because you can more easily trace nets back to your original design.

For example, any nets that remain unnamed in the design will be given generated names that will mean nothing to you later in the implementation process.

• Enhances readability and aids in documenting your design.

Label the five input nets you just drew. Refer to the completed schematic below. To label the reset net, do the following:

- 1. Select **Add > Net Name**.
- 2. In the Add Net Name Options that appear in the Options panel, enter **reset** in the Name box.

The net name is now attached to the cursor.

- 3. Place the name on the leftmost end of the net, as shown in Figure 4-29.
- 4. Repeat Steps 1 through 3 for the clk, lap_load, mode, and strtstop pins. After all of the nets have been labeled, add the I/O marker.
- 5. Select Add > I/O Marker.

6. Click and drag a box around the name of the five labeled nets to place an input port on each net, as shown in the following figure.



Figure 4-29: Adding I/O Markers to Labeled Nets

Assigning Pin Locations

Xilinx recommends that you let the automatic Place and Route (PAR) program define the pinout of your design. Pre-assigning locations to the pins can sometimes degrade the performance of the Place and Route tools. However, it may be necessary at some point to lock the pinout of a design so that it can be integrated into a Printed Circuit Board (PCB).

For this tutorial, the inputs and outputs will be locked to specific pins in order to place and download the design to the Spartan-3A demo board. Because the tutorial stopwatch design is simple and timing is not critical, the example pin assignments will not adversely affect the ability of PAR to place and route the design.

Assign a LOC parameter to the output nets on the stopwatch schematic as follows:

- 1. Right-click on the clk net, and select **Object Properties**.
- 2. In the Object Properties dialog box, click the **New** button.
- 3. In the New Attribute dialog box, enter **LOC** for the Attribute Name and **E12** for the Attribute Value.

View and edit the Name	attributes of the selec Value	ted nets	
Name	Value	A Gallata	
		VISIDIE	New
Name	clk	Add	
PortPolarity	Input	V Add	Edit Traits
LOC	E12	Add	d Delete
	PortPolarity	PortPolarity Input LOC E12	PortPolarity Input Y Add

4. Click **OK** to return to the Object Properties dialog box.

Figure 4-30: Assigning Pin Locations

- 5. To make the LOC attribute visible, select the **Add** button next to the LOC attribute.
- 6. In the Net Attribute Visibility dialog box, click on a location near the center of the displayed net, and then click **OK**.

This will display the LOC attribute on the schematic above the clk net.

7. Click **OK** to close the Object Properties dialog box.

The above procedure constrains clk to pin E12. Notice that the LOC property has already been added to the sf_d(7:0) bus. The remaining pin location constraints will be added in Using the Constraints Editor and Assigning I/O Locations Using the PlanAhead Tool of Chapter 6, Design Implementation.

Note: To turn off the location constraint without deleting it, select the loc attribute, and click **Edit Traits**. Select **VHDL or Verilog** and select **Ignore this attribute**.

Completing the Schematic

Complete the schematic by wiring the components you have created and placed, adding any additional necessary logic, and labeling nets appropriately. The following steps guide you through the process of completing the schematic. You may also want to use the completed schematic shown below to complete the schematic. Each of the actions referred

🗶 XILINX.

to in this section has been discussed in detail in earlier sections of the tutorial. Please see the earlier sections for detailed instructions.



Figure 4-31: Completed Stopwatch Schematic

To complete the schematic diagram, do the following:

- 1. Draw a hanging wire to the LOCKED_OUT pin of dcm1 and name the wire **locked**. See Drawing Wires and Adding Net Names.
- Draw a wire to connect the CLKFX_OUT pin of dcm1 to the CLK_IN pin of 2. clk_div_262k. See Drawing Wires.
- Draw a hanging wire to the clk input of both the time_cnt and statmach macros. See 3. Drawing Wires.
- 4. Name both wires **clk_100**. See Adding Net Names.

www.xilinx.com

Note: Remember that nets are logically connected if their names are the same, even if the net is not physically drawn as a connection in the schematic. This method is used to make the logical connection of clk_100 and several other signals.

- 5. Draw a wire to connect the clk inputs of the three debounce macros and name the wire clk 100.
- 6. Draw wires between the sig_out pins of the debounce components and the lap_load, mode_in, and strtstop pin of the statmach macro. Label the nets **11_debounced**, mode_debounced, and strtstop_debounced. See Drawing Wires and Adding Net Names.
- 7. Add hanging wires to the dcm_lock pin and the reset pin of the statmach macro. Name them **locked** and **reset**, respectively.
- 8. Draw a hanging wire to the clken output of the statmach component and another hanging wire to the ce pin of the time_cnt component. Name both wires **clk_en_int**.
- 9. Draw hanging wires from the rst output pin of the statmach macro and the clr pin of the time_cnt macro. See Drawing Wires. Label both wires **rst_int**.
- 10. Draw a wire from the bus output of the timer_preset to the q(19:0) input of the time_cnt macro. See Drawing Wires. Notice how the wire is automatically converted to a bus.
- 11. Draw a hanging bus on the input of the timer_preset macro and name the bus **address(5:0)**.
- 12. Draw wires from the lap_trigger and mode outputs of the statmach macro to the lap and mode inputs of the lcd_control macro. See Drawing Wires. Name the nets **lap** and **mode_control** respectively.
- 13. Draw hanging wires from the load output of the statmach macro and the load input of the time_cnt macro. See Drawing Wires. Name both wires **load**.
- 14. Draw a hanging wire to the up input time_cnt macro. See Drawing Wires. Name the wire mode_control.
- 15. Draw wires to connect the outputs of time_cnt to the corresponding inputs of lcd_control. See Drawing Wires.
- 16. Save the design by selecting **File > Save**.

You have now completed the schematic design.

To continue with the schematic flow, do either of the following:

- Go to Chapter 5, Behavioral Simulation, to perform a pre-synthesis simulation of this design.
- Proceed to Chapter 6, Design Implementation, to place and route the design.





Chapter 5

Behavioral Simulation

Overview of Behavioral Simulation Flow

The Xilinx® ISE® Design Suite provides an integrated flow with the Mentor ModelSim simulator and the Xilinx ISim simulator that allows simulations to be run from the Xilinx Project Navigator. The examples in this tutorial demonstrate how to use the integrated flow. Whether you use the ModelSim simulator or the ISim simulator with this tutorial, you will achieve the same simulation results. For additional information about simulation, and for a list of other supported simulators, see the *Synthesis and Simulation Design Guide* (*UG626*).

This tutorial provides an introduction to the simulation flow within Project Navigator, including highlights of features within the ModelSim and ISim simulators. For more detailed information about using these simulators, see the ModelSim documentation available from the <u>ModelSim website</u> or the *ISE Simulator (ISim) In-Depth Tutorial (UG682)* provided with the ISE Design Suite <u>Tutorials</u> available from the Xilinx website.

ModelSim Setup

To use this tutorial, you must install ModelSim on your computer. ModelSim PE, ModelSim SE, and ModelSim DE are full versions of ModelSim available for purchase directly from Mentor Graphics. To simulate with the ISE Design Suite libraries, use ModelSim 6.5c or newer. Older versions may work but are not supported. For more information about ModelSim PE, SE, and DE, please contact Mentor Graphics.

ISim Setup

ISim is automatically installed and set up with the ISE Design Suite installer on supported operating systems. To see a list of operating systems supported by ISim, please see the *ISE Design Suite: Release Notes Guide (UG631)* available from the Xilinx website.

Getting Started

The following sections outline the requirements for performing behavioral simulation in this tutorial.

Required Files

The behavioral simulation flow requires design files, a test bench file, and Xilinx simulation libraries.

Design Files (VHDL, Verilog, or Schematic)

This chapter assumes that you have completed the design entry tutorial in either Chapter 3, HDL-Based Design, or Chapter 4, Schematic-Based Design. After you have completed one of these chapters, your design includes the required design files and is ready for simulation.

Test Bench File

To simulate the design, a test bench file is required to provide stimulus to the design. VHDL and Verilog test bench files are available with the tutorial files. You may also create your own test bench file.

Simulation Libraries

Xilinx simulation libraries are required when a Xilinx primitive or IP core is instantiated in the design. The design in this tutorial requires the use of simulation libraries because it contains instantiations of a digital clock manager (DCM) and a CORE GeneratorTM tool component. For information on simulation libraries and how to compile them, see the next section, Xilinx Simulation Libraries.

Xilinx Simulation Libraries

To simulate designs that contain instantiated Xilinx primitives, CORE Generator tool components, and other Xilinx IP cores you must use the Xilinx simulation libraries. These libraries contain models for each component. These models reflect the functions of each component, and provide the simulator with the information required to perform simulation. For a detailed description of each library, see the *Synthesis and Simulation Design Guide* (UG626).

Updating the Xilinx Simulation Libraries

The Xilinx simulation libraries contain models that are updated on a regular basis:

- XilinxCoreLib models are updated each time an IP Update is installed.
- All other models are updated each time a software update is installed.

When the models are updated, you must recompile the libraries. The compiled Xilinx simulation libraries are then available during the simulation of any design.

ModelSim PE, SE, or DE

If you are using ModelSim PE, SE, or DE, you must compile the simulation libraries with the updated models. See the *Synthesis and Simulation Design Guide* (UG626).

Xilinx ISim

Updated simulation libraries for ISim are precompiled and installed with ISE Design Suite installations.

Mapping Simulation Libraries in the modelsim.ini File

ModelSim uses the modelsim.ini file to determine the location of the compiled libraries. For example, if you compiled the UNISIM library to c:\lib\UNISIM, the following mapping appears in the modelsim.ini file:

UNISIM = c:\lib\UNISIM

Note: The modelsim.ini is not applicable to ISim.

ModelSim searches for a modelsim.ini file in the following locations until one is found:

- modelsim.ini file pointed to by the MODELSIM environment variable.
- modelsim.ini file in the current working directory.
- modelsim.ini file in the directory where ModelSim is installed.

If the MODELSIM environment variable is not set, and the modelsim.ini file has not been copied to the working directory, the modelsim.ini file in the ModelSim installation directory is used.

ModelSim PE, SE, or DE

If you are using ModelSim PE, SE, or DE, refer to the *Command Line Tools User Guide* (*UG628*) and use Compxlib to compile the libraries. While compiling the libraries, Compxlib also updates the modelsim.ini file with the correct library mapping. Open the modelsim.ini file, and make sure that the library mappings are correct.

For future projects, you can copy the modelsim.ini file to the working directory and make changes that are specific to that project, or you can use the MODELSIM environment variable to point to the desired modelsim.ini file.

ISim

The modelsim. ini file is not applicable to ISim.

Adding an HDL Test Bench

To add an HDL test bench to your design project, you can either add a test bench file provided with this tutorial, or create your own test bench file and add it to your project.

Adding the Tutorial Test Bench File

This section demonstrates how to add an existing test bench file to the project. A VHDL test bench and Verilog test fixture are provided with this tutorial.

Note: To create your own test bench file in Project Navigator, select **Project > New Source**, and select either **VHDL Test Bench** or **Verilog Text Fixture** in the New Source Wizard. An empty stimulus file is added to your project. You must define the test bench in a text editor.

VHDL Simulation

To add the tutorial VHDL test bench to the project, do the following:

- 1. In Project Navigator, select **Project > Add Source**.
- 2. Select the test bench file stopwatch_tb.vhd.
- 3. Click **Open**.
- 4. Ensure that **Simulation** is selected for the file association type.
- 5. Click **OK**.

File Name	Association		Library
stopwatch_tb.vhd	Simulation	~	work

Figure 5-1: Adding VHDL Test Bench

Verilog Simulation

To add the tutorial Verilog test fixture to the project, do the following:

- 1. In Project Navigator, select Project > Add Source.
- 2. Select the file stopwatch_tb.v.
- 3. Click Open.
- 4. Ensure that **Simulation** is selected for the file association type.
- 5. Click **OK**.

stopwatch_tb.v	Simulation	🖌 work	1
<u></u>	u2		

Figure 5-2: Adding Verilog Test Fixture

Behavioral Simulation Using ModelSim

Now that you have a test bench in your project, you can perform behavioral simulation on the design using the ModelSim simulator. The ISE Design Suite has full integration with the ModelSim simulator. The ISE Design Suite enables ModelSim to create the work directory, compile the source files, load the design, and perform simulation based on simulation properties.

To simulate with ISim, skip to Behavioral Simulation Using ISim. Whether you choose to use the ModelSim simulator or the ISim simulator for this tutorial, the end result is the same.

To select ModelSim as your project simulator, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, right-click the device line (xc3s700a-4fg484), and select **Design Properties**.
- 2. In the Design Properties dialog box, set the Simulator field to **ModelSim** (with the appropriate type and language).

Locating the Simulation Processes

The simulation processes in Project Navigator enable you to run simulation on the design using ModelSim. To locate the ModelSim simulator processes, do the following:

- 1. In the View pane of the Project Navigator Design panel, select **Simulation**, and select **Behavioral** from the drop-down list.
- 2. In the Hierarchy pane, select the test bench file (stopwatch_tb).

 In the Processes pane, expand ModelSim Simulator to view the process hierarchy. The Simulate Behavioral Model process is available, which starts the design simulation.

If ModelSim is installed but the processes are not available, the Project Navigator preferences may not be set correctly. To set the ModelSim location, do the following:

- 1. Select Edit > Preferences.
- 2. In the Preferences dialog box, expand **ISE General**, and click **Integrated Tools**.
- 3. In the right pane, under Model Tech Simulator, browse to the location of the modelsim executable (for example: C:\modeltech_xe\win32xoem\modelsim.exe).

Specifying Simulation Properties

You will perform a behavioral simulation on the stopwatch design after you set process properties for simulation.

Project Navigator allows you to set several ModelSim simulator properties in addition to the simulation netlist properties. To see the behavioral simulation properties and to modify the properties for this tutorial, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select the test bench file (stopwatch_tb).
- 2. In the Processes pane, expand ModelSim Simulator, right-click Simulate Behavioral Model, and select Process Properties.
- 3. In the Process Properties dialog box (Figure 5-3), set the Property display level to **Advanced**.

This global setting enables you to see all available properties.

4. Change the Simulation Run Time to **2000 ns**.

Reprocess Properties - Simulation	n Properties				×
Category	Switch Name	Property Name	Value		•
Simulation Properties	-dir	Compiled Library Directory	language>/ <simulator></simulator>		
Display Properties		Ignore Pre-Compiled Library Warning Check			
		Generate Verbose Library Compilation Messages			
		Use Custom Do File			
		Custom Do File			
		Use Automatic Do File	 Image: A start of the start of		
		Custom Compile File List			
		Other VSIM Command Line Options			
		Other VLOG Command Line Options			
		Other VCOM Command Line Options			
		Simulation Run Time	2000ns		
		Simulation Resolution	Default (1 ps)	~	
		VHDL Syntax	93	~	~
	F	Property display level: 🛛 Advanced 🔽 🗹 Displa	y switch names De	fault	
		OK Cancel	Apply	elp	

Figure 5-3: Behavioral Simulation Process Properties

5. Click **OK**.

Note: For a detailed description of each property available in the Process Properties dialog box, click the **Help** button in the dialog box.

Performing Simulation

After the process properties have been set, you are ready to run ModelSim. To start the behavioral simulation, double-click **Simulate Behavioral Model**. ModelSim creates the work directory, compiles the source files, loads the design, and performs simulation for the time specified.

The majority of this design runs at 100 Hz and would take a significant amount of time to simulate. The first outputs to transition after RESET is released are the SF_D and LCD_E control signals, at around 33 ms. This is why the counter may seem like it is not working in a short simulation. For the purpose of this tutorial, only the DCM signals are monitored to verify that they work correctly.

Adding Signals

To view internal signals during the simulation, you must add them to the Wave window. The ISE Design Suite automatically adds all the top-level ports to the Wave window. Additional signals are displayed in the Signal window based on the selected structure in the Structure window.

There are two basic methods for adding signals to the Simulator Wave window:

- Drag and drop from the Signal/Object window.
- Highlight signals in the Signal/Object window, and select Add > To Wave > Selected Signals.

The following procedure explains how to add additional signals in the design hierarchy. In this tutorial, you will be adding the DCM signals to the waveform.

If you are using ModelSim version 6.0 or higher, all the windows are docked by default. To undock the windows, click the Undock icon.

ď

Figure 5-4: Undock Icon

To add additional signals in the design hierarchy, do the following:

1. In the Structure/Instance window, expand the **uut** hierarchy.

The following figure shows the Structure/Instance window for the VHDL flow. The graphics and the layout of the Structure/Instance window for a schematic or Verilog flow may be different.

nonopaco		
vital timing		
vital primitives		
📕 textio		
🚊 🛒 uut		
🔃 🗾 timer_state		
🕕 🧾 timer_inst		
🕀 🗾 t_preset		
+ m strtstop_debounce		
Ine_228		
	6	
line 73		
std_logic_unsigned		
🧧 std_logic_textio		
🗾 std_logic_arith		-
🧾 std_logic_1164		
🗾 standard		
4		

Figure 5-5: Structure/Instance Window—VHDL flow

- 2. Select **dcm_inst** in the Structure/Instance window. The signals listed in the Signal/ Object window are updated.
- 3. Click and drag **CLKIN_IN** from the Signal/Object window to the Wave window.
- 4. In the Signal/Object window, select the following signals:
 - RST_IN
 - CLKFX_OUT
 - CLK0_OUT
 - LOCKED_OUT

Note: To select multiple signals, hold down the Ctrl key.

- 5. Right-click in the Signal/Object window.
- 6. Select Add > To Wave > Selected Signals.

Adding Dividers

In ModelSim, you can add dividers in the Wave window to make it easier to differentiate the signals. To add a divider called DCM Signals, do the following:

- 1. Right-click anywhere in the signal section of the Wave window. If necessary, undock the window and maximize the window for a larger view of the waveform.
- 2. Select Insert Divider.
- 3. Enter **DCM Signals** in the Divider Name box.
- 4. Click **OK**.
- 5. Click and drag the newly created divider to above the CLKIN_IN signal.

After adding the DCM Signals divider, the waveform will appear as shown in the following figure.

Messages		
 /stopwatch_tb/clk /stopwatch_tb/lap_load /stopwatch_tb/mode /stopwatch_tb/strtstop /stopwatch_tb/lcd_rs /stopwatch_tb/lcd_rs 	0 0 0 1 0 0	
/stopwatch_tb/sf_d DCM Signals	00000000	0000000
 /stopwatch_tb/uut/dcm_inst/clkin_in /stopwatch_tb/uut/dcm_inst/clkin_out /stopwatch_tb/uut/dcm_inst/clkin_out /stopwatch_tb/uut/dcm_inst/locked_out /stopwatch_tb/uut/dcm_inst/locked_out 	0 0 0 1 0	

Figure 5-6: Waveform After Adding DCM Signals Divider

The waveforms have not been drawn for any of the newly added signals. This is because ModelSim did not record the data for these signals. By default, ModelSim records data only for the signals that are added to the Wave window while the simulation is running. After new signals are added to the Wave window, you must rerun the simulation for the desired amount of time.

Rerunning Simulation

To rerun simulation in ModelSim, do the following:

1. Click the Restart Simulation icon.



Figure 5-7: Restart Simulation Icon

2. In the Restart dialog box, click **Restart**.



Figure 5-8: Restart Dialog Box

- 3. At the ModelSim command prompt, enter **run 2000 ns**.
- 4. Press Enter.

VSIM 5> run 2000 ns

Figure 5-9: Entering the Run Command

The simulation runs for 2000 ns. The waveforms for the DCM are now visible in the Wave window.

Analyzing the Signals

The DCM signals can be analyzed to verify that they work as expected. The CLK0_OUT must be 50 MHz and the CLKFX_OUT should be approximately 26 MHz. The DCM outputs are valid only after the LOCKED_OUT signal is high; therefore, the DCM signals are analyzed only after the LOCKED_OUT signal has gone high.

ModelSim enables you to add cursors to measure the distance between signals. To measure the CLK0_OUT, do the following:

- 1. Select **Add > To Wave > Cursor** twice to add two cursors.
- 2. Click and drag one cursor to the first rising edge transition on the CLK0_OUT signal after the LOCKED_OUT signal has gone high.
- 3. Click and drag the second cursor just to the right of the first.
- 4. Click the **Find Next Transition** icon twice to move the cursor to the next rising edge on the CLK0_OUT signal.



Figure 5-10: Find Next Transition Icon

5. Look at the bottom of the waveform for the distance between the two cursors.

The measurement should read 20000 ps. This converts to 50 MHz, which is the input frequency from the test bench, which in turn should be the DCM CLK0 output.

6. Measure CLKFX_OUT using the same steps as above. The measurement should read 38462 ps. This comes out to approximately 26 MHz.

Saving the Simulation

The ModelSim simulator enables you to save the signals list in the Wave window after new signals or stimuli are added, and after simulation is rerun. The saved signals list can easily be opened each time the simulation is started.

To save the signals list, do the following:

- 1. In the Wave window, select File > Save Format.
- 2. In the Save Format dialog box, rename the file name from the default wave.do to dcm_signal.do.
- 3. Click Save.

After restarting the simulation, select **File > Load** in the Wave window to load this file.

Your behavioral simulation is complete. To implement the design, follow the steps in Chapter 6, Design Implementation.

Behavioral Simulation Using ISim

Follow this section of the tutorial if you have skipped the previous section, Behavioral Simulation Using ModelSim.

Now that you have a test bench in your project, you can perform behavioral simulation on the design using ISim. The ISE Design Suite has full integration with ISim. The ISE Design Suite enables ISim to create the work directory, compile the source files, load the design, and perform simulation based on simulation properties.

To select ISim as your project simulator, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, right-click the device line (xc3s700A-4fg484), and select **Design Properties**.
- 2. In the Design Properties dialog box, set the Simulator field to ISim (VHDL/Verilog).

Locating the Simulation Processes

The simulation processes in Project Navigator enable you to run simulation on the design using ISim. To locate the ISim processes, do the following:

- 1. In the View pane of the Project Navigator Design panel, select **Simulation**, and select **Behavioral** from the drop-down list.
- 2. In the Hierarchy pane, select the test bench file (stopwatch_tb).
- 3. In the Processes pane, expand ISim Simulator to view the process hierarchy.

The following simulation processes are available:

• Check Syntax

This process checks for syntax errors in the test bench.

• Simulate Behavioral Model

This process starts the design simulation.

Specifying Simulation Properties

You will perform a behavioral simulation on the stopwatch design after you set process properties for simulation.

Project Navigator allows you to set several ISim properties in addition to the simulation netlist properties. To see the behavioral simulation properties and to modify the properties for this tutorial, do the following:

- In the Hierarchy pane of the Project Navigator Design panel, select the test bench file (stopwatch_tb).
- 2. In the Processes pane, expand **ISim Simulator**, right-click **Simulate Behavioral Model**, and select **Process Properties**.
- 3. In the Process Properties dialog box, set the Property display level to **Advanced**.

This global setting enables you to see all available properties.

Note: For a detailed description of each property available in the Process Property dialog box, click the **Help** button.

- 4. Change the Simulation Run Time to **2000 ns**.
- 5. Click **OK**.

The following figure shows the properties for behavioral simulation.

E	C Process Pr	operties - ISim Properties		×				
	Switch Name	Property Name	Value	^				
	Sincernanio	Use Custom Simulation Command File						
		Custom Simulation Command File						
	-incremental	Incremental Compilation						
	-nodebua	Compile for HDL Debugging		_				
	noocog	Use Custom Project File		=				
	-ori	Custom Project Filename						
	F.)	Run for Specified Time						
		Simulation Run Time	2000 psl					
		Waveform Database Filename	istonwatch th isim beh with					
		Use Custom Waveform Configuration File						
		Custom Waveform Configuration File						
		Other Compiler Options						
	-rangecheck	Value Range Check		~				
	Property display level: Advanced V Display switch names Default							
		OK Cancel	Apply Help					

Figure 5-11: Behavioral Simulation Process Properties

Performing Simulation

After the process properties have been set, you are ready to run ISim to simulate the design. To start the behavioral simulation, double-click **Simulate Behavioral Model**. ISim

creates the work directory, compiles the source files, loads the design, and performs simulation for the time specified.

The majority of this design runs at 100 Hz and would take a significant amount of time to simulate. The first outputs to transition after RESET is released are SF_D and LCD_E at around 33 ms. This is why the counter may seem like it is not working in a short simulation. For the purpose of this tutorial, only the DCM signals are monitored to verify that they work correctly.

Adding Signals

To view signals during the simulation, you must add them to the Waveform window. The ISE Design Suite automatically adds all the top-level ports to the Waveform window. Additional signals are displayed in the Instances and Processes panel. The following procedure explains how to add additional signals in the design hierarchy. For the purpose of this tutorial, add the DCM signals to the waveform.

To add additional signals in the design hierarchy, do the following:

1. In the Instances and Processes panel, expand stopwatch_tb, and expand UUT.

The following figure shows the contents of the Instances and Processes panel for the VHDL flow. The graphics and the layout of the window for a schematic or Verilog flow may be different.

Instance and Process Name	Design Unit Block Type	^
V stopwatch_tb	stopwatch_tb VHDL Entity	
🔻 🚺 υυτ	stopwatch(sto VHDL Entity	
⊳ 📒 t_preset	timer_preset(t VHDL Entity	
⊳ 🚺 Inst_dcm1	dcm1(behavio VHDL Entity	
⊳ 🗐 clk_divider	clk_div_262k(VHDL Entity	
⊳ 🚺 lcd_cntrl_inst	lcd_control(lcd VHDL Entity	
⊳ 🗐 mode_debounce	debounce(beh VHDL Entity	
⊳ 🗐 strtstop_debounce	debounce(beh VHDL Entity	
> 🗐 lap_load_debounce	debounce(beh VHDL Entity	
⊳ 🚺 timer_inst	time_cnt(time VHDL Entity	
⊳ 🗐 timer_state	statmach(beh VHDL Entity	
:252	stopwatch(sto VHDL Process	
	stopwatch_tb VHDL Process	
:82	stopwatch_tb VHDL Process	
🌍 std_logic_1164	std_logic_1164 VHDL Package	
🕥 numeric_std	numeric_std VHDL Package	
🌍 textio	textio VHDL Package	
🌀 vital_timing	vital_timing VHDL Package	
🎯 vital_primitives	vital_primitives VHDL Package	
🕥 std_logic_arith	std_logic_arith VHDL Package	
🌍 std_logic_textio	std_logic_textio VHDL Package	
🌀 std_logic_unsigned	std_logic_unsi VHDL Package	
vcomponents	vcomponents VHDL Package	*
😤 Instances and Processes 🔒	Memory 📔 Source Files	

Figure 5-12: Simulation Hierarchy—VHDL flow

- 2. In the Instances and Processes panel, select Inst_dcm1.
- Click and drag CLKIN_IN from the Simulation Objects window to the Waveform window.
- 4. Select the following signals:
 - RST_IN
 - CLKFX_OUT
 - CLK0_OUT
 - LOCKED_OUT

Note: To select multiple signals, press the **Ctrl** key.

5. Drag all the selected signals to the waveform.

Note: Alternatively, right-click on a selected signal and select Add to Wave Window.

Instances and Processes		++□ & ×	Objects ↔ □ 중 ×						2.000000 us
			Simulation Objects for						
				12	Name	Value	10 us	1 us	2 us
Instance and Process Name	Design Unit	Block Type		. 8	Ta ck	0			
🔻 📳 stopwatch_tb	stopwatch_tb	VHDL Entity	Object Name	, , , , , , , , , , , , , , , , , , , ,	Lap load	0			
🗢 📒 υυτ	stopwatch(sto	VHDL Entity	📙 clkin_in	0	10. mode				
⊳ 🔝 t_preset	timer_preset(t	VHDL Entity	🔚 rst_in		ug mude	v			
🕞 📄 🛛 🕞 🕞 🕞 🕞	dcm1(behavio	VHDL Entity	🔚 clkfx_out	Θ	lig reset	0			
⊳ 🚺 clk_divider	clk_div_262k(VHDL Entity	🔚 clkin_ibufg_out	14	🕼 strtstop	1			
Icd_cntrl_inst	lcd_control(lcd	VHDL Entity	🔚 clk0_out	-	lik icd e	0			
b log mode_debounce	debounce(beh	VHDL Entity	locked_out	1	10. Ind. or				
⊳ 📄 strtstop_debounce	debounce(beh	VHDL Entity	👔 🗓 clkfb_in	1 🐺		U			
⊳ 📒 lap_load_debounce	debounce(beh	VHDL Entity	🛛 🗓 clkfx_buf	1	lig lcd_rw	0			
b imer_inst	time_cnt(time	VHDL Entity	🚺 🗓 clkin_ibufg	1	🕨 😽 sf_d[7:0]	00000000		0000000	
⊳ 🌆 timer_state	statmach(beh	VHDL Entity	🛛 🖓 clk0_buf	1	1 period	20000 ps	200	d0 ps	
Ci :252	stopwatch(sto	VHDL Process	🚺 🗓 gnd_bit	i III CH	10 duty cycle	0 500000	0.50	0000	
:72	stopwatch_tb	VHDL Process			10	0.300000	<u>5.5</u>		1
:82	stopwatch_tb	VHDL Process		21	ut rst_in	0			
🎯 std_logic_1164	std_logic_1164	VHDL Package		204	🖓 clkfx_out	0			
🎯 numeric_std	numeric_std	VHDL Package			🖫 ck0 out	0			
🎯 textio	textio	VHDL Package			10 locked out	,			
🎯 vital_timing	vital_timing	VHDL Package			d@ locksd_odc	±			
vital_primitives	vital_primitives	VHDL Package							
🎯 std_logic_arith	std_logic_arith	VHDL Package						1	
🧐 std_logic_textio	std_logic_textio	VHDL Package					X1: 2.000000 us		
std_logic_unsigned	std_logic_unsi	VHDL Package							
(S) vcomponents	vcomponents	VHDL Package 🔛	1	_	<u><</u>	< >	<		
🟯 Instances and Processes 🗎 🕅	Memory 📔 Sourc	e Files	<	202		Default.wcfg*	×		

Figure 5-13: Adding Signals to the Simulation Waveform

Notice that the waveforms have not been drawn for the newly added signals. This is because ISim did not record the data for these signals. By default, ISim records data only for the signals that are added to the waveform window while the simulation is running. Therefore, when new signals are added to the waveform window, you must rerun the simulation for the desired amount of time.

Rerunning Simulation

To rerun the simulation in ISim, do the following:

1. Click the **Restart Simulation** icon.



Figure 5-14: ISim Restart Simulation Icon

2. At the ISim command prompt in the Console, enter **run 2000 ns** and press **Enter**.

The simulation runs for 2000 ns. The waveforms for the DCM are now visible in the Waveform window.

Analyzing the Signals

Now the DCM signals can be analyzed to verify that they work as expected. The CLK0_OUT must be 50 MHz and the CLKFX_OUT should be approximately 26 MHz. The DCM outputs are valid only after the LOCKED_OUT signal is high; therefore, the DCM signals are analyzed only after the LOCKED_OUT signal has gone high.

ISim can add markers to measure the distance between signals. To measure the CLK0_OUT, do the following:

- 1. If necessary, zoom in on the waveform using the local Zoom toolbar buttons.
- 2. In the local waveform viewer toolbar, click the Snap to Transition toolbar button.

ζſι

Figure 5-15: Snap to Transition Toolbar Button

- 3. Click on the first rising edge transition on the CLK0_OUT signal after the LOCKED_OUT signal has gone high, then drag the cursor to the right to the next rising edge transition of the CLK0_OUT signal.
- 4. At the bottom of the waveform window, the start point time, end point time, and delta times are shown. The delta should read 20.0 ns. This converts to 50 MHz which is the input frequency from the test bench, which in turn is the DCM CLK0 output.



Figure 5-16: Waveform Viewer Displaying Time Between Transitions

5. Measure CLKFX_OUT using the same steps as above. The measurement should read 38.5 ns. This equals approximately 26 MHz.

Your behavioral simulation is complete. To implement the design, follow the steps in Chapter 6, Design Implementation.





Chapter 6

Design Implementation

Overview of Design Implementation

Design implementation is the process of translating, mapping, placing, routing, and generating a bitstream file for your design. The design implementation tools are embedded in the Xilinx® ISE® Design Suite for easy access and project management.

This chapter is the first in the Implementation-Only Flow and is a subsequent chapter for the HDL Design Flow and the Schematic Design Flow.

This chapter demonstrates the ISE Design Suite implementation flow. The front-end design has already been compiled in an EDA interface tool. For details about compiling the design, see Chapter 3, HDL-Based Design or Chapter 4, Schematic-Based Design. In this chapter, you will be passing a synthesized netlist (EDN, NGC) from the front-end tool to the back-end design implementation tools, and you will be incorporating placement constraints through a User Constraints File (UCF). You will also add timing constraints as well as additional placement constraints.

Getting Started

The tutorial design emulates a runner's stopwatch with actual and lap times. There are five inputs to the system: CLK, RESET, LAP_LOAD, MODE, and SRTSTP. This system generates a traditional stopwatch with lap times and a traditional timer on an LCD display.

Continuing from Design Entry

If you have followed the tutorial using either the HDL design flow or the schematic design flow, you have created a project, completed source files, and synthesized the design.

If you do not have a stopwatch.ucf constraint file in your project, create one as follows:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select the top-level source file stopwatch.
- 2. Select **Project > New Source**.
- 3. Select Implementation Constraints File.
- 4. Enter **stopwatch.ucf** as the file name.
- 5. Click Next.
- 6. Click **Finish**.

With a UCF in the project, you are now ready to begin this chapter. Skip to the Specifying Options section.

Starting from Design Implementation

The tutorial project files are provided with the ISE Design Suite <u>Tutorials</u> available from the Xilinx website. Download the pre-synthesized design files.

After you have downloaded the tutorial project files from the web, unzip the tutorial projects into the c:\xilinx_tutorial directory, replacing any existing files in that directory.

When you unzip the tutorial project files into c:\xilinx_tutorial, the directory wtut_edif is created within c:\xilinx_tutorial, and the tutorial files are copied into the newly-created directory.

The following table lists the locations of tutorial source files.

Table 6-1: Required Tutorial Files

File Name	Description
<pre>stopwatch.edn,stopwatch.edf or stopwatch.ngc</pre>	Input netlist file (EDIF)
timer_preset.ngc	Timer netlist file (NGC)
stopwatch.ucf	User Constraints File

Note: The completed directories contain the finished source files. Do not overwrite any files in the completed directories.

This tutorial assumes that the files are unzipped under c:\xilinx_tutorial, but you can unzip the source files into any directory with read/write permissions. If you unzip the files into a different location, substitute your project path in the procedures that follow.

- 1. Open the ISE Design Suite using one of the following methods:
 - On a workstation, enter **ise**.
 - On a PC, select Start > Programs > Xilinx ISE Design Suite > ISE Design Tools > Project Navigator.
- 2. Create a new project, and add the EDIF netlist as follows:
 - a. Select File > New Project.
 - b. In the Name field, enter **wtut_edif**.
 - c. Select **EDIF** for the Top-Level Source Type, and click **Next**.
 - d. Select stopwatch.edf or stopwatch.edn for the Input Design file.
 - e. Select **stopwatch.ucf** for the Constraints file, and click **Next**.
 - f. Select the following values:
 - Family: Spartan3A and Spartan3AN
 - Device: XC3S700A
 - Package: **FG484**
 - Speed: -4
 - g. Click Next., then Finish to complete the project creation.

Note: If the timer_preset.ngc file is not in the project directory, copy it from the extracted ZIP file.

Specifying Options

This section describes how to set process properties for design implementation. The implementation properties control how the software maps, places, routes, and optimizes a design.

To set the implementation properties for this tutorial, do the following:

- 1. In the View pane of the Project Navigator Design panel, select Implementation.
- 2. In the Hierarchy pane, select the stopwatch top-level file.
- 3. In the Processes pane, right-click the **Implement Design** process, and select **Process Properties**.

The Process Properties dialog box provides access to the Translate, Map, Place and Route, and Timing Report properties. In the left pane of the dialog box, you can click the different categories to set properties for each design implementation phase.

4. Ensure that you have set the Property display level to Advanced.

This global setting enables you to see all available properties.

- 5. Click the Place & Route Properties category.
- 6. Change the Place & Route Effort Level (Overall) to High.

This option increases the overall effort level of Place and Route during implementation.

Process Properties - Place & R	oute Properties	X
Category	Property Name	Value
Translate Properties	Place And Route Mode	Normal Place and Route
Map Properties Place & Route Properties	Place & Route Effort Level (Overall)	High 🗸
Post-Map Static Timing Report Prope	Placer Effort Level (Overrides Overall Level)	None
 Post-Place & Route Static Timing Rep Simulation Model Properties 	Router Effort Level (Overrides Overall Level)	None
Sinddormoder reperces	Extra Effort (Highest PAR level only)	None
	Starting Placer Cost Table (1-100)	1
	Ignore User Timing Constraints	
	Timing Mode	Performance Evaluation 🗸
	Use Bonded I/Os	
	Generate Asynchronous Delay Report	
	Generate Clock Region Report	
	Generate Post-Place & Route Simulation Model	
	Generate Post-Place & Route Power Report	
	Power Reduction	
	Power Activity File	
	Other Place & Route Command Line Options	
<u><</u>	Property display level: Advance	Image: Display switch names Default Cancel Apply Help

Figure 6-1: Place and Route Properties

7. Click **OK** to exit the Process Properties dialog box.

Creating Timing Constraints

The User Constraints File (UCF) is a text file and can be edited directly with a text editor. To facilitate editing of this file, graphical tools are provided to create and edit constraints. The Constraints Editor and PlanAheadTM tool are graphical tools that enable you to enter timing and I/O and placement constraints.

To launch the Constraints Editor, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select the stopwatch module.
- 2. In the Processes pane, expand **User Constraints**, and double-click **Create Timing Constraints**.



Figure 6-2: Create Timing Constraints Process

This automatically runs the Translate step, which is discussed in the following section. Then, the Constraints Editor opens.

Translating the Design

The ISE Design Suite manages the files created during implementation. The ISE design tools use the settings that you specified in the Process Properties dialog box. This gives you complete control over how a design is processed. Typically, you set your properties first. You then run through the entire flow by running the Implement Design process. The Implement Design process includes the three sub-processes: Translate, Map, and Place and Route. You can simply run the Implement Design process to automate the running of all three sub-processes, or you can run the sub-processes individually. In this tutorial you will run the sub-processes individually to more easily see and understand each step.

During translation, the NGDBuild program performs the following functions:

- Converts input design netlists and writes results to a single merged NGD netlist. The merged netlist describes the logic in the design as well as any location and timing constraints.
- Performs timing specification and logical design rule checks.
- Adds constraints from the User Constraints File (UCF) to the merged netlist.

Using the Constraints Editor

When you run the Create Timing Constraints process, Translate is automatically run and the ISE Design Suite launches the Constraints Editor.

The Constraints Editor enables you to do the following:

- Edit constraints previously defined in a UCF file.
- Add new constraints to your design.

Following are input files to the Constraints Editor:

• NGD (Native Generic Database) File

The NGD file serves as input to the mapper, which then outputs the physical design database, an NCD (Native Circuit Description) file.

• Corresponding UCF (User Constraint File)

All UCF files that are part of the ISE project are passed to Constraints Editor.

Multiple UCF files are supported in ISE projects. All constraint files in the project are read by the Constraints Editor, and constraints that you edit are updated in the originating constraint file. New constraints are written to the UCF file specified in Constraints Editor.

The Translate step (NGDBuild) uses the UCF file, along with design source netlists, to produce a newer NGD file, which incorporates the changes made. The Map program (the next section in the design flow) then reads the NGD. In this design, the stopwatch.ngd and stopwatch.ucf files are automatically read into the Constraints Editor.

In the following section, a PERIOD, Global OFFSET IN, Global OFFSET OUT, and TIMEGRP OFFSET IN constraint will be created and written in the UCF and used during implementation. The Clock Domains branch of the Timing Constraints tab automatically displays all the clock nets in your design, and enables you to define the associated period, pad to setup, and clock to pad values. Note that many of the internal names will vary depending on the design flow and synthesis tool used. The following figure shows the Constraints Editor.

🔯 File Edit View Project Source Process Tools	Window Layout Help										_ 8 :
※ ある X 回 2 ※ ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ●		🔊 i 🖻 🗆 🗆	🗅 i 🎤 K? i	🕨 🗵 📌	1 🖓						
Timing Constraints ↔											
Source Constraint File				Create by dir	iming Constraints ect entry or right	s for Clock D click to ope	Oomains (PERIOD) :n context menu				
stopwatch.ucf	TIMESPEC Name * 🔺	Clock Time Name	Clock Net *	Period	Duty Cycle	Edge	Reference TIMESPEC	Factor	Phase Shift	Input Jitter	Source
Show constraints from specified file only	1										
 Show constraints from all files 											
Save New Constraints To File											
stopwatch.ucf											
Constraint Type											
UCF Constraints Timing Constraints				*****							
Clock Domains	Validate Constraints Click "	alidate Constraints" bu	tton after direct er	ntry of any ch	ange						
Outputs											
Operating Conditions					Unconstr	ained Clocks	5				
Group Constraints Arrow Miscellaneous	1 dk										
	2 clk_divider/div_2621441										
	Filter:										Find
🗺 Start 🔯 Timing 🕫 Design 🜓 File (🕨 🗵	Design Summa	ry (Translated)	× 2		Timing	Constraints	×				

Figure 6-3: Constraints Editor in Project Navigator—Clock Domains

In the Constraints Editor, edit the constraints as follows:

- 1. Double-click the row containing the **clk** signal in the Unconstrained Clocks table.
- 2. In the Clock Period dialog box, verify that **Specify Time** is selected for the Clock Signal Definition.

This enables you to define an explicit period for the clock.

- 3. Enter a value of **7.0** in the Time field.
- 4. Verify that **ns** is selected from the Units drop-down list.



Figure 6-4: PERIOD Constraint Values

- 5. For the Input Jitter section, enter a value of **60** in the Time field.
- 6. Verify that **ps** is selected from the Units drop-down list.

Input jitter:	60	Units:	ps	*
Priority:				

Figure 6-5: INPUT JITTER Constraint Value

7. Click **OK**.

The period constraint is displayed in the constraint table at the top of the window. The period cell is updated with the global clock period constraint that you just defined (with a default 50% duty cycle).

- 8. In the Constraint Type tree view, select the **Inputs** branch under Timing Constraints.
- 9. Double-click the **clk** signal in the Global OFFSET IN Constraint table to bring up the Create Setup Time (OFFSET IN) wizard.
- 10. Keep the default values on the first page of the screen, and click Next.



Figure 6-6: Offset In Constraint—Page 1

- 11. In the External setup time (offset in) field, enter **6** ns.
- 12. In the Data valid duration field, enter **6 ns**.

This creates a Global OFFSET IN constraint for the CLK signal.

reate Setup Time (OFFSET I	4)	?
lock pad net and period		System Synchronous SDR Rising
Input clock pad net:		PERIOD (ns)
:lk	×	HIGH (ns)
Input clock period information:		
Clock Name : clk	Create/Edit	Clock
Duty Cycle : 50%		RISING OFFSET IN
		Data X Rising Data X X
		RISING VALID
nput pad timegroup/net		
(nput pad net: 🛛 💙 clk	~	
	(1112)	
	Create	
lising edge constraints		Input Pad Group
External setup time (offset in):	Unit:	The input Pad Group lists the defined timegroups which contain pad nets.
6	ns 😽	• This input Red Group is used to limit the score of the vision and falling
ata valid duration:	Unit:	constraints to only those data pins defined in the Pad Group.
6	ns 💙	
nout register timegroup:		 A new Pad Group may be defined by selecting the Create New Pad Group hutton.
······································	V Create	
		Rising Constraint Parameters
alling edge constraints		• The rising edge constraint applies to all rising edge registers and the clock and
External setup time (offset in):	Unit:	data relationship is specified in reference to the rising clock edge.
	ms 🗡	• Rising External Setup (OFFSET IN) is the time before the rising clock edge when
		the rising data becomes valid
ata valid duration:	Unit:	the rising data becomes valid.
ata valid duration:	Unit:	Rising VALID is the duration of the data valid window for the rising data
Pata valid duration:	Unit:	Rising VALID is the duration of the data valid window for the rising data.
Pata valid duration:	Unit: ms V	Rising Value becomes value. Rising Value is the duration of the data valid window for the rising data. The Input Register Group is used to limit the scope of the constraint to a subset of the king adapt societary.
ata valid duration: nput register timegroup:	Unit: ms v Create	Rising VALID is the duration of the data valid window for the rising data. The Input Register Group is used to limit the scope of the constraint to a subset of the rising edge registers.
ata valid duration: nput register timegroup:	Unit: ms V Create	 Rising VALID is the duration of the data valid window for the rising data. The Input Register Group is used to limit the scope of the constraint to a subset of the rising edge registers.

Figure 6-7: Offset In Constraint—Page 2

- 14. In the Constraint Type tree view, select the **Outputs** branch under Timing Constraints.
- 15. In the Global OFFSET OUT Constraint table, double-click the **clk** signal.
- 16. In the Create Clock to Pad (OFFSET OUT) dialog box, enter a value of **38 ns** in the External clock to pad (offset out) field.

This creates a Global OFFSET OUT constraint for the CLK signal.

17. Click **OK**.

Figure 6-8: Offset Out Constraint

- 18. In the Unconstrained Output Ports table, select the **sf_d<0>** through **sf_d<7>** signals using **Shift+Click** to select multiple rows.
- 19. Right-click, and select **Create Time Group**.

20. In the Create Time Group dialog, type **display_grp** for the Time group name, then click **OK**.

🚾 Create Time	Group 🔀
Time group name	display_grp
Selected ports	
sf_d<0> sf_d<1> sf_d<2> sf_d<3> sf_d<4> sf_d<4> sf_d<5> sf_d<6> sf_d<6> sf_d<7>	
ОК	Cancel Help

Figure 6-9: Creating a Time Group

- 21. When asked if you would like to create an offset constraint, click **OK**.
- 22. In the External clock to pad (offset out) field, enter **32 ns**.

Create Clock to Pad (OFFSET OUT)	
Clock pad net and period SDR (both edges) DDR * Output clock pad net: Ik	ClkIn
* Output clock period information: Clock Name : clk Period : 7 ns Duty Cycle : 50%	
Output pad timegroup/net	
Output pad timegroup: 💙 display_grp	
Create	Output Interface Detail:
Rising edge constraints * External clock to pad (offset out): Units: 22	The Single Data Rate and Dual Data Rate determine the output interface type. The Output clock Pad Net is the clock pet used to triager the outgoing data.
Output clear reference pip:	
<pre> </pre> <pre></pre> <pre>Codpat show reference pint </pre> <pre></pre> <pre><td> The optional Output pad timegroup limits the scope of the OFFSET OUT constraint to only those data pins defined in the PAD timegroup. </td></pre>	 The optional Output pad timegroup limits the scope of the OFFSET OUT constraint to only those data pins defined in the PAD timegroup.
Output register timegroup:	• A new Pad Group may be defined by selecting the Create New Pad Group button.
Falling edge constraints	Rising Constraint Parameters:
External clock to pad (offset out): Units: T Output skew reference pin:	 The optional Rising Clock-to-Output (OFFSET OUT) is the time from the rising clock edge at the input pin of the FPGA until data becomes valid at the output pin of the FPGA. For source-synchronous designs, the OFFSET OUT value can be left blank and only a skew remoti will be generated.
<default></default>	 The Output Skew Reference Pin is the reference signal in which the skew of all bits in the bus will be reported against.
Create	The optional Output Register Timegroup is used to limit the scope of the
	OK Close Create Help

23. Click **OK**.

Figure 6-10: Clock to Pad Dialog Box

24. Select **File > Save** in the Constraints Editor.

The changes are now saved in the stopwatch.ucf file in your current working directory.

25. To close the Constraints Editor, select **File > Close**.

Assigning I/O Locations Using the PlanAhead Tool

Use the PlanAhead tool to add and edit the pin locations and area group constraints defined in the NGD file. The PlanAhead tool writes the constraints to the project UCF file. In the case of multiple UCF files in the project, you will be asked to specify the constraint file in which to write new constraints. If you modify existing constraints, the constraints will be written to the constraint file in which they originated. The PlanAhead tool also provides device-specific design rule checks to aid you in pin planning and placement.

The Translate step uses the design UCF file, along with the design source netlists, to produce a newer NGD file. The NGD file incorporates the changes made in the design and the UCF file from the previous section.

To create IOB assignments for several signals:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select the stopwatch module.
- 2. In the Processes pane, expand User Constraints, and double-click I/O Pin Planning (PlanAhead) Post-Synthesis.

I/O pin planning can be performed either pre- or post-synthesis. Whenever possible, it is recommended that the process be run post-synthesis, because the design then contains information needed for I/O- and clock-related design rule checks performed by the PlanAhead tool.



Figure 6-11: I/O Pin Planning—Post-Synthesis

This process launches the PlanAhead tool. If the design has not yet completed synthesis, Project Navigator will first automatically run synthesis before launching the PlanAhead tool for I/O pin planning.

The Welcome to PlanAhead tool screen provides links to detailed documentation, tutorials, and other training material to help you learn more about the PlanAhead tool. The tutorials provide an overview of the use and capabilities of the PlanAhead tool.

File Edit: View Tools Window Sele	ect Layout	Help											
■ 10 UF× 例 東 条 氷	🖪 🥝 🖪	i 🎯 🛄											
Netlist Design - constrs_1 - xc3s7	00afg484-4							1. ··· \	and the second	÷ ;;.	in the		
Netlot	Joad_debounc	e or)	х				▶ <mark>일</mark> 및 유 K 한 <mark>2008 1 = 1 = 1 = 2 = 2 = 2 = 2 = 2 = 2 = 2 =</mark>						
🕅 Netlist 📕 Physical Constraints 🖉	Timing Const	traints 🔤 Clock Region	ns R										
Properties		ن ہے ہ ہ	× U V V V V V V V V V V V V V V V V V V	×				evice ×					
I/O Ports													900×
Name □ □ All ports (16) □ □ □ \$ f_d (8) □ □ \$ Scalar ports (8) □ □ \$ ck	Dir r Output Input	Neg Diff Pair Site	Bank I/O Std 2 LVCMOS25 0 LVCMOS25	Drive Strength Slew Type 12 SLOW 12 SLOW	Pull Type								
D lap_load	Input Output		LVCMO525 LVCMO525	12 SLOW 12 SLOW									×
D I/O Ports D Package Pins													

3. Click **Close** on the Welcome dialog to proceed in the PlanAhead tool.

Figure 6-12: PlanAhead Tool for I/O Planning

- 4. In the I/O Ports tab, expand the **Scalar Ports** tree under All ports. You will now create pin assignments for the lcd_e, lcd_rs, and lcd_rw I/O signals.
- 5. Locate the **lcd_e** output signal, then click and drag it into the Package view and drop it on the **AB4** pin location.





- 6. Repeat the previous step to place the following additional output pins:
 - LCD_RS: Y14
 - LCD_RW: W13

Alternatively, you can type the location in the Site field in the I/O Port Properties tab when the I/O signal is selected.

I/O Port Proper	rties 무 🗆 급 🗡
4 🔶 🔯 🖡	
·	
Name:	lcd_rs
Direction:	Output
Site:	Y14 Fixed
Package Pin:	₽ ¥14
Instance:	Icd_rs_OBUF
Net:	📑 lcd_rs 🗸
General Co	onfigure

Figure 6-14: Assigning I/O Pins Using I/O Port Properties

- 7. Using either the drag and drop or Port Properties method, place the following input signals onto the appropriate I/O pin locations:
 - LAP_LOAD: T16
 - RESET: U15
 - MODE: T14
 - STRTSTOP: T15
- 8. After the pins are locked down, select **File > Save Project**. The changes are saved in the stopwatch.ucf file.
- 9. To exit the PlanAhead tool, select **File > Exit**.

Mapping the Design

Now that the implementation properties and constraints have been defined, continue with the implementation of the design as follows:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select the stopwatch module.
- 2. In the Processes pane, expand Implement Design, and double-click Map.

If the Translate process is not up-to-date, Project Navigator automatically runs that process as well.

The design is mapped into CLBs and IOBs. Map performs the following functions:

- Allocates CLB and IOB resources for all basic logic elements in the design.
- Processes all location and timing constraints, performs target device optimizations, and runs a design rule check on the resulting mapped netlist.

Each step generates its own report as shown in the following table.

Table 6-2: Reports Generated by Translate and Map

Report	Description
Translation Report	Includes warning and error messages from the translation process.
Map Report	Includes information about how the target device resources are allocated, references to trimmed logic, and device utilization.
All NGDBuild and Map Reports	For detailed information on the Map reports, refer to the <i>Command Line Tools User Guide</i> (<i>UG628</i>).

To view a report, do the following:

1. In the Processes pane of the Project Navigator Design panel, double-click **Design Summary/Reports**.



Figure 6-15: Opening the Design Summary/Reports

0	Design Overview	stopwatch Project Status (03/30/2010 - 10:46:42)									
	IOB Properties	Project File:	wtut_vhd.xise Parser Errors:				N	o Errors			
G	Module Level Utilization	Module Name:	stopwatch			Implen	nentation Stat	e: M	lapped		
Θ	Timing Constraints	Target Device:	xc3s700a-4frr484				Frrors:		No Errors		
¢5	Clock Report	Product Version:	ISE 12.1				• Warnings:		Warnings (6 ne	(we	
	- 🚮 Static Timing	Design Goal:	Balanced			Routing Results:		-c.			
1	Errors and Warnings Dercer Messages	Design Strategy:	Viliny Default (up)	ocked)		Timing Constraints:					
-	- Synthesis Messages	Environment:	System Settings	<u>ocnody</u>			Final Timing Se	ore:			
(4)	Translation Messages	entri onnenc.	<u>System security</u>			-rinar nining SCORE.					
	Map Messages Place and Route Messages										
	Timing Messages			Devic	e Utilization	Summa	ary			6	
	— 📄 Bitgen Messages	Logic Utilization			Used	Avai	ilable	Utilization	Note(s)		
	All Implementation Messages Detailed Reports	Number of Slice Flip Flops			22	29	11,776	1%	>		
	- i Synthesis Report	Number of 4 input LUTs			37	71	11,776	3%	,		
	Translation Report	Number of occupied Slices			28	35	5,888	4%	,		
	Place and Route Report	Number of Slices containing only related logic			28	35	285	100%	,		
	— 🛅 Post-PAR Static Timing Report	Number of Slices containing unrelated logic				0	285	0%	,		
	Power Report	Total Number of 4 input LUTs			44	13	11,776	3%	,		
	Secondary Reports	Number used as logic			37	71					
	🖵 📄 ISIM Simulator Log	Number used as a route-thru			7	72					
		Number of bonded IOBs			1	16	372	4%	,		
		Number of BUFGMUXs				3	24	12%	,		
		Number of DCMs				1	8	12%	,		
	Design Properties	Average Fanout of Non-Clock Net:	5		3.4	13					
	Enable Message Filtering										
	Optional Design Summary Contents	Printi d Principal de la constante de la consta									
	Show Failing Constraints	Dan auk Nama	Chabur	Carro	Jecalleu Kep	JUILS	Emana	Warnia an	Tafaa		
	Show Warnings Show Errors	Support Name	Current	Mon M	accu	\$ 2010	0	E Warnings (E nami	4 Infor	(4 5000)	
		Translation Depart	Current	Tuo Ma	a 2922.40.00	2010	0	1 Warnings (1 now)	1 Tofo /	1 pour)	
		Man Deport	Current	Tue Ma	= 30 10,40,29	2010	0		E Infor	(E pow)	
		Place and Daute Depart	Currenc	TUE Me	ar 30 10:46:41	2010	U	U	<u>o inros</u>	(5 new)	
		Place and Route Report	_				_				
		Power Report									
		Post-PAK Static Timing Report									
		Bitgen Report									
Σ	Design Summary	(Mapped)	×								

The following figure shows the Design Summary/Report Viewer.

Figure 6-16: Design Summary/Report Viewer

- 2. In the left pane of the Design Summary/Report Viewer, select a report such as the **Translation Report** or **Map Report** in the Detailed Reports section.
- 3. Review the report.

The Design Summary also provides a summary of the design results, and a list of all of the messages (Errors, Warnings, Info) generated by the implementation run.

Using Timing Analysis to Evaluate Block Delays After Mapping

After the design is mapped, evaluate the Logic Level details in the Post-Map Static Timing Report to evaluate the logical paths in the design. Evaluation verifies that block delays are reasonable given the design specifications. Because the design is not yet placed and routed, actual routing delay information is not available. The timing report describes the logical block delays and estimated routing delays. The net delays provided are based on an optimal distance between blocks (also referred to as "unplaced floors").

Estimating Timing Goals with the 50/50 Rule

For a preliminary indication of how realistic your timing goals are, evaluate the design after the map stage. A rough guideline (known as the "50/50 rule") specifies that the block delays in any single path make up approximately 50% of the total path delay after the design is routed. For example, a path with 10 ns of block delay should meet a 20 ns timing constraint after it is placed and routed.

If your design is extremely dense, the Post-Map Static Timing Report provides a summary analysis of your timing constraints based on block delays and estimates of route delays. This analysis can help to determine if your timing constraints are going to be met. This report is produced after Map and prior to Place and Route (PAR).

Reviewing the Post-Map Static Timing Report

Use the Post-Map Static Timing Report to determine timing violations that may occur prior to running PAR. Because you defined timing constraints for the stopwatch design, the timing report will display the path for each of the timing constraints.

To view the Post-Map Static Timing Report and review the PERIOD Constraints that were entered earlier, do the following:

- 1. In the Processes pane, expand **Map**, and double-click **Generate Post-Map Static Timing**.
- 2. To open the Post-Map Static Timing Report, double-click **Analyze Post-Map Static Timing**.



Figure 6-17: Post-Map Static Timing Report Process

Timing Analyzer automatically launches and displays the report.

3. In the Report Navigation pane, select the **TS_inst_dcm1_CLKFX_BUF** timing constraint.



Figure 6-18: Selecting Post-Map Static Timing Constraint

The Workspace shows the report for the selected constraint. At the top of this report, you will find the selected period constraint and the minimum period obtained by the tools after mapping. By default, only three paths per timing constraint are shown. Selecting one of the three paths allows you to see a breakdown of the path which contains the component and routing delays.

Notice that the report displays the percentage of logic versus the percentage of routing at the end of each path (e.g. 88.0% logic, 12.0% route). The unplaced floors listed are estimates (indicated by the letter "e" next to the net delay) based on optimal placement of blocks.

4. After viewing the report, close the Timing Analyzer by selecting **File > Close**.

Note: Even if you do not generate a timing report, PAR still processes a design based on the relationship between the block delays, floors, and timing specifications for the design. For example, if a PERIOD constraint of **8 ns** is specified for a path, and there are block delays of **7 ns** and unplaced floor net delays of **3 ns**, PAR stops and generates an error message. In this example, PAR fails because it determines that the total delay (**10 ns**) is greater than the constraint placed on the design (**8 ns**). The Post-Map Static Timing Report will list any pre-PAR timing violations.

Placing and Routing the Design

After the mapped design is evaluated, the design can be placed and routed. One of two place-and-route algorithms is performed during the Place and Route (PAR) process:

• Timing-Driven PAR

PAR is run with the timing constraints specified in the input netlist, the constraints file, or both.

• Non-Timing-Driven PAR

PAR is run, ignoring all timing constraints.

Because you defined timing constraints earlier in this chapter, the Place and Route (PAR) process performs timing-driven placement and routing.

To run Place and Route, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select the stopwatch module.
- 2. In the Processes pane, expand Implement Design, and double-click Place & Route.

The Place and Route process generates the reports shown in the following table.

Table 0.0. Thepoints deficit decided by TAT	Table 6-3:	Reports	Generated by	y PAR
---------------------------------------------	------------	---------	--------------	-------

Report	Description
Place and Route Report	Provides a device utilization and delay summary. Use this report to verify that the design successfully routed and that all timing constraints were met.
Asynchronous Delay Report	Lists all nets in the design and the delays of all loads on the net.
All PAR Reports	For detailed information on the PAR reports, refer to the <i>Command Line Tools User Guide</i> (UG628).

Note: Additional, optional Place and Route reports can also be generated by enabling their creation in the Place and Route process properties. When these reports are created, they will appear in the Design Summary in the Secondary Reports section.
To review the reports that are generated after the Place and Route process is completed, do the following:

- 1. In the Processes pane of the Project Navigator Design panel, double-click **Design Summary/Reports**.
- 2. In the left pane of the Design Summary/Report Viewer, select the **Place and Route Report** in the Detailed Reports section.

The following figure shows the Place and Route Report in the Design Summary/ Report Viewer.

-	🖮 - Design Overview		~
0	– 📄 Summary		
0	 IOB Properties 	Constraints file: stonwatch ncf	
G	Module Level Utilization	"stervetsk" is en NCD wersien 2.2. dewise w	22700e perkers fr/94 speed 4
\bigcirc	 Timing Constraints 	"Stopwatch" is an NCD, version 5.2, device x	cos/oba, package 19404, speed -4
-	- Pinout Report		
ç	Clock Report	Initializing temperature to 85.000 Celsius. (de	fault - Range: 0.000 to 85.000 Celsius)
HTHE	Static Timing	Initializing voltage to 1.140 Volts. (default -	Range: 1.140 to 1.260 Volts)
	Errors and Warnings		
38	Synthesis Messages	WARNING: Timing: 3224 - The clock clk associated	with OFFSET = IN 6 ns VALID 6 ns BEFORE COMP
	 Translation Messages 	"clk" "RISING"; does not	
(A)	Map Messages	clock any registered input components.	
	Place and Route Messages	WARNING: Timing: 3225 - Timing constraint OFFSET	= IN 6 ns VALID 6 ns BEFORE COMP "clk"
	Timing Messages	"RISING": ignored during timing	
	- Bitgen Messages	analmeje	
	All Current Messages	INFO, Timing, 2286 Interpreting Constraints for	nd and regulated. For more information, gas the
	Detailed Reports	TAT Blasse	nu anu resorveu. For more informacion, see che
	Synthesis Report	isi report. Fiease	
	- 📄 Translation Report	consult the Xilinx Command Line loois User G	uide for information on generating a 151
	Map Report	report.	
	Place and Route Report		
	Post-PAR Static Timing Report	Device speed data version: "PRODUCTION 1.41 20	09-03-03".
	- Power Report		
	- Bitgen Report		
	Secondary Reports	Design Summary Report:	
	Post-Map Static Timing Report		
		Number of External IOBs	16 out of 372 4%
		Number of External Input IOBs	5
		Number of Pressons 1 Tourse TRUP-	-

Figure 6-19: Place and Route Report

Using FPGA Editor to Verify the Place and Route

Use the FPGA Editor to display and configure Field Programmable Gate Arrays (FPGAs).

The FPGA Editor reads and writes Native Circuit Description (NCD) files, macro files (NMC) and Physical Constraints Files (PCF).

Use FPGA Editor to do the following:

- Place and route critical components before running the automatic Place and Route tools.
- Finish placement and routing if the routing program does not completely route your design.
- Add probes to your design to examine the signal states of the targeted device. Probes are used to route the value of internal nets to an IOB (Input/Output Block) for analysis during debugging of a device.
- Run the BitGen program and download the resulting bitstream file to the targeted device.
- View and change the nets connected to the capture units of an Integrated Logic Analyzer (ILA) core in your design.

To view the actual design layout of the FPGA, do the following:

1. In the Processes pane of the Project Navigator Design panel, expand **Place & Route**, and double-click **View/Edit Routed Design (FPGA Editor)**.





2. In FPGA Editor, change the List Window from All Components to **All Nets**. This enables you to view all of the possible nets in the design.

All Ne	ts			
All Ne	ts			
Route Unrou Power Zero-p All Cor Place Unpla Comp All Har Place Unpla All Har Layer	d Nets ted Nets Nets mponents d Components ced Component onent Groups d Macros d Hard Macros d Hard Macros d Macro Extern s	s os al Pins		
Paths 7	N21	2	2	I no color
8	address<0>	28	?	no color
9	address<1>	23	?	no color
10	address<2>	24	2	no color
1000		121	100	

Figure 6-21: List Window in FPGA Editor



3. Select the **clk_26214k** (Clock) net to see the fanout of the clock net.

Figure 6-22: Clock Net

4. To exit FPGA Editor, select **File > Exit**.

Evaluating Post-Layout Timing

After the design is placed and routed, you can analyze the post-Place and Route timing results to verify how the design performs against your specified timing goals.

There are multiple ways in which you can analyze timing:

- View the Post-Place and Route Static Timing Report.
- Use the PlanAhead tool for post-Place and Route timing analysis.
- Use hyperlinks in the Design Summary to analyze individual timing constraints.

Viewing the Post-Place and Route Static Timing Report

This report evaluates the logical block delays and the routing delays. The net delays are reported as actual routing delays after the Place and Route process. To display this report, do the following:

1. In the upper left pane of the Design Summary/Report Viewer, select **Static Timing** in the Design Overview section.

Note: Alternatively, you can run the Analyze Post-Place & Route Static Timing process from the Processes pane. Expand Implement Design > Place & Route > Generate Post-Place & Route Static Timing to access this process.

2. The Timing Report opens in Timing Analyzer.

Following is a summary of the post-Place and Route Static Timing Report for the stopwatch design:

• The minimum period value increased due to the actual routing delays.

The post-Map timing report showed logic delays contributed to 80% to 90% of the minimum period attained. The post-layout report indicates that the logical delay value now equals between 30% and 40% of the period. The total unplaced floors estimate changed as well.

- The post-layout result does not necessarily follow the 50/50 rule previously described, because the worst-case path primarily includes component delays.
- For some hard-to-meet timing constraints, the worst-case path is mainly made up of logic delay. Because total routing delay makes up only a small percentage of the total path delay spread out across two or three nets, expecting the timing of these paths to be reduced any further is unrealistic. In general, you can reduce excessive block delays and improve design performance by decreasing the number of logic levels in the design.

Analyzing the Design using the PlanAhead Tool

The PlanAhead tool can be used to perform post-layout design analysis. Graphical layout analysis and timing path viewing, as well as floorplanning can be performed to both analyze design results as well as aid in design closure.

- 1. In the Hierarchy pane of the Project Navigator Design panel, select the stopwatch module.
- 2. In the Processes pane, expand **Implement Design**, expand **Place & Route**, and double-click **Analyze Timing/Floorplan Design (PlanAhead)**.

The process is shown in the following figure.





3. When the PlanAhead tool opens, select one of the timing paths in the Timing Results tab. You will be able to view the path graphically in the Device view, and also view details of the path and the associated delays in the Properties tab.



Figure 6-24: Viewing Timing Path in PlanAhead Tool

4. Zoom in on the path in the Device view by clicking and dragging a box around the area.

For a detailed tutorial on the full set of capabilities in the PlanAhead tool related to timing analysis and design closure, select **Help > PlanAhead Tutorials** and see the *Design Analysis and Floorplanning Tutorial (UG676)*.

5. To close the PlanAhead tool, select **File > Exit**.

Creating Configuration Data

After analyzing the design, you need to create configuration data. A configuration bitstream is created for downloading to a target device or for formatting into a PROM programming file.

In this tutorial, you will create configuration data for a Xilinx Serial PROM. To create a bitstream for the target device, set the properties and run configuration as follows:

- 1. In the Hierarchy pane of the Project Navigator Design panel, select the stopwatch module.
- 2. In the Processes pane, right-click **Generate Programming File**, and select **Process Properties**.
- 3. In the Process Properties dialog box, click the Startup Options category.

4. Change the FPGA Start-Up Clock property from CCLK to JTAG Clock.

🚾 Process Properties - Startup Op	tions	X
Category	Property Name	Value
General Options	FPGA Start-Up Clock	JTAG Clock 🛛 🗸
Startup Options	Enable Internal Done Pipe	
Readback Options	Done (Output Events)	Default (4)
Suspend/Wake Options	Enable Outputs (Output Events)	Default (5)
	Release Write Enable (Output Events)	Default (6)
	Wait for DLL Lock (Output Events)	Default (NoWait)
	Drive Done Pin High	
	Property display level:	Advanced 🕑 🗋 Display switch names 🛛 Default
		OK Cancel Apply Help

Figure 6-25: Process Properties Startup Options

Note: You can use CCLK if you are configuring Select Map or Serial Slave.

- 5. Click **OK**.
- 6. In the Processes pane, double-click **Generate Programming File** to create a bitstream of this design.

The BitGen program creates the bitstream file (in this tutorial, the stopwatch.bit file), which contains the actual configuration data.

7. To review the Programming File Generation Report, open the **Bitgen Report** in the Design Summary/Report Viewer. Verify that the specified options were used when creating the configuration data.

Creating a PROM File with iMPACT

To program a single device using iMPACT, all you need is a bitstream file. To program several devices in a daisy chain configuration or to program your devices using a PROM, you must use iMPACT to create a PROM file. iMPACT accepts any number of bitstreams and creates one or more PROM files containing one or more daisy chain configurations.

In iMPACT, a wizard enables you to do the following:

- Create a PROM file.
- Add additional bitstreams to the daisy chain.
- Create additional daisy chains.
- Remove the current bitstream and start over, or immediately save the current PROM file configuration.

For this tutorial, create a PROM file in iMPACT as follows:

- 1. In the Processes pane, expand **Configure Target Device**, and double-click **Generate Target PROM/ACE File**.
- 2. In iMPACT, double-click on **Create PROM File (PROM File Formatter)** in the iMPACT Flows window.

iMPACT Flows	⇔□₽×
Boundary Scan SystemACE	File Formatter)

Figure 6-26: Create PROM File

- 3. In the PROM File Formatter window, select **Xilinx Flash/PROM** in the Select Storage Target section.
- 4. Click the green arrow to activate the next section.
- 5. In the Add Storage Device(s) section, click the **Auto Select PROM** checkbox.
- 6. In the Enter Data section, enter an Output File Name of **stopwatch1**.
- 7. Verify that the Checksum Fill Value is set to **FF** and the File Format is **MCS**.

😓 PROM File Formatter								×
Step 1. Select Storage Target	c	Step 2.	Add	Storage Device(s)	Step 3,		Enter	Data
Storage Device Type :		PROM Family		Platform Elash	General File Detail		Value	
Xilinx Flash/PROM		Device (bits)		xcf01s [1 M]	Checksum Fill Value	FF		
SPI Flash Configure Single FPGA		Add Storage D	evice	Remove Storage Device	Output File Name	stopwatch1		
Configure MultiBoot FPGA BPI Flash Configure Single EPGA		er andere en			Output File Location	e_temp8\bft3	\bft_proj\bft_pr	oil 📂
Configure MultiBoot FPGA Configure from Paralleled PROMs								
Generic Parallel PROM					Flash/PROM Fl	le Property	Value	
					Enable Revisioning		Vec	
					Number Of Revision	ns	103	
					Enable Compression	n	No	~
		Auto Select P	ROM					

Figure 6-27: PROM File Formatter

- 8. Click **OK** to close the PROM File Formatter.
- 9. In the Add Device dialog box, click **OK** and then select the **stopwatch.bit** file.
- 10. Click **No** when you are asked if you would like to add another design file to the datastream.
- 11. Click **OK** to complete the process.
- 12. Select the device graphic in the workspace area.
- 13. In the iMPACT Processes view, double-click **Generate File**.

iMPACT displays the PROM associated with your bitstream file.



Figure 6-28: PROM File

- 14. To close iMPACT, select **File > Exit**.
- 15. When prompted to save the project, select **Yes**, then name the project file **stopwatch_impact.ipf**.

With the resulting stopwatch.bit, stopwatch1.mcs, and a MSK file generated along with the BIT file, you are ready for programming your device using iMPACT. For more information on programming a device, see the iMPACT Help, available from the iMPACT application by selecting **Help > Help Topics**.

This completes the "Design Implementation" chapter of the tutorial. For more information on this design flow and implementation methodologies, see the ISE Help, available from Project Navigator by selecting **Help > Help Topics**.

Command Line Implementation

The ISE Design Suite allows you to easily view and extract the command line arguments for the various steps of the implementation process. This allows you to verify the options being used or to create a command batch file to replicate the design flow.

At any stage of the design flow, you can look at the command line arguments for completed processes by double-clicking **View Command Line Log File** under the **Design Utilities** process hierarchy in the Processes pane. This process opens a file named <source_name>.cmd_log in read-only mode. To create an editable batch file, select **File** > **Save As** and enter the desired file name.

Sections of the command line log file can also be copied from <source_name>.cmd_log using either the copy-and-paste method or the drag-and-drop method into a text file.

For a complete listing of command line options for most Xilinx executables, refer to the *Command Line Tools User Guide (UG628)*. Command line options are organized according to implementation tools. Command line options can also be obtained by typing the executable name followed by the **-h** option at a command prompt.



Chapter 7

Timing Simulation

Overview of Timing Simulation Flow

Timing simulation uses the block and routing delay information from a routed design to give a more accurate assessment of the behavior of the circuit under worst-case conditions. For this reason, timing simulation is performed after the design has been placed and routed.

Timing (post-Place and Route) simulation is a highly recommended part of the HDL design flow for Xilinx® devices. Timing simulation uses the detailed timing and design layout information that is available after Place and Route. This enables simulation of the design, which closely matches the actual device operation. Performing a timing simulation in addition to a static timing analysis will help to uncover issues that cannot be found in a static timing analysis alone. To verify the design, the design should be analyzed both statically and dynamically.

In this chapter, you will perform a timing simulation using either the ModelSim simulator or the Xilinx ISim simulator.

Getting Started

The following sections outline the requirements to perform this part of the tutorial flow.

Required Software

To simulate with ModelSim, you must have the Xilinx ISE® Design Suite and ModelSim simulator installed. Refer to Chapter 5, Behavioral Simulation, for information on installing and setting up ModelSim. Simulating with ISim requires that the ISE Design Suite is installed.

Required Files

The timing simulation flow requires the following files:

• Design files (VHDL or Verilog)

This chapter assumes that you have completed Chapter 6, Design Implementation, and thus, have a placed and routed design. The NetGen tool will be used in this chapter to create a simulation netlist from the placed and routed design, which will be used to represent the design during the timing simulation.

• Test bench file (VHDL or Verilog)

To simulate the design, a test bench is needed to provide stimulus to the design. You should use the same test bench that was used to perform the behavioral simulation. Please refer to Adding an HDL Test Bench in Chapter 5 if you do not already have a test bench in your project.

• Xilinx simulation libraries

For timing simulation, the SIMPRIM library is needed to simulate the design.

To perform timing simulation of Xilinx designs in any HDL simulator, the SIMPRIM library must be set up correctly. The timing simulation netlist created by Xilinx is composed entirely of instantiated primitives, which are modeled in the SIMPRIM library.

If you completed Chapter 5, Behavioral Simulation, the SIMPRIM library should already be compiled. For more information on compiling and setting up Xilinx simulation libraries, see Xilinx Simulation Libraries in Chapter 5.

Specifying a Simulator

To specify the simulator to simulate the stopwatch design, do the following:

- 1. In the Hierarchy pane of the Project Navigator Design panel, right-click the device line (xc3s700A-4fg484), and select **Design Properties**.
- 2. In the Design Properties dialog box, set the Simulator field to **ISim (VHDL/Verilog)** or **ModelSim** (with the appropriate type and language).

Note: ModelSim and Xilinx ISim are the only simulators that are integrated with Project Navigator. Selecting a different simulator (for example, NC-Sim or VCS) will set the correct options for NetGen to create a simulation netlist for that simulator, but Project Navigator will not directly open the simulator. For additional information about simulation and for a list of other supported simulators, see the *Synthesis and Simulation Design Guide (UG626)*.

Timing Simulation Using ModelSim

The Xilinx ISE Design Suite provides an integrated flow with the Mentor ModelSim simulator. The ISE Design Suite enables you to create work directories, compile source files, initialize simulation, and control simulation properties for ModelSim.

Note: To simulate with ISim, skip to Timing Simulation Using Xilinx ISim. Whether you choose to use the ModelSim simulator or ISim for this tutorial, the end result is the same.

Specifying Simulation Process Properties

To set the simulation process properties, do the following:

- 1. In the View pane of the Project Navigator Design panel, select **Simulation**, and select **Post-Route** from the drop-down list.
- 2. In the Hierarchy pane, select the test bench file (stopwatch_tb).
- 3. In the Processes pane, expand ModelSim Simulator, right-click Simulate Post-Place & Route Model, and select Process Properties.

Note: If the ModelSim Simulator processes do not appear, ensure that you selected ModelSim in the Design Properties dialog box, as described in Specifying a Simulator. If this setting is correct and the ModelSim Simulator processes still do not appear, ensure that Project Navigator can find the modelsim.exe file. To set the location for this file, select Edit > Preferences. In the left pane of the Preferences dialog box, expand ISE General, and click Integrated Tools. In the right pane, under Model Tech Simulator, browse to the location of modelsim.exe file. For example: c:\modeltech_xe\win32xoem\modelsim.exe.

4. In the Process Properties dialog box, ensure that the Property display level is set to **Advanced**.

This global setting enables you to see all available properties.

5. Select the **Simulation Model Properties** category. These properties set the options that NetGen uses when generating the simulation netlist. For a description of each property, click the **Help** button.

The properties should appear as shown in the following figure. For this tutorial, the default Simulation Model Properties are used.

Process Properties - Simula	non wodet Properties	
tegory	Property Name	Value
Simulation Properties	Simulation Model Target	VHDL
Display Properties	Device Speed Grade/Select ABS Minimum	-4
XPower Analyzer Properties	Retain Hierarchy	
	Generate Multiple Hierarchical Netlist Files	
	Bring Out Global Tristate Net as a Port	
	Global Tristate Port Name	GTS_PORT
	Bring Out Global Set/Reset Net as a Port	
	Global Set/Reset Port Name	GSR_PORT
	Generate Testbench File	
	Rename Design Instance in Testbench File to	UUT
	Insert Buffers to Prevent Pulse Swallowing	
	Other NETGEN Command Line Options	
	Rename Top Level Entity to	stopwatch
	Rename Top Level Architecture To	Structure
	Tristate On Configuration Pulse Width	0
	Reset On Configuration Pulse Width	100
	Generate Architecture Only (No Entity Declaration)	
	² Output Extended Identifiers	
	Rename Top Level Module To	
	Include 'uselib Directive in Verilog File	
	Include sdf_annotate task in Verilog File	
	Path Used in sdf_annotate task	Default
	Do Not Escape Signal and Instance Names in Netlist	
	Include SIMPRIM Models in Verilog File	
	Automatically Insert glbl Module in the Netlist	
	Property displa	ay level: Advanced 💌 🗌 Display switch names 🔹 Defau
		OK Cancel Apply Help

Figure 7-1: Simulation Model Properties

- 6. Select the **Display Properties** category. These properties give you control over the ModelSim simulation windows. When timing simulation is launched from the ISE Design Suite, three windows open by default: the Signal window, the Structure window, and the Wave window. For more details on ModelSim simulator windows, refer to the *ModelSim User Guide*.
- 7. Select the **Simulation Properties** category. These properties set the options that ModelSim uses to run the timing simulation. For a description of each property, click the **Help** button.

The properties should appear as shown in the following figure. Set the Simulation Run Time property to **2000 ns**.

Simulation Properties - Simulation	n Properties			×
Category	Switch Name	Property Name	Value	^
Simulation Properties	-dir	Compiled Library Directory	\$XILINX/ <language>/<simulator></simulator></language>	
Simulation Model Properties		Ignore Pre-Compiled Library Warning Check		
XPower Analyzer Properties		Generate Verbose Library Compilation Messages		
		Use Custom Do File		
		Custom Do File		Ξ
		Use Automatic Do File		
		Delay Values To Be Read from SDF	Setup Time 💌	
		Other VSIM Command Line Options		
		Other VLOG Command Line Options		
	-	Other VCOM Command Line Options		
		Simulation Run Time	2000ns	
		Simulation Resolution	Default (1 ps) 🛛 👻	
		VHDL Syntax	93 💌	
		Use Explicit Declarations Only		~
		Property display level: Advanced	Display switch names Default	
		ОК	Cancel Apply Help	

Figure 7-2: Simulation Properties

8. Click **OK** to close the Process Properties dialog box.

Performing Simulation

To start the timing simulation, double-click **Simulate Post-Place and Route Model** in the Processes pane.

The ISE Design Suite will run NetGen to create the timing simulation model. The ISE Design Suite will then call ModelSim and create the working directory, compile the source files, load the design, and run the simulation for the time specified.

Note: The majority of this design runs at 100 Hz and would take a significant amount of time to simulate. This is why the counter will seem like it is not working in a short simulation. For the purpose of this tutorial, only the DCM signals will be monitored to verify that they work correctly.

Adding Signals

To view signals during the simulation, you must add them to the Wave window. The ISE Design Suite automatically adds all the top-level ports to the Wave window. Additional signals are displayed in the Signal window based on the selected structure in the Structure window.

There are two basic methods for adding signals to the Simulator Wave window:

- Drag and drop from the Signal/Object window.
- Highlight signals in the Signal/Object window and then select Add > Wave > Selected Signals.

The following procedure explains how to add additional signals in the design hierarchy. In this tutorial, you will be adding the DCM signals to the waveform.

Note: If you are using ModelSim version 6.0 or higher, all the windows are docked by default. All windows can be undocked by clicking the **Undock** icon.



Figure 7-3: Undock Icon

1. In the Structure/Instance window, expand the **UUT** hierarchy.

The following figure shows the Structure/Instance window for the Schematic flow. The graphics and the layout of the Structure/Instance window for a Verilog or VHDL flow may be different.



Figure 7-4: Structure/Instance Window—Schematic Flow

- 2. Click the Structure/Instance window, and select **Edit > Find**.
- 3. Type **X_DCM** in the search box, and select **Entity/Module** in the Field section.
- 4. After ModelSim locates X_DCM, select **X_DCM_SP**, and click on the signals/objects window. All the signal names for the DCM will be listed.
- 5. Select the Signal/Object window, and select **Edit > Find**.
- 6. Type **CLKIN** in the search box and select the **Exact** checkbox.
- 7. Click and drag CLKIN from the Signal/Object window to the Wave window.

- 8. Click and drag the following signals from the Signal/Object window to the Wave window:
 - RST
 - CLKFX
 - CLK0
 - LOCKED

Note: Multiple signals can be selected by holding down the **Ctrl** key. In place of using the drag and drop method, select **Add to Wave > Selected Signals**.

Adding Dividers

ModelSim has the capability to add dividers in the Wave window to make it easier to differentiate the signals. To add a divider called DCM Signals, do the following:

- 1. Right-click anywhere in the signal section of the Wave window. If necessary, undock the window and maximize the window for a larger view of the waveform.
- 2. Select Insert Divider.
- 3. In the Divider Name box, enter **DCM Signals**.
- 4. Click **OK**.
- 5. Click and drag the newly created divider to above the CLKIN signal.

Note: Stretch the first column in the waveform to see the signals clearly. The hierarchy in the signal name can also be turned off by selecting **Tools > Options > Wave Preferences**. In the Display Signal Path box, enter **2** and click **OK**.

After adding the DCM Signals divider, the waveform appears as shown in the following figure.



Figure 7-5: **Resulting Waveform**

The waveforms have not been drawn for the newly added signals. This is because ModelSim did not record the data for these signals. By default, ModelSim only records data for the signals that are added to the Wave window while the simulation is running. Therefore, after new signals are added to the Wave window, you must rerun the simulation for the desired amount of time.

Rerunning Simulation

To restart and rerun the simulation, do the following:

1. Click the Restart Simulation icon.



Figure 7-6: **Restart Simulation Icon**

The Restart dialog box opens.

М	Restart	_	
	—Кеер):	
	☑	List Format	
	☑	Wave Format	
	☑	Breakpoints	
	☑	Logged Signals	
	☑	Virtual Definitions	
	V	Assertions	
	☑	Cover Directives	
		TTV Format	
	Res	<u>tart </u> Cancel	

Figure 7-7: Restart Dialog Box

- 2. Click Restart.
- 3. At the ModelSim command prompt, enter **run 2000 ns** and hit the **Enter** key.



The simulation will run for 2000 ns. The waveforms for the DCM should now be visible in the Wave window.

Analyzing the Signals

Now the DCM signals can be analyzed to verify that it works as expected. The CLK0 must be 50 Mhz and the CLKFX should be approximately 26 Mhz. The DCM signals should only be analyzed after the LOCKED signal has gone high. Until the LOCKED signal is high the DCM outputs are not valid.

ModelSim has the capability to add cursors to carefully measure the distance between signals. To measure the CLK0, do the following:

- $1. \quad Select \ \textbf{Add} > \textbf{Cursor twice to place two cursors on the wave view}.$
- 2. Click and drag the first cursor to the rising edge transition on the CLK0 signal after the LOCKED signal has gone high.

- 3. Click and drag the second cursor to a position just right of the first cursor on the CLK0 signal.
- 4. Click the Find Next Transition icon twice to move the cursor to the next rising edge on the CLK0 signal.



Figure 7-9: Find Next Transition Icon

Look at the bottom of the waveform to view the distance between the two cursors. The measurement should read 20000 ps. This converts to 50 Mhz, which is the input frequency from the test bench, which in turn should be the DCM CLK0 output.

Measure CLKFX using the same steps as above. The measurement should read 38462 ps. This equals approximately 26 Mhz.

Saving the Simulation

The ModelSim simulator provides the capability of saving the signals list in the Wave window. Save the signals list after new signals or stimuli are added, and after simulation is rerun. The saved signals list can easily be loaded each time the simulation is started. To save the signals list, do the following:

- 1. In the Wave window, select File > Save Format.
- 2. In the Save Format dialog box, rename the filename from the default wave.do to dcm_signal_tim.do.



Figure 7-10: Save Format Dialog Box

3. Click **OK**.

After restarting the simulation, you can select **File > Load** in the Wave window to reload this file.

Your timing simulation is complete, and you are ready to program your device by following Chapter 8, Configuration Using iMPACT.

Timing Simulation Using Xilinx ISim

Follow this section of the tutorial if you have skipped the previous section, Timing Simulation Using ModelSim.

Specifying Simulation Process Properties

To set the simulation process properties, do the following:

- 1. In the View pane of the Project Navigator Design panel, select **Simulation**, and select **Post-Route** from the drop-down list.
- 2. In the Hierarchy pane, select the test bench file (stopwatch_tb).
- 3. In the Processes pane, expand **ISim Simulator**, right-click **Simulate Post-Place & Route Model**, and select **Process Properties**.
- 4. In the Process Properties dialog box, ensure that the Property display level is set to **Advanced**.

This global setting enables you to see all available properties.

5. Select the **Simulation Model Properties** category. These properties set the options that NetGen uses when generating the simulation netlist. For a description of each property, click the **Help** button.

For this tutorial, the default Simulation Model Properties are used.

6. Select the **ISim Properties** category. These properties set the options the simulator uses to run the timing simulation. For a description of each property, click the **Help** button.

The properties should appear as shown in the following figure. Set the Simulation Run Time property to **2000 ns**.

ategory	Switch Name	Property Name	Value
ISim Properties		Use Custom Simulation Command File	
XPower Analyzer Properties		Custom Simulation Command File	
	-incremental	Incremental Compilation	
	-nodebug	Compile for HDL Debugging	
		Use Custom Project File	
	-prj	Custom Project Filename	
		Run for Specified Time	
		Simulation Run Time	2000 ns
		Waveform Database Filename	topwatch_tb_isim_par.wdb 🗔
		Use Custom Waveform Configuration File	
		Custom Waveform Configuration File	
		Generate SAIF File for Power Optimization/Estimation	
		SAIF File Name	_vhd/xpower_time_sim.saif 🕠
		Delay Values To Be Read from SDF	Setun Time 🗸
		Property display level: Advanced 👽 🗹 Dis	play switch names Default

Figure 7-11: Simulation Properties

7. Click **OK** to close the Process Properties dialog box.

Performing Simulation

To start the timing simulation, double-click **Simulate Post-Place and Route Model** in the Processes pane.

When a simulation process is run, Project Navigator automatically runs NetGen to generate a timing simulation model from the placed and routed design. The ISim then compiles the source files, loads the design, and runs the simulation for the time specified.

Note: The majority of this design runs at 100 Hz and would take a significant amount of time to simulate. This is why the counter will seem like it is not working in a short simulation. For the purpose of this tutorial, only the DCM signals will be monitored to verify that they work correctly.

Adding Signals

To view signals during the simulation, you must add them to the waveform window. The ISE Design Suite automatically adds all the top-level ports to the waveform window. All available external (top-level ports) and internal signals are displayed in the simulation hierarchy.

The following procedure explains how to add additional signals in the design hierarchy. In this tutorial, you will be adding the DCM signals to the waveform.

- 1. In the Instances and Processes panel, expand the **stopwatch_tb** hierarchy.
- 2. Expand the **UUT** hierarchy.
- 3. Locate and select Inst_dcm1_DCM_SP_INST
- 4. In the Objects window, right-click the **locked** signal, and select **Add to Wave Window**.

The following figure shows the Simulation Instances and Simulation Objects window for the VHDL flow. The signal names and layout in the Simulation Instances window for a schematic or Verilog flow may be different.

👷 File	Edit	View Simulation Window Layout	: Help										
i 🔝 🛿) 📄	। 🕹 । 🔏 🗋 🛅 🗙 🚷 🛤 ०	- 🖄 🕅 🖡	1 🛛 🖂 🖪		🖻 i 🎤 🎌 i	P P 🔉	۶	🗟 🤅 🏝 🏦 🏌	it 🤺 🖬	🕨 🔽 1.00us 🔽 🌜	1 II	
Instance	es and P	Processes		⇔⊡₽×	Object	ts	⇔⊡₽×	Æ					
					Simula	ation Objects for In	st_dcm1_D	۲					
					101	10/10/10/10/		-	Name	Value	1,999,996 ps	1,999,997 ps	1,999,998 ps
Instan	ce and	Process Name	Design Unit	Block Type				8	🕼 clk	0			
and the second		sf_d_4_OBUF	x_obuf(x_obu	VHDL Entity	Obje	ect Name	Value 🔷	~	lan load	0			
	Þ 📒	sf_d_5_OBUF	x_obuf(x_obu	VHDL Entity	1 1	🔓 clk0	0	0	10 mode				
Section.		sf_d_6_OBUF	x_obuf(x_obu	VHDL Entity	1	🔓 clk180	1			°			
		sf_d_7_OBUF	x_obuf(x_obu	VHDL Entity	1 1	🔓 clk270	0 🗾	9	Ue reset	0			
123 SOC		reset_IBUF	x_buf(x_buf_v)	VHDL Entity		🔓 clk2x	1	1	🍓 strtstop	1			
		lap_load_IBUF	x_buf(x_buf_v)	VHDL Entity	1	🖕 clk2x180	0	-	🕼 lcd_e	0			
NAME IN		lcd_rs_OBUF	x_obuf(x_obu	VHDL Entity	and L	🖕 clk90	1	-	1 led rs	0			
		lcd_rw_OBUF	x_obuf(x_obu	VHDL Entity	1	💩 clkdv	0	+	10	Ľ			
1028.00		mode_IBUF	x_buf(x_buf_v)	VHDL Entity		🔓 clkfx	1	-	ue lcd_rw	0			
100000000000000000000000000000000000000		Inst_dcm1_CLKIN_IBUFG_INST	x_buf(x_buf_v)	VHDL Entity	1	a clkf×180	0	1.	▶ 💐 sf_d[7:0]	00000000		00000	000
and parts		Inst_dcm1_CLK0_BUFG_INST	x_bufgmux(x	VHDL Entity	1	n locked	1	1	🛺 period	20000 ps		20000	ps
1010101000		Inst_dcm1_CLK0_BUFG_INST_SINV	x_inv(x_inv_v)	VHDL Entity	1	b psdone	0	1104	1ª duty cycle	0 500000		0 500	
and the second		Inst_dcm1_CLK0_BUFG_INST_I0_USED	x_buf(x_buf_v)	VHDL Entity		👹 status[7:0]	10100	No.	10 laded			0.0004	
		Inst_dcm1_CLKFX_BUFG_INST	x_bufgmux(x	VHDL Entity	1	🛓 clkfb	1	21	liocked	1-			
Selection .		Inst_dcm1_CLKFX_BUFG_INST_SINV	x_inv(x_inv_v)	VHDL Entity	TALK.	👆 clkin	1						
01/11/2010/01/0		Inst_dcm1_CLKFX_BUFG_INST_I0_U	x_buf(x_buf_v)	VHDL Entity	4	🛓 dssen	υ						
101010		clk_divider_div_262144_BUFG	x_bufgmux(x	VHDL Entity	Dist.	🖕 psclk	0						
000000000000000000000000000000000000000		clk_divider_div_262144_BUFG_SINV	x_inv(x_inv_v)	VHDL Entity	4	psen	0						
CAR SA		clk_divider_div_262144_BUFG_I0_US	x_buf(x_buf_v)	VHDL Entity	1000	b psincdec	0						
1770-1878-1879-18		Inst_dcm1_DCM_SP_INST_PSCLKINV	x_buf(x_buf_v)	VHDL Entity	L	🙀 rst	0						
1112136		Inst_dcm1_DCM_SP_INST	×_dcm_sp(x	VHDL Entity		clkfb_ipd	1				X1: 2,000,000 ps		
1		I Inst dcm1 DCM SP INST CLKFB BUF	× but(x buf v)	VHDL Entity	1	clkin_ipd	1		-				
-						odssen_ipd	U 🔽					_	
🚠 In	stances	and Processes 🔚 Memory 📔 S	Source Files		<		>	222	in a start and the start of the	Default.wcfg*			

Figure 7-12: Simulation Instances and Simulation Objects Windows—VHDL Flow

www.xilinx.com

- 5. Click and drag the following X_DCM_SP signals from the simulation hierarchy to the waveform window:
 - RST
 - CLKFX
 - CLK0
 - CLKIN

Note: You can select multiple signals by pressing the Ctrl key.

Viewing Full Signal Names

You can view signal names using either the complete hierarchical name or the short name, which omits hierarchy information. To change the signal name display, do the following:

- 1. Right-click the desired signal in the waveform window.
- 2. Select Name > Long or Name > Short.

Stretch the first column in the waveform to see the signals clearly.

The waveform should appear as shown in the following figure.



Figure 7-13: Resulting Waveform

Notice that the waveforms have not been drawn for the newly added signals. This is because ISim did not record the data for these signals. ISim only records data for the signals that are added to the waveform window while the simulation is running. Therefore, after new signals are added to the waveform window, you must rerun the simulation for the desired amount of time.

Rerunning Simulation

To restart and rerun the simulation, do the following:

1. Click the Restart Simulation toolbar button.



Figure 7-14: Restart Simulation Icon

2. At the Sim Console command prompt, enter **run 2000 ns** and hit the **Enter** key.

* run 2000 ns

Figure 7-15: Entering the Run Command

The simulation will run for 2000 ns. The waveforms for the DCM should now be visible in the Simulation window.

Analyzing the Signals

Now the DCM signals can be analyzed to verify that they are working as expected. The CLK0 must be 50 Mhz and the CLKFX should be approximately 26 Mhz. The DCM signals should only be analyzed after the LOCKED signal has gone high. Until the LOCKED signal is high the DCM outputs are not valid.

ISim has the capability to add cursors to carefully measure the distance between signals. To measure the CLK0, do the following:

- 1. If necessary, zoom in on the waveform using the local Zoom toolbar buttons.
- 2. In the local waveform viewer toolbar, click the Snap to Transition toolbar button.

31

Figure 7-16: Snap to Transition Toolbar Button

3. Click on the first rising edge transition on the CLK0 signal after the LOCKED signal has gone high, then drag the cursor to the right to the next rising edge transition of the CLK0 signal.

At the bottom of the waveform window, the start point time, end point time, and delta times are shown. The delta should read 20.0 ns. This converts to 50 Mhz, which is



the input frequency from the test bench, which in turn should be the DCM CLK0 output.

Figure 7-17: Waveform Viewer Displaying Time Between Transitions

4. Measure CLKFX using the same steps as above. The measurement should read 38.5 ns, this equals approximately 26 Mhz.

Your timing simulation is complete and you are ready to program your device by following Chapter 8, Configuration Using iMPACT.



Chapter 8

Configuration Using iMPACT

Overview of iMPACT

This chapter takes you on a tour of iMPACT, a file generation and device programming tool. iMPACT enables you to program through several parallel cables, including the Platform Cable USB. iMPACT can create bitstream files, System ACETM solution files, PROM files, and SVF/XSVF files. The SVF/XSVF files can be played backed without having to recreate the chain.

Device Support

For information on supported devices, refer to the *ISE Design Suite: Release Notes Guide* (*UG631*) available from the Xilinx® website.

Download Cable Support

The following cables are supported.

Parallel Cable IV

The Parallel Cable connects to the parallel port of your computer and can be used to facilitate Boundary-Scan functionality. For more information, see the <u>Xilinx Parallel Cable</u> IV Data Sheet available from the Xilinx website.

Platform Cable USB

The Platform Cable connects to the USB port of your computer and can be used to facilitate Boundary-Scan functionality. For more information, see the <u>Platform Cable USB Data</u> <u>Sheet</u> available from the Xilinx website.

Platform Cable USB-II

The Platform Cable connects to the USB port of your computer and can be used to facilitate Boundary-Scan functionality. For more information, see the <u>Platform Cable USB-II Data</u> <u>Sheet</u> available from the Xilinx website.

Configuration Mode Support

iMPACT currently supports the Boundary-Scan configuration mode for FPGAs, CPLDs, PROMs (XCFxxS and XCFxxP), and third-party SPI/BPI Flash devices.

www.xilinx.com

Getting Started

The following sections outline the requirements to perform this part of the tutorial flow.

Generating the Configuration Files

To follow this chapter, you must have the following files for the stopwatch design:

• BIT file

A binary file that contains proprietary header information as well as configuration data.

MCS file

An ASCII file that contains PROM configuration information.

• MSK file

A binary file that contains the same configuration commands as a BIT file, but that has mask data in place of configuration data. This data is not used to configure the device, but is used for verification. If a mask bit is 0, the bit should be verified against the bit stream data. If a mask bit is 1, the bit should not be verified. This file is generated along with the BIT file.

These files are generated in Chapter 6, Design Implementation.

The tutorial project files are provided with the ISE Design Suite <u>Tutorials</u> available from the Xilinx website. Download the project files for the VHDL, Verilog, or schematic design flow.

Connecting the Cable

Prior to launching iMPACT, connect the parallel side of the cable to your computer's parallel port, and connect the cable to the SpartanTM-3 Starter Kit demo board. Be sure that the board is powered.

Starting the Software

This section describes how to start the iMPACT software from the ISE® Design Suite and how to run the iMPACT software standalone.

Opening iMPACT from Project Navigator

To start iMPACT from Project Navigator, double-click **Manage Configuration Project** (**iMPACT**) in the Processes pane in the Design panel, as shown in the following figure.

Processes	×
Processes for: stopwatch - stopwatch_arch	
Add Existing Source	_
📩 Create New Source	
🗵 View Design Summary	
🗄 🎾 Design Utilities	
🗄 🎾 User Constraints	
🗄 🔁 🚹 Synthesize - XST	
🗄 🤁 🔥 Implement Design	
🗄 🎦 🕜 Generate Programming File	
🗄 🤁 Configure Target Device	
- 🥵 Manage Configuration Project (iMPACT)	
🦾 🔟 Update Bitstream with Processor Data	
Processes	

Figure 8-1: Opening iMPACT from Project Navigator

Opening iMPACT Standalone

To open iMPACT without going through an ISE project, use one of the following methods:

- PC only: Click Start > All Programs > Xilinx ISE Design Suite > ISE Design Tools > Tools > iMPACT.
- *PC or Linux*: Type **impact** at a command prompt.

Note: To run applications from the command line, you must configure the system environment to point to the ISE Design Suite. To do this, run the appropriate settings32.csh/bat or settings64.csh/bat file from the settings64.csh/bat for more information, refer to the ISE Design Suite: Installation and Licensing Guide (UG798) available from the Xilinx website.

Using Boundary-Scan Configuration Mode

For this tutorial, you will be using the Boundary-Scan configuration mode. Boundary-Scan configuration mode enables you to perform Boundary-Scan operations on any chain comprising JTAG compliant devices. The chain can consist of both Xilinx and non-Xilinx devices; however, limited operations will be available for non-Xilinx devices. To perform operations, the cable must be connected and the JTAG pins, TDI, TCK, TMS, and TDO, must be connected from the cable to the board.

Specifying Boundary-Scan Configuration Mode

In iMPACT, creating a new project includes specifying the configuration mode and the device to program. To select Boundary-Scan Mode, do the following:

- 1. Select **File > New Project**.
- 2. In the Automatically create and save a project dialog box, select Yes.
- 3. In the Welcome to iMPACT dialog box, select **Configure Devices using Boundary-Scan (JTAG)**.
- 4. Ensure that **Automatically connect to a cable and identify Boundary-Scan chain** is selected.

Note: The selection box also gives you the option to Enter a Boundary-Scan Chain, which enables you to manually add devices to create the chain. This option enables you to generate an SVF/XSVF programming file and is discussed in a later section in this chapter. Automatically detecting and initializing the chain should be performed whenever possible.

5. Click OK.

& Welcome	to iMPACT
-Please select	an action from the list below
💿 Configu	re devices using Boundary-Scan (JTAG)
	Automatically connect to a cable and identify Boundary-Scan chain 🛛 💌
🔘 Prepare	a PROM File
🔘 Prepare	a System ACE File
🔘 Prepare	a Boundary-Scan File
	SVF 🗸
	OK

Figure 8-2: Selecting Automatic Boundary-Scan Using iMPACT Wizard

iMPACT will pass data through the devices and automatically identify the size and composition of the Boundary-Scan chain. Any supported Xilinx device will be recognized and labeled in iMPACT. Any other device will be labeled as unknown. The software will then highlight each device in the chain and prompt you to assign a configuration file or BSDL file.

Note: If you were not prompted to select a configuration mode or automatic Boundary-Scan mode, right-click in the iMPACT window and select **Initialize Chain**. The software will identify the chain if the connections to the board are working. Go to Troubleshooting Boundary-Scan Configuration if you are having problems.

Assigning Configuration Files

After initializing a chain, the software prompts you for a configuration file (see Figure 8-3). The configuration file is used to program the device. There are several types of configuration files:

- Bitstream file (*.bit, *.rbt, *.isc) is used to configure an FPGA.
- JEDEC file (*.jed,*.isc) is used to configure a CPLD.
- PROM file (*.mcs, *.hex) is used to configure a PROM.

When the software prompts you to select a configuration file for the first device (XC3S700A), do the following:

- 1. Select the BIT file from your project working directory.
- 2. Click Open.

You should receive a warning stating that the startup clock has been changed to JtagClk.

3. Click **OK**.

The following figure shows configuration file selection.

😵 ISE iMPACT (0.40b) - [Boundary Scan]					
File Edit View Oper	ations Output Debug Window Help	×			
: 🛄 💋 🖬 : 🚜 🗐 🕼					
MPACT Flows	→ □ B × (SP2)BF1 DM File Formatter) TDI xc3s700a xc104s bypass bypass				
	le Assign New Configuration File				
	Look in: C:\xilinx_tutorial\wtut_sc 🕑 O O 🗭 🔃 🗏				
IMPACT Processes Available Operations are:	My Computer howardp howardp bisim wtut_sc_completed xnx_auto_0_xdb xst stopwatch.bit Copen				
	File name: stopwatch.bit Cancel				
Console PROGRESS END - E: Elapsed time = // *** BATCH CMD	Files of type: All Design Files (*.bit *.rbt *.nky *.isc *.bsd) Sector Cancel All	+ 🗆 🗗 ×			
<		>			
📃 Console 🔕 Errors	🔬 Warnings				
	Configuration Platform Cable USB 6 MHz	ısb-hs .:			

Figure 8-3: Selecting a Configuration File

Note: If a configuration file is not available, a Boundary-Scan Description File (BSDL or BSD) file can be applied instead. The BSDL file provides the software with the necessary Boundary-Scan information that allows a subset of the Boundary-Scan operations to be available for that device. To have the ISE Design Suite automatically select a BSDL file (for both Xilinx and non-Xilinx devices), select **Bypass** in the Assign New Configuration File dialog box.

- 4. When the software prompts you to select a configuration file for the second device (XCF02S), select the MCS file from your project working directory.
- 5. Click Open.

Saving the Project File

After the chain has been fully described and configuration files are assigned, you should save your iMPACT Project File (IPF) for later use. To do this, select **File** > **Save Project As**. The Save As dialog box opens, and you can browse and save your project file accordingly. To restore the chain after reopening iMPACT, select **File** > **Open Project** and browse to the IPF.

Note: Previous versions of the ISE Design Suite use Configuration Data Files (CDF). These files can still be opened and used in iMPACT. iMPACT Project Files can also be exported to a CDF.

Editing Preferences

To edit the preferences for the Boundary-Scan configuration, select **Edit** > **Preferences**. This selection opens the window shown in the following figure. Click **Help** for a description of the preferences. In this tutorial, keep the default values and click **OK**.

🚾 Preferences - iMPACT General Optio	ns ?X
Category Category Console Floorplan Editor Colors Floorplan View Overlays Package View HTML Browser MPACT Configuration Preferences File General Design Goals & Strategies Editors Integrated Tools Process Completion Notification Sources View SISE Simulator (ISim) ISE Text Editor Canguage Templates RTL/Technology Viewers Schematic Editor CK	Set general behavior of iMPACT General Settings Load most recent project file when iMPACT starts Use iMPACT Main Wizard Message Level: Detailed I Validate BSCAN Chain After Loading Project or CDF Cancel Apply Help

Figure 8-4: Edit Preferences

Performing Boundary-Scan Operations

You can perform Boundary-Scan operations on one device at a time. The available Boundary-Scan operations vary based on the device and the configuration file that was applied to the device. To see a list of the available options, right-click on any device in the chain. This brings up a window with all of the available options.

When you select a device and perform an operation on that device, all other devices in the chain are automatically placed in BYPASS or HIGHZ, depending on your iMPACT Preferences setting. For more information about Preferences, see Editing Preferences.

To perform an operation, right-click on a device and select one of the options. In this section, you will retrieve the device ID and run the programming option to verify the first device as follows:

🐉 ISE iMPACT (0.40b) - C:\examples_0\w	vave_gen_vhd_s6\auto_project_1.ipf - [Boundary Scan]				
🛞 File Edit View Operations Output De	bug Window Help	- 8 ×			
i 🗋 🏓 🗐 i 🐰 🖻 📔 🗙 🖽 🖽 🖽	※ 1 鶴 三山 こ そう				
MPACT Flows ↔ □ ♂ ×					
	TDI Example xc3s700a xc104s stopwatch.bit stopwatch2.mcs				
Available Operations are: Program Get Device ID Get Device Signature/Usercode Read Device Status One Step SVF One Step XSVF					
	🛞 Boundary Scan				
Console	······································	· 🗆 🗗 ×			
<pre>// *** BATCH CMD : setMode -bs Selected part: xcf04s // *** BATCH CMD : assignFile -p 2 -file "C:/xilinx_tutorial/wtut_sc/stopwatch2.mcs" '2': Loading file 'C:/xilinx_tutorial/wtut_sc/stopwatch2.mcs' done. // *** BATCH CMD : setAttribute -position 2 -attr packageName -value ""</pre>					
		>			
📃 Console 🔇 Errors 🔔 Warnings					
	No Cable Connection No File Open				

1. Right-click on the XC3S700A device, and select Get Device ID.

Figure 8-5: Available Boundary-Scan Operations for XC3S700A Device

The software accesses the IDCODE for this Spartan-3A device. The result is displayed in the log window, as shown in the following figure.

```
// *** BATCH CMD : ReadIdcode -p 1
Maximum TCK operating frequency for this device chain: 0.
Validating chain...
Boundary-scan chain validated successfully.
'1': IDCODE is '00000010011000101000000010010011'
'1': IDCODE is '02628093' (in hex).
'1': : Manufacturer's ID =Xilinx xc3s700a , Version : 0
```

Figure 8-6: Log Window Showing Result of Get Device ID

- 2. Right-click on the XC3S700A device, and select **Set Programming Properties**. The Device Programming Properties dialog box opens.
- 3. Select the **Verify** option.

The Verify option enables the device to be read back and compared to the BIT file using the MSK file that was created earlier.

4. Click **OK** to begin programming.

🔤 Device Programming Properties - Device 2 Programming Properties						
Category - Boundary-Scan - Davies 1 (FDSA ws2:700s)						
Device 2 (PROM, xc3s700a)	Property Name	Value				
	Verify					
	General CPLD And PROM Properties					
	Erase Before Programming					
	Read Protect					
	PROM/CoolRunner-II Usercode (8 Hex Digit)					
	PROM Specific Properties					
	Load FPGA					
	OK Cancel Apply	Help				

Figure 8-7: Program Options for XC3S700A Device

Note: The options available in the Device Programming Properties dialog box vary based on the device you have selected.

5. Right-click on the XC3S700A device again, and select **Program**.

The Programming operation begins and an operation status window appears. At the same time, the log window reports all of the operations being performed.

🚾 Progress Dialog [55%]	?×
Executing command	
	Cancel

Figure 8-8: Operation Status

When the Program operation completes, a large blue message appears showing that programming was successful, as shown in the following figure. This message disappears after a few seconds.



Figure 8-9: Programming Operation Complete

Your design has been programmed and has been verified. The board should now be working and should allow you to start, stop and reset the runner's stopwatch.

Troubleshooting Boundary-Scan Configuration

The following sections assist you with troubleshooting errors that may occur during Boundary-Scan operations.

Verifying the Cable Connection

When an error occurs during a Boundary-Scan operation, first verify that the cable connection is established and that the software auto detect function is working. If a connection is still not established after plugging the cable into the board and into your machine, right-click in a blank portion of the iMPACT window and select either **Cable Auto Connect** or **Cable Setup**. Cable Auto Connect will force the software to search every port for a connection. Cable Setup enables you to select the cable and the port to which the cable is connected.

When a connection is found, the bottom of the iMPACT window will display the type of cable connected, the port attached to the cable, and the cable speed, as shown in the following figure.

Configuration Parallel IV 5 MHz LPT1

Figure 8-10: Cable Connection Successful

Note: If a cable is connected to the system and the cable autodetection fails, refer to Xilinx <u>Answer</u> <u>Record 15742</u>.

Verifying the Chain Setup

When an error occurs during a Boundary-Scan operation, verify that the chain is set up correctly and verify that the software can communicate with the devices. The easiest way to do this is to initialize the chain. To do so, right-click in the iMPACT window and select **Initialize Chain**. The software will identify the chain if the connections to the board are working.

If the chain cannot be initialized, it is likely that the hardware is not set up correctly or the cable is not properly connected. If the chain can be initialized, try performing simple operations. For example, try getting the Device ID of every device in the chain. If this can be done, then the hardware is set up correctly and the cable is properly connected.

The debug chain can also be used to manually enter JTAG commands, as shown in the following figure. This can be used for testing commands and verifying that the chain is set up correctly. To use this feature, select **Debug > Enable/Disable Debug Chain** in iMPACT.



Figure 8-11: Debug Chain

For help using iMPACT Boundary-Scan Debug, use the iMPACT Help, accessible from **Help** > **Help Topics**. For help with troubleshooting, file a WebCase on the Xilinx website.

Creating an SVF File

This section is optional and assumes that you have followed the Using Boundary-Scan Configuration Mode section and have successfully programmed to a board. In this section, all of the configuration information is written to the SVF file.

iMPACT supports the creation of device programming files in three formats: SVF, XSVF, and STAPL. If you are using third-party programming solutions, you may need to set up your Boundary-Scan chain manually and then create a device programming file. These programming files contain both programming instructions and configuration data, and they are used by Automatic Test Equipment (ATE) machines and embedded controllers to perform Boundary-Scan operations. A cable normally does not need to be connected because no operations are being performed on devices.

Setting Up the Boundary-Scan Chain

This section assumes that you are continuing from the previous sections of this chapter and already have the chain detected. If not, skip to Manually Setting Up the JTAG Chain for SVF Generation to define the chain manually.

Setting Up the JTAG Chain for SVF Generation

To set up the JTAG chain, do the following:

- 1. Select **Output** > **SVF File** > **Create SVF File** to indicate that you are creating a programming file.
- 2. In the Create New SVF File dialog box, enter **getid** in the File Name field, and click **Save**.
- 3. An informational message appears stating that all device operations will be directed to the .svf file. Click **OK**.

Manually Setting Up the JTAG Chain for SVF Generation

For this tutorial, you may skip this section if you completed the Using Boundary-Scan Configuration Mode section.

The Boundary-Scan chain can be manually created or modified as well. To do this, do the following:

- 1. Ensure that you are in Boundary-Scan Mode by clicking the Boundary-Scan tab. You can now add one device at a time.
- 2. Right-click on an empty space in the iMPACT Boundary-Scan window, and select **Add Xilinx Device** or **Add Non-Xilinx device**.

An Add Device dialog box opens, allowing you to select a configuration file.

3. Select stopwatch.bit, and then click **Open**.

The device is added where the large cursor is positioned. To add a device between existing devices, click on the line between them and then add the new device.

Repeat steps 2 and 3 to add the stopwatch.mcs file to the chain.

Note: The Boundary-Scan chain that you manually create in the software must match the chain on the board, even if you intend to program only some of the devices. All devices must be represented in the iMPACT window.

Writing to the SVF File

The process of writing to an SVF file is identical to performing Boundary-Scan operations with a cable. You simply right-click on a device and select an operation. Any number of operations can be written to an SVF file.

In this section, you will be writing the device ID to the programming file for the first device, and performing further instructions for the second device.

To write the device ID, do the following:

1. Right-click the first device (XC3S700A), and select **Get Device ID**.



Figure 8-12: Selecting a Boundary-Scan Operation

The instructions that are necessary to perform a Get Device ID operation are then written to the file.

2. To see the results, select **View** > **View SVF-STAPL File**. The following figure shows the SVF file after the Get Device ID operation is performed.

```
// Created using Xilinx iMPACT Software [ISE - 10.1]
// Date: Mon May 19 21:44:00 2008
TRST OFF:
ENDIR IDLE;
ENDDR IDLE;
STATE RESET;
STATE IDLE;
FREQUENCY 1E6 HZ;
TIR 0 ;
HIR O ;
TDR O ;
HDR O ;
TIR 0 ;
HIR O ;
TDR O ;
HDR O ;
TIR 0 ;
HIR O ;
TDR O ;
HDR O ;
TIR 0 ;
HIR 14 TDI (3fff) SMASK (3fff) ;
HDR 2 TDI (00) SMASK (03) ;
TDR O ;
//Loading device with 'idcode' instruction.
SIR 6 TDI (09) SMASK (3f) ;
SDR 32 TDI (00000000) SMASK (ffffffff) TDO (f2628093) MASK (Ofbfffff) ;
TIR O ;
HIR O ;
TDR O ;
HDR O ;
TIR 0 ;
HIR O ;
TDR O ;
HDR O ;
TIR O :
HIR 14 TDI (3fff) SMASK (3fff) ;
HDR 2 TDI (00) SMASK (03) ;
TDR O ;
//Loading device with 'idcode' instruction.
SIR 6 TDI (09) ;
SDR 32 TDI (00000000) TDO (f2628093) ;
//Loading device with 'idcode' instruction.
SIR 6 TDI (09) ;
SDR 32 TDI (00000000) TDO (f2628093) ;
TIR O ;
HIR 14 TDI (3fff) ;
HDR 2 TDI (00) ;
TDR 0 ;
TIR 0 ;
HIR O ;
TDR O ;
HDR O ;
SIR 20 TDI (Offfff) SMASK (Offfff) ;
SDR 3 TDI (00) SMASK (07) ;
```


To write further instructions to the SVF for the second device, do the following:

1. Right-click the second device (XCF02S), and select Program.



Figure 8-14: Available Boundary-Scan Operations for XCF02S Device

2. Click **OK** in the Programming Properties window.

The instructions and configuration data needed to program the second device are added to the SVF file.

Stopping Writing to the SVF File

After all the desired operations have been performed, you must add an instruction to close the file from further instructions. To stop writing to the programming file, select **Output** > **SVF File** > **Stop Writing to SVF File**.

To add other operations in the future, you can select **Output** > **SVF File** > **Append to SVF File**, select the SVF file, and click **Save**.

Playing Back the SVF or XSVF File

To play back the SVF file that you created to verify the instructions, do the following:

- 1. Manually create a new chain.
- 2. Assign the SVF file to the chain by right-clicking and selecting **Add Xilinx Device** and selecting the SVF file in the search window.
- 3. Right-click on the SVF file in the Boundary-Scan chain and select Execute XSVF/SVF.

Your device programming is complete, and you have successfully completed the *ISE In-Depth Tutorial* (*UG695*).





Appendix A

Additional Resources

Xilinx Resources

- *ISE Design Suite: Installation and Licensing Guide* (UG798): <u>http://www.xilinx.com/support/documentation/sw_manuals/xilinx13_4/iil.pdf</u>
- *ISE Design Suite: Release Notes Guide* (UG631): http://www.xilinx.com/support/documentation/sw_manuals/xilinx13_4/irn.pdf
- Product Support and Documentation: <u>http://www.xilinx.com/support</u>
- Xilinx Glossary: <u>http://www.xilinx.com/company/terms.htm</u>

ISE Design Suite Documentation

- Libraries Guides: <u>http://www.xilinx.com/support/documentation/dt_ise13-4_librariesguides.htm</u>
- ISE Design Suite Documents: http://www.xilinx.com/support/documentation/dt_ise13-4.htm
 - Command Line Tools User Guide (UG628): http://www.xilinx.com/support/documentation/sw_manuals/xilinx13_4/devref.pdf
 - *ISim In-Depth Tutorial* (*UG682*): <u>http://www.xilinx.com/support/documentation/sw_manuals/xilinx13_4/ug682.pdf</u>
 - Synthesis and Simulation Design Guide (UG626): http://www.xilinx.com/support/documentation/sw_manuals/xilinx13_4/sim.pdf
 - XST User Guide for Virtex-4, Virtex-5, Spartan-3, and Newer CPLD Devices (UG627):

http://www.xilinx.com/support/documentation/sw_manuals/xilinx13_4/xst.pdf

- XST User Guide for Virtex-6, Spartan-6, and 7 Series Devices (UG687): http://www.xilinx.com/support/documentation/sw_manuals/xilinx13_4/xst_v6s6.pdf

